




# TECH BRIEFS

ENGINEERING SOLUTIONS FOR DESIGN & MANUFACTURING



**A Changing Climate for CAD**


**Data Analysis Software Enables Real-Time  
Diagnosis of Complex Systems**

*Photonics Tech Briefs*

**REFERENCE**  
**COPY** MAR 14 2002  
**KSC LIBRARY**



# The Best Kept Secret in Data Logging...



## ...is right in your PC.

For 15 years, engineers and scientists have built increasingly flexible data logging systems using National Instruments data acquisition (DAQ) hardware and LabVIEW™ software.

Now NI introduces VI Logger, our ready-to-run, configuration-based data logging software for use stand alone or within LabVIEW. With VI Logger, you can:

- Easily log, view, and share data
- Interface to more than 100 DAQ and signal conditioning devices
- Export data to Microsoft Excel
- Migrate your logging tasks to LabVIEW for analysis, Web publishing, and more.

**Unlock the secret. Download VI Logger for a FREE 30 day trial.**

[ni.com/info](http://ni.com/info)

Visit [ni.com/info](http://ni.com/info) and enter na2c01 to download an evaluation version of VI Logger for a free 30-day trial and to run a brief VI Logger demo presentation.

**NATIONAL  
INSTRUMENTS™**

**(800) 258-7016**

Fax: (512) 683-9300 • [info@ni.com](mailto:info@ni.com)




# These Books Are Not For Sale®

They're **FREE** to people like yourself, who need to know!

**Reserve Your New,  
Hardbound  
Made In The USA  
Handbook  
and Encyclopedia™  
Today!**

- ✓ Temperature
- ✓ Pressure
- ✓ Load Cells
- ✓ Data Acquisition
- ✓ Humidity
- ✓ pH & Conductivity
- ✓ Panel Meters
- ✓ Controllers
- ✓ Recorders
- ✓ Flow
- ✓ Thermocouples
- ✓ RTD's
- ✓ Thermistors
- ✓ Connectors
- ✓ Level
- ✓ 2 Volumes, Over 3,000 Pages
- ✓ Full-Color, Hardbound Handbooks With Prices



From OMEGA's 96-page New Horizons®

**10** Collection Series

To Request Your DILBERT® Deck Card Pack, Dial: 1-(203)-329-1266

Get Your Dilbert Card Deck **Circle** No. 501

DILBERT® by Scott Adams

Online info at: [omega.com/dilbert](http://omega.com/dilbert)

Dilbert Decks No. 13 & 14 Available

**ORDER ONLINE!**  
Overnight Delivery!  
Over 100,000 Process  
Control Products Online!

**omega.com®**  
Ω OMEGA®  
**1-888-82-66342®**  
**1-888-TC-OMEGA**




e-mail: [info@omega.com](mailto:info@omega.com)

©COPYRIGHT 2002 OMEGA ENGINEERING, INC. ALL RIGHTS RESERVED.

**OMEGAfax™** 24-Hour-a-Day On-Demand Publishing System - Call 1-800-848-4271  
to request product information. Simply enter the document number associated with the item.





© David Corio

"IEEE is a magnet bringing engineers together.  
Engineering is a language that transcends  
bureaucracy and nationalism. It gives to us  
all a common language and understanding."

**Ya-Qin Zhang, IEEE Fellow**  
Managing Director, Microsoft Research Asia



Build relationships in a worldwide community of innovators. Join IEEE.

[www.ieee.org/apply](http://www.ieee.org/apply)



# Digi-Key<sup>®</sup>.com

## 1-800-DIGI-KEY

[www.digikey.com](http://www.digikey.com)

Parts Search →

GO

Quality Electronic Components, Superior Service

# Over 35,000 NEW PRODUCTS!

**NEW! Texas Instruments**  
Integrated Circuits

**NEW! Motorola**  
MCUs, MPUs, DSPs, ICs

**NEW! Intel**  
MPUs, MCUs, Flash Memory, ICs

**NEW! Kemet**  
SMT Ceramic Chip Capacitors

**NEW! Panasonic**  
LEDs, Ferrites, Capacitors

**NEW! Gems**  
Flow/Level Sensors

**NEW! Amphenol**  
Smart Cards, Circular Connectors

**NEW! International Rectifier**  
ICs, Hexfets, Schottky SSRs

**NEW! NKK Switches of America, Inc.**  
Toggle, Rocker, Illuminated Switches

**NEW! Zetex**  
Transistors, Filters, Mosfets, ICs

**NEW! Artesyn**  
DC-DC Converters, Power Supplies

**NEW! API Delevan**  
Inductors, Chokes

**NEW! Cadinal Components**  
Programmable Oscillators

**NEW! E-Switch**  
Switches

**NEW! Micorchip**  
IRed Encoder/Decoders

**NEW! Diodes, Inc.**  
Zener Diodes, Rectifiers

**NEW! Cambridge Radcuts**  
RF Connectors, Adapters

**NEW! Honeywell**  
Digital Compass Modules, Dev. Kits

**NEW! JW Miller**  
Chokes, Inductors

**NEW! Omron**  
Relays, Power Supplies, Timers

**NEW! Teccor**  
SCRs, Triacs, Rectifiers

**NEW! Power Tends**  
Converters, Regulators

**NEW! Xicor**  
Digital Pots, Memory ICs

**NEW! LEM**  
Current Transducers

**NEW! Meder Electronics**  
Reed Sensors

**NEW! Schaevitz Sensors**  
Sensors - LVDT

**NEW! Crydom**  
G2 Series Solid State Relays

**NEW! CTS**  
BGA Terminators, Networks

**NEW! Bud Industries**  
Enclosures

Circle No. 523 or Enter No. 523





# In the world of CAD/CAM,



## VX Overdrive™. Premium-performance CAD/CAM



### ***Design through manufacturing with no stops***

VX® blows the doors off of CAD/CAM with a value-priced, design-through-manufacturing


system so superior it leaves everything else in the dust. New VX Overdrive is so feature-rich, so fun to drive, what used to be roadblocks at every phase now become thrilling curves you can negotiate with ease.

### ***So easy to use***

VX Overdrive is loaded with flexibility to help you fly through even the toughest jobs. Unique surface creation tools let you blast through challenges at high speed. And its full integration from design through manufacturing means engineers can

bring projects to market faster using a single, seamless system. With VX

Overdrive, if you can imagine it, you can build it.





# we're changing the rules.

that's fun to drive.

***Premium performance  
without the premium price***

VX Overdrive comes fully loaded so you'll get the most bang for your buck of any system, plus the ability to import legacy data and the highest level of interoperability on the market (STEP, IGES and direct CAD translators).



***Take a test spin***

See for yourself how VX Overdrive is changing the rules. Contact us for a demo today.



**VX®** Shaping the future of CAD/CAM™

**VX.COM 321-676-3222**

For Free Info Circle No. 546 or Enter No. 546 at [www.nasatech.com/rs](http://www.nasatech.com/rs)

©2001, VX Corporation. VX Overdrive and the VX logo are trademarks of VX Corporation.





## FEATURES

- 22 Application Briefs**
- 24 A Changing Climate for CAD**

## SOLUTIONS



- 32 Technology Focus: Data Acquisition**
  - 32 Parallel-Processing High-Rate Digital Demodulator ASIC
  - 33 Reusable Software for Autonomous Diagnosis of Complex Systems
  - 35 TAXI Direct-to-Disk Interface Demultiplexes Proprietary Formatted Data
  - 37 Program Improves Transfer of Data From CAD to Machine Shops
  - 38 Compensating for Motion Errors in UWB SAR Data



- 40 Software**
  - 40 Program for International-Temperature-Scale Calculations
  - 40 Updated Global Atmospheric Reference Model Computer Programs
  - 42 Gyroscope Automated Testbed



- 43 Electronic Components and Systems**
  - 43 Nanoelectronic Devices With Precise Atomic-Scale Structures
  - 44 Mounting Flip Chips on Heat-Dissipating, Matched-CTE Boards
  - 46 Lightweight, Dimensionally Stable Printing-Wiring Boards



- 50 Materials**
  - 50 Protective Solid Electrolyte Films for Thin Li-Ion Cells




- 52 Mechanics**
  - 52 Study of Turbulent Boundary Layer on the F-15B Airplane
  - 55 Improved Alignment Mechanism for Robotic Drilling
  - 58 Measuring Volume of Incompressible Liquid in a Rigid Tank



- 59 Machinery/Automation**
  - 59 Vision-Based Maneuvering and Manipulation by a Mobile Robot



- 61 Manufacturing**
  - 61 Photolithographic Fine Patterning of Difficult-to-Etch Metals
  - 63 Software for Optimized Flattening From 3D to 2D
  - 64 Electron-Beam Welding of Superalloys at High Temperatures



24



22



79


## DEPARTMENTS

- 12 Commercial Technology Team**
- 14 UpFront**
- 16 Reader Forum**
- 18 Who's Who at NASA**
- 20 NASA Patents**
- 30 Technologies of the Month**
- 82 Advertisers Index**

## NEW FOR DESIGN ENGINEERS

- 79 Products/Software**
- 80 Literature**

## SPECIAL SUPPLEMENT




### 1a - 22a Photonics Tech Briefs

*Follows page 42 in selected editions only.*



“The application of  
this software is  
universal -  
the only limit  
is in one's  
imagination.”

-ALGOR customer **Phil Piszczak**,  
Preformed Line Products



## ▶ National HDTV Conversion Effort Requires Re-Engineered Transmission Towers

Preformed Line Products (PLP®), a \$200 million global leader in the manufacture of cable anchoring systems headquartered in Cleveland, Ohio, is contributing to the national conversion from analog TV to high-definition television (HDTV) with its ROCKET-SOCKET™ Dead-end for guy wires, which supports the transmission towers that will be taller, bigger and heavier to bear HDTV's dramatically improved wide screen digital audio/video information. PLP's customer base includes most of the nation's power utility providers and communication providers such as Verizon, Bell South and Adelphia in addition to a variety of resellers.



### THE CHALLENGE

To design the dead-end to support the large communication/broadcast transmission towers that would withstand typical loads including 252,000 pounds of structural weight and wind loading as well as dynamic loads that might result from accidental impact.



### THE SOLUTION

PLP engineers chose ALGOR to analyze the ROCKET-SOCKET design. PLP used the material austempered ductile iron for increased strength and toughness, rather than ductile iron, which they have used for other dead-end components.

The geometry was modeled in PRO/ENGINEER, captured directly in ALGOR and then an impact analysis was performed with ALGOR Mechanical Event Simulation (MES) software. The result was a modification to the geometry of the ROCKET-SOCKET Dead-end to better withstand higher mechanical loadings. By using MES, PLP engineers were able to expedite the testing, reduce the number of iterations in the laboratory and get their product to market more quickly.

**autodesk**  
authorized developer

**PTC**  
Enterprise  
Software  
Partner

**SolidWorks**  
SOLIDWORKS  
CORPORATION

**CADKEY**  
KEY PARTNER

**SOLID EDGE**  
SOLID EDGE  
CORPORATION

**ALGOR**

**ALGOR, Inc.**  
150 Beta Drive  
Pittsburgh, PA 15238-2932 USA  
Phone 1.412.967.2700  
Fax 1.412.967.2781

**challenge@algor.com**  
**challenge.ALGOR.com**

USA/Canada  
1.800.48.ALGOR

France  
0.800.918.917

Italy  
800.783.132

Singapore  
800.120.3775

United Kingdom  
0.800.731.0399

All trademarks may be trademarks or registered trademarks of their respective owners.

For Free Info Circle No. 513 or Enter No. 513 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## 65 Bio-Medical

- 65 Petri-Dish Spreaders Sterilized by Electrical Heating
- 66 Quantifying Microbial Diversity Through Dilution/Extinction

## 68 Physical Sciences

- 68 Electrochemical Systems Generate Ozone and Ozonated Water
- 70 Solar Simulator for a Portable Solar-Absorptance Instrument
- 71 Portable Instrument Detects Very Dilute Airborne Organics

## 73 Books and Reports

- 73 Quantum Mechanics of Harmonic Oscillator in External Fields
- 73 Algorithms for Collision-Avoidant Formation Flying
- 73 Integrated Colloid Thrusters for Microspacecraft
- 74 PCI Bridge to Instruments and Telecommunication Systems
- 74 Effect of Gravitation on Noninteracting Trapped Fermions
- 75 Improvements in a Piezoelectrically Actuated Microvalve
- 75 Low-Energy Transfer From Near-Earth to Near-Moon Orbit

This document was prepared under the sponsorship of the National Aeronautics and Space Administration. Neither Associated Business Publications Co., Ltd. nor the United States Government nor any person acting on behalf of the United States Government assumes any liability resulting from the use of the information contained in this document, or warrants that such use will be free from privately owned rights. The U.S. Government does not endorse any commercial product, process, or activity identified in this publication.

## PRODUCT OF THE MONTH

The TPS600 rugged power supplies from Tracewell Power (Lewis Center, OH) provide a pluggable, multiple power supply backup for all equipment in a system.



# 14

## ON THE COVER





Created with Autodesk Inventor 3D design software from Autodesk (San Rafael, CA), this image details the right-side rear end of a race car by PacWest Racing Group of Indianapolis, IN. The 2D drawing and 3D solid modeling aspects highlighted in this image illustrate the migration of 2D to 3D that many CAD users are faced with today. The feature beginning on page 24 includes insights from CAD industry leaders on this and other issues facing the CAD market.

(Image created by John Helfen, Autodesk)

Permissions: Authorization to photocopy items for internal or personal use, or the internal or personal use of specific clients, is granted by Associated Business Publications, provided that the flat fee of \$3.00 per copy be paid directly to the Copyright Clearance Center (222 Rose Wood Dr., Danvers, MA 01923). For those organizations that have been granted a photocopy license by CCC, a separate system of payment has been arranged. The fee code for users of the Transactional Reporting Service is: ISSN 0145-319X/94 \$3.00+.00

# Ready. Aim. Digitize.

## MEASURE ANYTHING, ANYWHERE WITH VULCAN... THE ONE PERSON, 3D MEASUREMENT SYSTEM



Now you can quickly and easily measure and create digital models of complicated shapes, objects, and work sites anywhere.

Vulcan uses 3D-Intelligence® to quickly record the precise position of a handheld receiver. Just touch a point and record it... even hidden points. It offers the ease of use of a laser (without leveling), the functionality of GPS, and the accuracy of a Total Station in one product. It is the fastest method available to collect, store, edit and view 3D measurements in real time... which saves you money. Plus it can be used by multiple users at the same time.

Vulcan allows you to transfer data easily to and from a personal computer for use in CAD and Windows® based programs. Better yet, Vulcan can run a Pocket PC version of CAD (PocketCAD®) directly on-board.

For more detailed information visit  
[www.arcsecond.com](http://www.arcsecond.com).

# VULCAN

3D Measurement System

Vulcan is from ArcSecond – the leader in advanced metrology applications – and is ideal for a variety of industries and applications, including:

As-built      Law Enforcement      Boat Building      Visual Effects      Custom R&D

© 2002 Arc Second, Inc. All rights reserved. All trademarks or registered trademarks are the property of their respective owners.

3D-Intelligence  
TECHNOLOGY

ArcSecond



I design.  
I discover. I invent.  
I solve.  
I collaborate.  
I create. I innovate.

I am an engineer and I want to make a difference in my job and in this world. I work with formulas and models, vectors and forces, details and standards. I think in terms of mathematical expressions—not programming languages—so I rely on tools that are intuitive, reliable and deliver exceptional performance. I need to share my work with colleagues and clients anywhere and anytime. I need a tool that maximizes my productivity so I have the freedom to be more creative.

I am a Mathcad believer.

**Mathcad®**

**PART OF EVERY SOLUTION.**

No mathematical software is more flexible or easier to use. With over 1.5 million copies sold, Mathcad can be found at 90% of the Fortune 1000 and in 500 government agencies. Volume licensing and government pricing are available. Become a Mathcad believer. To request a FREE evaluation copy for your organization, call 1-800-628-4223 or visit [www.mathcad.com/eval](http://www.mathcad.com/eval).

RESELLERS:



**Math Soft**



# do you need more... speed

NE/Nastran V8.1 adds one of the **fastest iterative solvers** available today for linear and nonlinear solutions. The PCGLSS solver is 10-20 times faster than typical sparse direct solvers. It requires considerably less memory and can handle models with over **2 million** degrees of freedom using any combination of element types.



## PLUS:

- True surface to surface contact
- A new NE/Nastran editor
- A new job queuing system allows the user to run multiple jobs in series or parallel
- A new line search algorithm reduces nonlinear analysis time up to 25%

# do you need more... support




## New .OP2 interface

Already using **Hypermesh®** or **Patran®**? NE/Nastran can now power your results with speed and accuracy.



Now go DIRECT from **Pro/E®** to NE/Nastran using the new .OP2 interface.



**FEMAP®** users get a true 3D surface-to-surface contact and non-linear cable element interface.

# then you need... NE/Nastran v8.1 for Windows

Noran Engineering, Inc. announces the release of NE/Nastran V8.1, the latest upgrade of it's powerful, affordable, and easy-to-use finite element analysis (FEA) tool for engineers in practically all disciplines.



**Noran Engineering, Inc.**

www.NENastran.com

Toll-Free: 1.877.NENastran

Phone: 562.799.9911

2001 NE, Noran Engineering, Inc. NE/NEI, and NEI logo are Registered Trademarks of Noran Engineering, Inc. NASTRAN is a registered trademark of the National Aeronautics and Space Administration. Windows is a registered trademark of the Microsoft Corporation. All other trademarks and registered trademarks are the property of their respective owners.

W  
W  
W  
•  
N  
E  
N  
a  
s  
t  
r  
a  
n  
•  
c  
o  
m  
1  
•  
8  
7  
7  
•  
N  
E  
N  
a  
s  
t  
r  
a  
n



**TECH BRIEFS**  
www.nasatech.com



Published by ..... **Associated Business Publications**  
Publisher ..... **Joseph T. Pramberger**  
Editor/Associate Publisher ..... **Linda L. Bell**  
Editor, Market Focus Editions ..... **Robert Clark**  
Associate Editor/Internet Editor ..... **Laura Raduta**  
Production Manager ..... **Joanne Gaccione**  
Assistant Production Manager ..... **John Iwanciw**  
Art Director ..... **Lois Erlacher**  
Senior Designer ..... **Christopher Coleman**  
Circulation Manager ..... **Hugh J. Dowling**

**BRIEFS & SUPPORTING LITERATURE:** Written and produced for NASA by  
**Advanced Testing Technologies, Inc.**, Hauppauge, NY 11788

Technical/Managing Editor ..... **Ted Selinsky**  
Sr. Technical Analyst ..... **Dr. Larry Grunberger**  
Art Manager ..... **Eric Starstrom**  
Staff Writers/Editors ..... **Dr. Theron Cole, George Watson**  
Graphics ..... **Robert Simons**  
Editorial & Production ..... **Joan Schmiemann, Becky D. Bentley**

## NASA:

NASA Tech Briefs are provided by the National Aeronautics and Space Administration, Technology Transfer Division, Washington, DC:

Administrator ..... **Sean O'Keefe**  
Director, Commercial Technology ..... **Dr. Robert Norwood**  
Publications Director ..... **Carl Ray**

**ASSOCIATED BUSINESS PUBLICATIONS INTERNATIONAL**  
317 Madison Avenue, New York, NY 10017-5391  
(212) 490-3999 FAX (212) 986-7864

Chairman/Chief Executive Officer ..... **Bill Schnirring (bill@abpi.net)**  
Vice Chairman/Chief Operating Officer ..... **Domenic A. Mucchetti**  
MIS Manager ..... **Ted Morawski**  
Webmaster ..... **Albert Sunseri**  
Director of Electronic Products ..... **Luke Schnirring**  
eStrategy Director ..... **Andrew Runk**  
Credit/Collection ..... **Felecia Lahey**  
Human Resources Manager ..... **Lourdes Del Valle**  
Accounting Manager ..... **Sylvia Ruiz**  
Office Manager ..... **Alfredo Vasquez**

## NASA TECH BRIEFS ADVERTISING ACCOUNT EXECUTIVES


Headquarters ..... (212) 490-3999  
CT, MA, NH, ME, VT, RI, Eastern Canada ..... **Ed Marecki**  
at (401) 351-0274  
NJ, NY, PA, DE ..... **Jim Oot**  
at (973) 983-2757  
VA, MD, DC, NC, SC, GA, FL, AL, TN, MS, LA, AR, OK, TX ..... **Bill Manning**  
at (770) 971-0677  
MN, ND, SD, WI, IL ..... **Bob Casey**  
at (847) 223-5225  
IN, KY, MI, OH, MO, KS, IA, NE, Western PA & NY, Central Canada ..... **Chris Casey**  
at (847) 223-5225  
N. Calif., CO ..... **Bill Hague**  
at (800) 830-4351  
WA, OR, ID, MT, WY, UT, NV, Western Canada ..... **David Chew**  
at (650) 726-2128  
S. Calif., AZ, NM ..... **Tom Boris**  
at (949) 642-2785  
Internet Advertising ..... **Luke Schnirring**  
at (212) 490-3999  
Postcard/Literature Advertising ..... **John Waddell**  
at (212) 490-3999  
Reprints ..... **Jeannie Martin**  
at (866) 879-9144

**For a complete list of staff e-mail addresses,  
visit [www.abpi.net](http://www.abpi.net)**





## ▲ Welding Copper-Nickel Foil with CO<sub>2</sub> Lasers



**A weld created** using a Synrad CO<sub>2</sub> laser on copper-nickel foil.

CO<sub>2</sub> lasers are useful in a broad range of welding applications. The photo to the left shows the results of welding 0.0025"-thick sheets of copper-nickel alloy foil. Used in aerospace, automotive, and many other industries, the material was welded with a Synrad Evolution™ 125-watt laser. The weld was made at a velocity of 110" per minute with a 2.5" focal length lens having a spot size of 0.004". Argon gas, at 2 psi, was used for shielding.

The key to achieving virtually no heat deformation and a uniform weld bead is in selecting proper pulsing parameters for the laser. In this case, a pulse frequency of 685 Hz and a pulse length of 880 microseconds provided the weld characteristics desired. Changing the thickness or width of the weld bead is simply a matter of experimenting with variations in beam velocity, pulse frequency, or pulse length.

## ▲ Laser Cutting Urethane Bushings

The 2.5"-thick urethane bushing shown to the right was cut in nine seconds while being rotated underneath a 240 watt CO<sub>2</sub> laser beam. Although a slight discoloration is present, no charring of the urethane material occurs.

To cut the material, a 7.5" focal length lens with a 0.5" depth of focus and a 0.012" spot size was used. The bushing was rotated at 140 rpm during cutting, which took nine seconds (21 revolutions). Nitrogen assist gas at 20 psi was used while cutting.



**This Urethane Bushing** was cut with a 240 watt Synrad laser.

## ▲ Laser Marking Fast Bar Codes on Inked Paper

This 24 character Code 128 bar code, including human-readable text, was marked on inked paper in only one second! The bar code, measuring 1.5" long by 0.5" high, was marked by a marking head and Synrad laser driven by WinMark Pro™ laser marking software. 20 watts of laser power were used to achieve a velocity of 250" per second.



**Using a Synrad 25 watt marking system**, these codes were marked at 250" per second!

Discover more CO<sub>2</sub> laser applications!  
Sign up for our monthly online  
Applications Newsletter at  
**[www.synrad.com/signup1](http://www.synrad.com/signup1)**

*All applications on this page were processed at Synrad's Applications Laboratory. Synrad, the world's leading manufacturer of sealed CO<sub>2</sub> lasers, offers free process evaluations to companies with qualified applications. Call 1-800-SYNRAD1 for more information.*



NASA's R&D efforts produce a robust supply of promising technologies with applications in many industries. A key mechanism in identifying commercial applications for this technology is NASA's national network of commercial technology organizations. The network includes ten NASA field centers, six Regional Technology Transfer Centers (RTTCs), the National Technology Transfer Center (NTTC), business support organizations, and a full tie-in with the Federal Laboratory Consortium (FLC) for Technology Transfer. Call (609) 667-7737 for the FLC coordinator in your area.

## NASA's Technology Sources

If you need further information about new technologies presented in *NASA Tech Briefs*, request the Technical Support Package (TSP) indicated at the end of the brief. If a TSP is not available, the Commercial Technology Office at the NASA field center that sponsored the research can provide you with additional information and, if applicable, refer you to the innovator(s). These centers are the source of all NASA-developed technology.

### Ames Research Center

Selected technological strengths: Information Technology; Biotechnology; Nanotechnology; Aerospace Operations Systems; Rotorcraft; Thermal Protection Systems.  
*Carolina Blake* (650) 604-1754  
cblake@mail.arc.nasa.gov

### Dryden Flight Research Center

Selected technological strengths: Aerodynamics; Aeronautics Flight Testing; Aeropropulsion; Flight Systems; Thermal Testing; Integrated Systems Test and Validation.  
*Jenny Baer-Riedhart* (661) 276-3689  
jenny.baer-riedhart@dfrc.nasa.gov

### Goddard Space Flight Center

Selected technological strengths: Earth and Planetary Science Missions; LIDAR; Cryogenic Systems; Tracking; Telemetry; Remote Sensing; Command.  
*George Alcorn* (301) 286-5810  
galcorn@gsfc.nasa.gov

### Jet Propulsion Laboratory

Selected technological strengths: Near/Deep-Space Mission Engineering; Microspacecraft; Space Communications; Information Systems; Remote Sensing; Robotics.  
*Merle McKenzie* (818) 354-2577  
merle.mckenzie@jpl.nasa.gov

### Johnson Space Center

Selected technological strengths: Artificial Intelligence and Human Computer Interface; Life Sciences; Human Space Flight Operations; Avionics; Sensors; Communications.  
*Charlene E. Gilbert* (281) 483-3809  
commercialization@jsc.nasa.gov

### Kennedy Space Center

Selected technological strengths: Fluids and Fluid Systems; Materials Evaluation; Process Engineering; Command, Control and Monitor Systems; Range Systems; Environmental Engineering and Management.  
*Jim Aliberti* (321) 867-6224  
Jim.Aliberti-1@ksc.nasa.gov

### Langley Research Center

Selected technological strengths: Aerodynamics; Flight Systems; Materials; Structures; Sensors; Measurements; Information Sciences.  
*Sam Morello* (757) 864-6005  
s.a.morello@larc.nasa.gov

### John H. Glenn Research Center at Lewis Field

Selected technological strengths: Aeropropulsion; Communications; Energy Technology; High Temperature Materials Research.  
*Larry Viterna* (216) 433-3484  
cto@grc.nasa.gov

### Marshall Space Flight Center

Selected technological strengths: Materials; Manufacturing; Nondestructive Evaluation; Biotechnology; Space Propulsion; Controls and Dynamics; Structures; Microgravity Processing.  
*Vernotto McMillan* (256) 544-2615  
vernotto.mcmillan@msfc.nasa.gov

### Stennis Space Center

Selected technological strengths: Propulsion Systems; Test/Monitoring; Remote Sensing; Nonintrusive Instrumentation.  
*Kirk Sharp* (228) 688-1929  
kirk.sharp@ssc.nasa.gov

## NASA Program Offices

At NASA Headquarters there are seven major program offices that develop and oversee technology projects of potential interest to industry. The street address for these strategic business units is: NASA Headquarters, 300 E St. SW, Washington, DC 20546.

**Carl Ray**  
**Small Business Innovation Research Program (SBIR) & Small Business Technology Transfer Program (STTR)**  
(202) 358-4652  
cray@mail.hq.nasa.gov

**Dr. Robert Norwood**  
**Office of Commercial Technology (Code RW)**  
(202) 358-2320  
rnorwood@mail.hq.nasa.gov

**John Mankins**  
**Office of Space Flight (Code MP)**  
(202) 358-4659  
jmankins@mail.hq.nasa.gov

**Terry Hertz**  
**Office of Aero-Space Technology (Code RS)**  
(202) 358-4636  
thertz@mail.hq.nasa.gov

**Glen Mucklow**  
**Office of Space Sciences (Code SM)**  
(202) 358-2235  
gmucklow@mail.hq.nasa.gov

**Roger Crouch**  
**Office of Microgravity Science Applications (Code U)**  
(202) 358-0689  
rcrouch@hq.nasa.gov

**Granville Paules**  
**Office of Mission to Planet Earth (Code Y)**  
(202) 358-0706  
gpaules@mtpe.hq.nasa.gov

## NASA's Business Facilitators

NASA has established several organizations whose objectives are to establish joint sponsored research agreements and incubate small start-up companies with significant business promise.

**Wayne P. Zeman**  
**Lewis Incubator for Technology**  
Cleveland, OH  
(216) 586-3888

**B. Greg Hinkebein**  
**Mississippi Enterprise for Technology**  
Stennis Space Center, MS  
(800) 746-4699

**Julie Holland**  
**NASA Commercialization Center**  
Pomona, CA  
(909) 869-4477

**Bridgette Smalley**  
**UH-NASA Technology Commercialization Incubator**  
Houston, TX  
(713) 743-9155

**John Fini**  
**Goddard Space Flight Center Incubator**  
Baltimore, MD  
(410) 327-9150 x1034

**Thomas G. Rainey**  
**NASA KSC Business Incubation Center**  
Titusville, FL  
(407) 383-5200

**Joanne W. Randolph**  
**BizTech**  
Huntsville, AL  
(256) 704-6000

**Joe Becker**  
**Ames Technology Commercialization Center**  
San Jose, CA  
(408) 557-6700

**Marty Kaszubowski**  
**Hampton Roads Technology Incubator (Langley Research Center)**  
Hampton, VA  
(757) 865-2140

## NASA-Sponsored Commercial Technology Organizations

These organizations were established to provide rapid access to NASA and other federal R&D and foster collaboration between public and private sector organizations. They also can direct you to the appropriate point of contact within the Federal Laboratory Consortium. To reach the Regional Technology Transfer Center nearest you, call (800) 472-6785.

**Joseph Allen**  
**National Technology Transfer Center**  
(800) 678-6882

**Ken Dozier**  
**Far-West Technology Transfer Center**  
University of Southern California  
(213) 743-2353

**James P. Dunn**  
**Center for Technology Commercialization**  
Westborough, MA  
(508) 870-0042

**B. David Bridges**  
**Southeast Technology Transfer Center**  
Georgia Institute of Technology  
(404) 894-6786

**Gary Sera**  
**Mid-Continent Technology Transfer Center**  
Texas A&M University  
(409) 845-8762

**Charles Blankenship**  
**Technology Commercialization Center**  
Newport News, VA  
(757) 269-0025

**Pierrette Woodford**  
**Great Lakes Industrial Technology Transfer Center**  
Battelle Memorial Institute  
(216) 898-6400

**NASA ON-LINE:** Go to NASA's Commercial Technology Network (CTN) on the World Wide Web at <http://nctn.hq.nasa.gov> to search NASA technology resources, find commercialization opportunities, and learn about NASA's national network of programs, organizations, and services dedicated to technology transfer and commercialization.

If you are interested in information, applications, and services relating to satellite and aerial data for Earth resources, contact: Dr. Stan Morain, **Earth Analysis Center**, (505) 277-3622.



# TEAC®



V-80

## STILL MASTERS OF AIRBORNE RECORDING TECHNOLOGY!

### DIGITAL SOLID STATE AND HI-8MM

If you're flying TEAC Hi-8mm airborne video tape recorders, you may be considering migrating to solid state video recorders. But on some aircraft upgrades, JSF, or other new programs you may be thinking... let's combine aircraft digital data and video.

Our new digital solid state Mission Data Recorder (MDR-80) offers an all-in-one solution with all the plug-in configurations you'll need. Over 50 configurations that combine airborne MPEG-2 video recording with key functions like video burst receive/transmit, mission data loading, 1553, and ACMI recording. All in a unit that conveniently fits into your existing V-80 slot for that cost-effective drop-in upgrade.

Not ready for the move to digital? We also offer many options for your existing V-80/83 Hi-8mm recorders including video burst transmission, multisync playback stations and more. Now installed in over 35 aircraft configurations. All with proven reliability, worldwide support, and unquestioned quality. Our new MDRs will deliver the "drop-in" digital upgrade when you are ready.

The questions are yours... the answer is still TEAC.

*If it's worth a mission, it's worth a*

**TEAC®**  
Airborne Products Division

www.teac-recorders.com  
Tel. 323-727-4866 • Fax 323-727-4877  
e-mail: airborne@teac.com



MDR-80



V-83

SSMDR



ME-1000



## PRODUCT OF THE MONTH

The TPS600 rugged power supplies from Tracewell Power, Lewis Center, OH, are designed for applications requiring uninterrupted operation, including computer, data storage, and telecon/data communications. The five-output TPS600 supplies up to 600W at 50°C, and up to 420W at 70°C. Multiple output configurations are available to cover a range of power requirements. The units are compatible with N+1 redundancy configuration, providing a pluggable, multiple power supply backup for all equipment in a system. All input and output connections are through a single, rear-panel, 60-pin connector that provides hot-swap capability for standard card or power backplanes. LED status indicators on the front panel show input and output OK. Interface signals meeting CompactPCI Power Interface specs are available for controlling and monitoring the power supply.

For Free Info Circle No. 715 or Enter No. 715  
at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## NASA Welding Technology Hits the Market

Two commercial companies — MTS Systems of Eden Prairie, MN, and MCE Technologies of Seattle, WA — have successfully commercialized a welding tool developed at NASA's Marshall Space Flight Center in Alabama.


Friction stir welding uses the high rotational speed of a tool

and the resulting frictional heat created from contact to "stir" together and bond two metal alloys. The process, however, relies on a single-piece pin tool, which can leave "keyholes" when welding cylindrical objects. The Marshall team designed an automatic retractable pin tool that uses a computer-controlled motor to automatically retract the pin into the shoulder of the tool at the end of the weld, preventing keyholes.

MTS Systems used the pin tool technology in its recent friction stir welding process system. Used by automotive, shipbuilding, and other industries, the system has proven cost-effective and efficient.

MCE Technologies (MCETEC) developed a line of production stir welding equipment using Marshall's pin tool for welding high-performance aluminum alloys. MCETEC's use of the NASA technology has contributed to production advantages such as reduced contamination and greater joint strength.

For more information on this and other NASA Marshall technologies available for commercialization, visit [www.nasasolutions.com](http://www.nasasolutions.com).




MCETEC's friction stir welding equipment incorporates NASA Marshall's pin tool technology.

## Next Month in NTB

In the April issue, the winners of the 2001 Readers' Choice Product of the Year Awards will be featured. We'll let you know which product you chose as the most significant new introduction to the engineering community last year. Also, look for our preview of the Sensors Expo, which will highlight the hottest sensor products that will be on display at the show in San Jose in May.





Sooner or later, every design becomes 3D.  
This is an argument for sooner.



LASER WELDER BY INCISION LASERTEC

Introducing **Autodesk Inventor™ Series**. We've paired the groundbreaking Autodesk Inventor 3D technology with the AutoCAD®-based Autodesk® Mechanical Desktop®, creating a flexible design solution that helps you move from 2D to 3D without giving up your current system. For Dr. Markus Bohrer, General Manager of Incision Lasertec, the breakthrough adaptive technology and industry-leading DWG compatibility has helped increase productivity: "With Inventor we finished our latest, highly complex machine in only 8 months. Without Inventor it would have taken us twice the time." Are you ready for 3D made easy? Experience the freedom to design without limits. Visit [www.autodesk.com/inventorseries](http://www.autodesk.com/inventorseries) to find out more.

**autodesk®**

©2002 Autodesk, Inc. Autodesk, the Autodesk logo, AutoCAD, Autodesk Inventor, and Mechanical Desktop are either registered trademarks or trademarks of Autodesk, Inc., in the USA and/or other countries. All other brand names, product names, or trademarks belong to their respective holders.

**For Free Info Circle No. 507 or Enter No. 507 at [www.nasatech.com/rs](http://www.nasatech.com/rs)**



# The solution you're looking for may be right at

## your fingertips.

The solution is **Inastomer**, an exquisitely fine, elastic material for precise pressure sensing.

Choose the PX series for high density, high capacity analysis. Over 16,000 points of measurement, 0.5mm of resolution, and only 0.621mm thick. These pressure distribution sheets offer 3-dimensional, 7 color displays, with rotatable views (64x64mm to 640x640mm).

For the same great qualities in a smaller size, choose flexible adhesive pressure sensors. They are perfect for soft touch products and contact pressure applications such as robotics and mechanical equipment. Standard sizes are 2.9mm to 5.9mm square and 10mm round, but custom shapes and sizes are welcome.

IESF-X

SF-X

Also offering  
the SS-13  
stroke  
sensor  
with  
4.0kgf  
max  
load!

PX

Call us to find your solution!

1-800-275-4899

www.cuistack.com CUI STACK

## Reader Forum

Reader Forum is dedicated to the thoughts, concerns, questions, and comments of our readers. If you have a comment, a question regarding a technical problem, or an answer to a previously published question, post your letter to Reader Forum on-line at [www.nasatech.com](http://www.nasatech.com), or send to: Editor, *NASA Tech Briefs*, 317 Madison Ave., New York, NY 10017; Fax: 212-986-7864. Please include your name, company (if applicable), address, and e-mail address or phone number.

I am exciting a small PZT in shear mode, over the range of 1.7 to 3.3 MHz, with a variable-amplitude source. To close an amplitude control loop, I'd like to measure the motion envelope, which is on the order of 0 to 10 microns, with a very small sensor (large laser interferometry is not possible). In addition, I have multiple assemblies spaced horizontally over an area of roughly 1/4" by 4". The units and the individual sensors must be housed in an enclosure with vertical cross-section dimensions of about 18 mm by 4.5". Each PZT is vibrating a cone-shaped element, about 0.2" in diameter at its base, and 0.5" tall. I must sense motion at the tip of the cone. What about detecting a projected image on a semiconductor sensor? Any sensor sources that I can investigate? Thanks.

Rudy Schneider  
[rudy.schneider@noveraoptics.com](mailto:rudy.schneider@noveraoptics.com)

We are currently working on developing a wireless video system to be used in a sports-related environment that demands constant movements by the wearer of our micro-video cameras. We have tested 2.4 systems and have seen very poor results. All of our tests have been with portable transmitters and receivers. We are about to try patch antennas worn on both sides of the athlete's body going to a portable 2.4 receiver. It's been suggested that we try a YAGI antenna for receiving, and hopefully by combining a dual patch antenna system, this will work. If anyone has any other suggestions or can direct us to a reliable source of miniature equipment for transmitting and receiving, it would be greatly appreciated. Also, if anyone has information on a repeater design to send the signals to other portable stations, that would be welcomed. Size and weight are concerns in all cases.

Michael Jones  
[concepts@capital.net](mailto:concepts@capital.net)

I am a chartered physiotherapist interested in looking at hyperbaric medicine for the treatment of soft tissue injuries, including grade two ankle sprains. Has any research been done using the lightweight chambers for such use, and how can I find details on where to obtain one? Thank you.

Jo Shepherd  
[physio.jo@virgin.net](mailto:physio.jo@virgin.net)



# Expand your capabilities...



## ...faster, better, more affordably.

**Anywhere you need to go, our rugged portables are ready.** FlexPAC™ is available with six full-size expansion slots, an Intel Pentium® 4 processor running at 2 GHz, system memory up to 2 GB, and video memory of 16 MB. That means you won't find a more robust industrial portable computer anywhere. And with its new rugged design and lifetime guaranteed configuration control, FlexPAC is also remarkably affordable. No wonder companies like Agilent and National Instruments have made Dolch their choice.

Check it out along with other Dolch products at [www.DolchNTB.com](http://www.DolchNTB.com) or call 877.347.4924.

©2002 Dolch Computer Systems, Inc. FlexPAC is a trademark of Dolch Computer Systems, Inc. All other brand or products named are trademarks or registered trademarks of their respective companies.

For Free Info Circle No. 512 or Enter No. 512 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



# SMALLEST STABLE CABLE™ EVER

## High Performance Microwave Cable Assemblies

- Phase & IL stable over temperature
- 4°K to 900°C temperature range
- Reliable under extreme shock, vibration and radiation
- Premium SiO<sub>2</sub> dielectric
- Stainless steel jacket

ENGINEERING EXPERTISE FOR  
DIVERGENT APPLICATIONS



0.047-inch diameter  
NEW!

# KAMAN

[www.stablecable.com](http://www.stablecable.com)  
719-635-6954

For Free Info Circle No. 404 or  
Enter No. 404 at [www.nasatech.com/rs](http://www.nasatech.com/rs)

## Who's Who at NASA

### Dr. Jim Weiss, Chief Engineer and Technologist, Earth and Space Sciences Division, Jet Propulsion Laboratory

**D**r. Jim Weiss is the Program Manager for Collaborative Neural Repair at NASA's Jet Propulsion Laboratory in Pasadena, CA. His team is working to develop a robotic device that will aid patients with spinal cord injuries.



#### **NASA Tech Briefs: What is the device, and how will it work?**

**Dr. Jim Weiss:** The original idea was to develop something that could be used for the rehabilitation of people with spinal cord injuries and also the training of astronauts. The device has not been built yet. We're currently doing the design work and testing some of the components. A patient will be suspended on a treadmill by lines connected to an overhead hoist. The robotics will be attached to the patient's legs and to the treadmill in the form of a motor. The motor is going to monitor and control the movement of the person while they're walking on the moving treadmill. Basically, we'll put someone on the treadmill, start the treadmill, and then use robotic arms attached to their knees to help them walk.

The device will help prepare astronauts for work in space. One of the problems of being in a zero-gravity environment is that you don't utilize your legs, and your neurology forgets how to function properly. So when you return to Earth and you've not used your legs, you've forgotten how to use them. They're weak and they're atrophied.

There is a central pattern generator in one's spinal cord that controls the motion of locomotion — all the fine motor functions that control the muscles — and if that's not refreshed on a regular basis, it forgets and starts learning a new environment as part of being adaptive. We would use this to train astronauts for different environments, so when they return to Earth, they would be able to walk normally.

#### **NTB: Do you see any other applications for this device?**

**Dr. Weiss:** There are other things that it could be used for, such as training football players to sprint faster, or to help basketball players perform with more power. So, you could actually train the human body to operate better at sports like volleyball, basketball, football, or baseball.

Also, it would be applicable for controlled exercising. You could have controlled exercise, for instance, if a patient has a knee, ankle, or hip injury, or they've had some serious surgery on their leg and they've got to exercise to regain strength. When you've got an injury, you favor the other limb. This system could be used to make sure a patient doesn't favor the other limb so they re-learn normal function, and movement is complete. I've only spoken of the applications that are leg-dominant. You could do the same things with arms and other parts of the body. Motion is what we're really focusing on.

#### **NTB: Who are NASA's partners in the research and development?**

**Dr. Weiss:** UCLA was our primary partner in this. There's more in the development; it's now expanded to a collaboration with the University of California Irvine. There also has been a company formed around this technology called Robomedica, and they're raising funds to start the development of this technology.


#### **NTB: When will it be available for clinical trials or actual use?**

**Dr. Weiss:** I hope it will be available in three years; it depends on our ability to raise funds. Robomedica had their first round of funding and they've raised enough to get started. So, I think it's going to be 18 months to two years to get a product ready for testing.

A full transcript of this interview appears on-line at [www.nasatech.com/whoswho](http://www.nasatech.com/whoswho). Dr. Weiss can be reached at [james.r.weiss@jpl.nasa.gov](mailto:james.r.weiss@jpl.nasa.gov).



# What do you need to record? Waveforms – Video – Audio... **Dash 18<sup>®</sup>** **handles** **it all!**




- Record waveform data, synchronized video snapshots and audio
- 18 Universal input channels for voltage, thermocouple and bridge
- 15.4" touch-screen display for data viewing and analysis
- Record data directly to 9 GB hard drive at 100 kHz per channel
- Real-time filtering and math functions
- 10/100 BaseT Ethernet interface and 250 MB Zip drive



## Optional Printer

For real-time recording or playback from memory, an attachable 10" wide high speed printer is available.



Call, E-mail, Fax, or write to us today for all the details.

Web Site: [www.astro-med.com/de13](http://www.astro-med.com/de13)



**Astro-Med, Inc.**  
TEST & MEASUREMENT PRODUCT GROUP

**Astro-Med is System Certified to ISO-9001**

Astro-Med Industrial Park, West Warwick, Rhode Island 02893  
Phone: (401) 828-4000 • Toll Free: 1-877-867-9783 • Fax: (401) 822-2430  
In Canada Telephone 1-800-565-2216 • E-mail: [mtgroup@astromed.com](mailto:mtgroup@astromed.com)



# World's Fastest CompactPCI Digitizers

## CompactPCI Digitizers



### Product of the Month

## CompuScope 85GC

5 GS/s, 8 Bit  
CompactPCI Digitizer



- 5 GS/s A/D Sampling on two Simultaneous Channels
- 500 MHz Bandwidth
- 8 Bit Resolution
- 100 Hz Repetitive Acquisition Rate
- Based on Advanced Tektronix Technology
- TV Triggering Capability
- CompactPCI Form Factor
- Software Development Kits for C/C++, MATLAB and LabVIEW

# GAGE

A Tektronix Technology Company

**1-800-567-GAGE** ext:3405  
www.gage-applied.com/ad/nasa302.htm

Outside the U.S. contact: Gage Applied, Inc.  
Tel: +1-514-633-7447 Fax: +1-514-633-0770  
e-mail: prodinfo@gage-applied.com

For Free Info Circle No. 403 or  
Enter No. 403 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



*Over the past three decades, NASA has granted more than 1000 patent licenses in virtually every area of technology. The agency has a portfolio of 3000 patents and pending applications available now for license by businesses and individuals, including these recently patented inventions:*

## Compact Dexterous Robotic Hand

(U.S. Patent No. 6,244,644)

Christopher Scott Lovchik and  
Myron A. Diftler, Johnson  
Space Center.

The present invention is intended to give a robotic hand the anatomical movement of the human hand yet to make it lightweight, mobile, and capable of grasping both heavy and light objects with precision. The robotic hand includes highly reliable yet simple components that enable the desired movements of a plurality of flexible fingers attached to a palm housing, a thumb, and a wrist member. Force is mechanically transmitted from drive components in a forearm portion through the wrist section to operate fingers and thumb. The dexterous robotic hand described herein generally consists of, in addition to a palm housing, fingers, and a thumb, a forearm section that houses the drive motors and electronics that enable the controlled movement of the fingers and the thumb. The device includes a two-degree-of-freedom wrist section and a twelve-degree-of-freedom hand.

## Piezoelectric Vibrational and Acoustic Alert for a Personal Communications Device

(U.S. Patent No. 6,259,188)

Inventors: Stanley E. Woodard,  
Richard F. Heilbaum, Robert H.  
Daugherty, Raymond C. Scholz,  
Bruce D. Little, Robert L. Fox, Gerald  
A. Denhart, SeGon Jang, and Rizza  
Balcein, Langley Research Center.

A team at Langley Research Center identified a need for a combination vibrating and acoustical alarm mechanism that has a relatively uncomplicated design, is relatively inexpensive to produce, that is substantially durable, and is lightweight and small enough to be incorporated into a handheld communication device (PCD). It should provide an alert apparatus that includes a mechanically prestressed piezoelectric wafer inside the

PCD and an alternating voltage input line coupled at two points on the wafer where polarity is recognized. The apparatus would also have a variable frequency device coupled to the voltage input line so that the alternating voltage on the input line would have a first frequency and a second frequency. The first would preferably be high enough to cause the wafer to vibrate at a resulting frequency that produces a sound perceptible by the human ear, and the second would preferably be sufficiently low to cause the wafer to vibrate at a frequency that would produce a vibration readily felt by the holder of the PCD.

## Stable Algorithm for Estimating Airdata from Flush Surface Pressure Measurements

(U.S. Patent No. 6,253,166)

Inventors: Stephen A. Whitmore,  
Brent R. Cobleigh, and Edward A.  
Haering Jr., Dryden Flight Research  
Center.

Airdata are those parameters, characteristics, properties, and quantities derived from the air surrounding a flight vehicle. Accurate airdata are absolutely necessary for many purposes and applications, and help to ensure efficient and safe flights. But systems developed to date have proven highly inaccurate. There are several problems with existing algorithms. One is that the nonlinear regression method used in the estimation algorithm tends to be highly unstable. This unstable algorithm leads to the problem of complexity. The present invention is embodied in an airdata estimation and evaluation system and method for estimating and evaluating airdata from nonintrusive surface pressure measurements. It includes a triples formulation module for eliminating the pressure-related states from the flow model equation, an angle of attack module for computing that angle, an angle of sideslip module for computing that angle, and an airdata module for estimating and evaluating other airdata.

*For more information on the inventions described here, contact the appropriate NASA Field Center's Commercial Technology Office. See page 12 for a list of office contacts.*



Visit us at  
NDES, Booth 7505

©2002 EDS. EDS and Solid Edge are registered marks and EDS & Design & Design are trademarks of Electronic Data Systems Corporation or its subsidiaries.



### With Solid Edge, you design with insight.

- Just think what Edison could have done with Solid Edge® Insight. Intuitive, powerful design tools with built-in knowledge sharing, right out of the box. Solid Edge's visionary technology adds engineering data extensions to Microsoft® document management to ensure first-time fit, cut costs and reduce time-to-market. Solid Edge offers specialized toolsets for your industry. And it's backed by EDS for support and stability. So get the edge. You'll electrify your competition. Visit [www.solidedge.com](http://www.solidedge.com) or call 877-342-5847.






## Simulation Software Helps Evaluate Mission Converter

**Maxwell 3D Field Simulator software**  
**Ansoft Corp.**  
**Pittsburgh, PA**  
**412-261-3200**  
**[www.ansoft.com](http://www.ansoft.com)**

A free-piston Stirling converter is being developed by the Department of Energy, NASA's Glenn Research Center in Cleveland, OH, and Stirling Technology of Kennewick, WA.



Dual-opposed Stirling converter during test at NASA Glenn.

The converter will be utilized on the Stirling Radioisotope Generator (SRG), which is being constructed to provide electric power for unmanned Mars rovers and potential NASA deep space missions of long duration. To evaluate various 3D geometries, materials, and excitation levels on the converter, NASA engineer Steven M. Geng used Maxwell 3D Field Simulator to perform electromagnetic modeling.

"Glenn researchers are conducting a variety of in-house tasks to provide data in developing the Stirling converter for readiness for space qualification and mission implementation. Our work helps determine if a design will perform and function properly with the capability of surviving in a deep space or Mars surface environment," said Geng.

The converter is also being designed to survive a high-radiation environment such as a potential mission to Europa, one of Jupiter's moons. So far, the converter has passed launch environment random vibration testing at workmanship, flight acceptance, and qualification test levels while operating at full stroke and full power.

Geng said that the Maxwell software helped him and his colleagues investigate new methodologies to both improve designs and analyze existing designs. NASA is evaluating the magnets used in the converter's linear alternator. "Using Maxwell, we studied the magnets and the alternator to estimate the magnet's margin to demagnetization," said Geng.

**For Free Info Circle No. 725 or**  
**Enter No. 725 at [www.nasatech.com/rs](http://www.nasatech.com/rs)**

## 3D Measuring System Helps Build Rocket Bodies

**Forged steel solid rocket motor cases**  
**Ladish Co.**  
**Cudahy, WI**  
**414-747-2611**  
**[www.ladishco.com](http://www.ladishco.com)**

The two solid-rocket bodies of the Space Shuttle are able to resist loads of launch because they are forged from D-6 tool steel, and are nearly indestructible. Ladish forges all of the cylinders and domes that form the solid rocket motor cases. To assess the exact shape of each forging prior to machining, technicians previously measured each newly forged dome with a portage CMM to guide them in setting up the piece to be machined. This technique usually took two weeks to finish, and the 2D image generated was not always complete.

To generate a more detailed digital image of the rough-forged dome, Ladish engineers began using a FaroArm, a portable, 3D measuring system from Faro Technologies. The arm is an articulating instrument that employs optical encoders at the joints to provide X-Y-Z position and I-J-K orientation data to a computer. Dimensional tolerances are as close as  $\pm 0.001$ ", and it can measure any point within its spherical reach.

Ladish uses the arm for conventional dimensional checking by gathering a "digital cloud" of data consisting of up to 200,000 streaming points on each piece. After the data is collected in the



arm's companion software, an accurate 3D reproduction of the dome is created. According to Ed Pastorek, Ladish's supervisor of product assurance, quality, and technology, the technique provides near-perfect parts. "This has given us a 'no-mistake' way to align and machine these parts," said Pastorek. "Now we know exactly what metal we have to take off."

**For Free Info Circle No. 726 or**  
**Enter No. 726 at [www.nasatech.com/rs](http://www.nasatech.com/rs)**





# No Matter What You Test, Do It With Dewetron!



Above left to right – the DEWE-4000, DEWE-2010, and DEWE-3010 portable PC Instruments

Our customers are testing everything from train cars to the Space Shuttle, from automobile airbags to oilwells...and the list keeps growing. Why? Maybe it's our plug-in signal conditioners that allow connection of *any signal, any sensor*. Or perhaps it's the fact that Dewetron systems are built on an open-architecture, COTS\* computer platform, allowing easy upgrades and compatibility with all Windows® software and hardware.

Or it could be our software—so easy to use and yet so powerful—with brilliant on-line displays, full-color printing and one-click export to Excel®, MatLab®, ASCII, and several other popular formats. Of course, Dewetron machines are perfect platforms for LabVIEW® development, and they already include a National Instruments® A/D card connected to our high-isolation plug-in signal conditioners!

Our basic models are also highly popular as portable industrial computers built to MIL-STD-810C for shock and vibration.

It could be any of these things - or maybe it's all of them. The bottom line is, if you're doing data acquisition any other way, you're missing a lot. Please take a look at Dewetron today. Start with our website, or give us a call and arrange a no-obligation demonstration at your facility.

Contact us today toll-free at **877-431-5166** (+1 401-364-9464 outside the USA), or visit us on-line at **[www.dewamerica.com/ntb](http://www.dewamerica.com/ntb)**




Plug-in signal conditioners for every signal, every sensor

Just need a front-end? Check out our DEWE-RACK and DEWE-BOOK solutions for your notebook computer!



\*COTS = Commercial, off-the-shelf.  
All trademarks acknowledged as the property of their owners.





# A Changing Climate for CAD

**W**hen we last visited the state of the CAD industry in March of 2001, the industry leaders we interviewed focused on the Internet, ease of use, and consolidation of CAD vendors. For this year's look at CAD, our experts were outspoken on ease of use, 2D to 3D migration, and how the changing economic climate has affected the CAD software market.

As a general rule, most of the vendors we interviewed are not changing their marketing strategy for new customers as a result of the economic downturn. If anything, many vendors are focusing more on their current customers than targeting new ones.

"We're marketing to the people who are already our customers," said John McEleney, CEO of SolidWorks. "As the economy gets a little more challenging, and some of our competitors try to drive their price down in the market, the one good thing about having a large installed base is that you're going back to people you already have a relationship with, so your cost of sales should be lower," he explained.

"Our initial installed base provides a very rich, fertile ground for continued building of those relationships and a nice business. There is a lot of opportunity for new business," said Brian Shep-

herd, senior vice president of MCAD technical marketing for PTC. "A lot of companies feel they need to be ready when the economy turns with a stable full of great products. The way they cut costs in the short term to weather the storm usually starts in their manufacturing organization where they ramp down production. They're trying to minimize physical inventory, but they're still very focused on creating intellectual inventory," Shepherd added.

Some vendors such as VX Corporation, a CAD/CAM supplier, are actually increasing their marketing efforts. "It's a real opportunity at this point," said Bob Fischer, vice president of sales and marketing for VX. "Companies have to do as much as before but with fewer people. We've changed the amount of face time, doing things like Web seminars. We need to go to the people — they won't come to us."

While much attention has centered around the economy since September 11, there were signs of a downturn at least six months before that, according to David Primrose, MCAD product marketing director for EDS PLM Solutions. "The economy took a knock, but life goes on, and people are purchasing products that have to be manufactured. In economic times like these, companies turn to tools that will increase their

productivity and help recover costs as a way of solving the problem. Those companies that are far-sighted will look upon a CAD investment as one that will give them a very high return, rather than a cost they can't afford," Primrose explained.

## The Cost of CAD

The type of CAD system a company can afford is more important now than it was in the past. Cost-cutting and budget-watching have taken a front seat to flashy features. According to Robert Kross, vice president of Autodesk's Manufacturing Division, "Companies look at a lower-cost solution in economies like this. There has been much more awareness of the engineers who hold the intellectual property of the company in their heads. Everyone believes that this year, we're going to see the economy blossom again. Companies are using the downtime to train more."


Companies with low-cost CAD products are finding it much easier to sell their software. Bob Mayer, executive vice president of sales and marketing for IMSI — which offers its TurboCAD V8 Professional program for just under \$500 — believes that customers are getting the message that you don't have to spend a lot of money to get professional

*(Continued on pg. 27)*



# FEMLAB<sup>®</sup>

## — multiphysics in MATLAB<sup>®</sup>



FEMLAB<sup>®</sup> supplies highly sought-after new technology for the modeling and simulation of physics in all science and engineering fields. Its main attribute is the ease with which modeling can be performed and its unlimited multiphysics capabilities, in 1D, 2D and 3D — the perfect way to apply state-of-the-art numerical analysis to your expertise in modeling.


**Order your free literature kit!**



Visit [www.comsol.com/ient](http://www.comsol.com/ient) or  
call +1-781-273-3322







- ▶ The most common reactor for environmental protection, which we encounter or use everyday, is the catalytic converter in automobiles. In these monolithic catalysts, carbon monoxide and nitrous oxides are converted into relatively harmless species like carbon dioxide and nitrogen. To optimize the utilization of the expensive catalyst, it is important to be able to model the reactor at different operational conditions. In this FEMLAB model, mass and heat balances are coupled to compute temperature distribution and flowlines in the reactor.
- ▶ This square-shaped spiral inductor is used for bandpass filters in micro electro-mechanical systems (MEMS). The FEMLAB simulation takes the nonuniform current density in the coils into account to compute an accurate magnetic flux around the coils. The inductance of this inductor is 2.1 nH, which is obtained by integrating the magnetic energy. Using the programming language of FEMLAB for parametric analysis, you can find the correlation between the induction and the input parameters of the model.
- ▶ In the design of electrodes for water electrolysis, it is important to minimize the voltage losses at a given total current. FEMLAB modeling helps the engineer in the design of the electrode geometry and the current collector. The model gives the current density distribution and the potential distribution in the system. These results make it possible to avoid excessive degradation of the active electrode surface and overheating of the welds at the position of the current collector.
- ▶ When designing an electric motor it is important to design the rotor shaft so that no eigenfrequencies exist in the working range of the rotational speed. It is also important to study the shape of the eigenmode and not just the eigenfrequencies. In the eigenfrequency analysis, one end of the shaft is fixed and the other end is free to rotate and axially deform. The image shows deformation and rotation angle in the second eigenmode, using different visualization options like colormaps and scaling.

FEMLAB is a registered trademark of COMSOL AB.

## FEMLAB KEY FEATURES

- Flexible and powerful graphical user interface
- Built-in user-friendly CAD tool for solid modeling in 1D, 2D and 3D
- Automatic mesh generation, adaptive mesh and multigrid
- Powerful solvers for linear, nonlinear and time-dependent systems of partial differential equations (PDEs)
- Extensive postprocessing capabilities
- Model Libraries with over fifty models fully documented from various engineering fields
- Ready-to-use application modes for different engineering fields
- Equation-based modeling for arbitrary systems of PDEs

## FEMLAB PUTS YOU IN THE FRONTLINE

FEMLAB employs sophisticated numerical techniques developed by our staff of leading scientists in collaboration with industry experts from around the world. These professionals had a goal of making modeling available to every engineer and scientist. FEMLAB is the result of our commitment to putting engineering mathematics in a box.

## Order your free literature kit!



Visit [www.comsol.com/ient](http://www.comsol.com/ient) or call +1-781-273-3322



COMSOL

[www.comsol.com](http://www.comsol.com)




functionality. "In the past, we had only one product that sold for \$99, and the perception was that a \$99 product couldn't have much functionality. Over time, we've raised the retail price by about \$200 on that product, and most importantly, we put in the CAD functionality that CAD professionals expect," Mayer said.

Relatively new companies with new products face the challenge of competing both in pricing and in functionality with established "legacy" systems. "The economy, as far as who we're marketing to, hasn't changed," said Shaun Murphy, vice president of marketing for IronCAD. "There has to be a higher level of confidence before people will take their wallets out of their pockets. Since we're a new company and we just introduced our Innovation-Suite last October, we didn't need to make any adjustments. We brought it out value-priced and packaged for the price-conscious. Right from the beginning, we targeted our packaging, our products, and our pricing to the small- to medium-sized business," Murphy explained.

For the leading mid-range and high-end CAD vendors, it's more a question of whether customers can afford not to invest, according to Geoff Rogers, marketing manager of the Americas for IBM. "You have to look at the entire cost of what you're implementing. Look at the entire cost of what it's going to take to implement that solution, and then look at the benefits you'll receive therein. In this economic environment," Rogers said, "I think the question is not 'how can I afford to invest in product lifecycle management,' but, 'how can I afford *not* to invest in a product lifecycle management solution?'"

McEleney believes that when saving costs, companies need to look at how much they already have invested in a CAD system, and what they need to do with it. "In the large-scale enterprises," McEleney said, "they're not going to switch to a lower-cost alternative, because CAD costs are a small fraction of what the overall costs are."

PTC now offers the lowest-cost alternative — free downloadable software. Last month, the company introduced Pro/DESKTOP Express, a parametric, associative solid modeling program built on the same kernel as Pro/ENGINEER. According to Shepherd, the reasons for offering the free software were simple. "If you're a Pro/ENGINEER



LEWA Herbert Ott GmbH in Leonberg, Germany, used Solid Edge (an EDS PLM Solutions product) to design this pump and piping assembly.

customer today, but you want to do business with a supplier who doesn't use Pro/E, that customer had a few-thousand-dollar barrier to get over to buy Pro/E. What if the person who doesn't use Pro/E could download an application for free from PTC.com that read in the Pro/E data because it's based on the same kernel?" The value proposition PTC is offering, said Shepherd, is that Pro/DESKTOP Express is a full-featured CAD system. "It's part of our game-changing strategy," he added. "In our industry, we're looking to turn things upside down."

### The Migration Continues

One of the issues facing CAD companies today also was a primary focus a year ago. Will 2D to 3D migration continue, and does widespread adoption of 3D CAD tools need to happen? This issue divided our experts more than any other aspect of the CAD market.

"In today's world, everybody already has a system. No one is starting with a drafting board and pencil anymore," said Kross. "We have a very large focus on 3D with Autodesk Inventor. Our objective is to shift our entire installed base to 3D." To that end, Autodesk has announced the Autodesk Inventor Series, which incorporates both 2D and 3D products — Autodesk Mechanical Desktop 6, based on AutoCAD, and Autodesk Inventor 5.3 3D design software. The new combined product allows users of AutoCAD, AutoCAD Mechanical, and Autodesk Me-


chanical Desktop to keep using their products while they get started with 3D by using Autodesk Inventor.

"Our customers get the advantage of keeping what they're using today, plus the new capability of a much easier to use product. Some customers will go gradually from 2D to 3D, but I hope we make it so easy for them, that they just say, 'I'm going to do this,'" said Kross.

"We see companies moving from 2D to 3D every day," said Rogers. "When you move to a 3D environment, you can immediately do things in maybe

one step that used to take you five in a 2D environment, so you see immediate benefits." IBM offers the CATIA Companion, which allows companies to move into 3D without being intimidated. Rogers explained that CATIA Companion sits on the same workstation as CATIA. "When there is a specific topic on which you have a question when working in CATIA, you can enter into the Companion product, and it steps you through what you're trying to do in 3D."

According to Fischer, VX chose not to support either 2D or 3D, but to offer both. "In some circumstances, creating a quick drawing in 2D is sufficient. You can either work in the world of 3D or do it quick and dirty and get it done



Pac West Racing used Autodesk software to design this chassis.

without style," he added. "Many 2D users don't ever have to use 3D. But if it needs to be part of an assembly, that must be created in 3D and exist as a digital model."

Primrose agrees that 2D will never entirely go away, but he sees 3D as the best choice. "There will always be people who refuse to move from 2D. They



**Fast.  
Reliable.  
Safe.  
Everything  
automated  
riveting  
should be.**



**Introducing POPmatic Point & Set™, the first reliable auto-feed rivet system.**

POPmatic Point & Set, our new auto-feed rivet system, delivers what no riveting tool has before. Consistent riveting at a rate faster than any current hand tool. Designed with a safe, self loading hopper that holds up to 2500 rivets, Point & Set accelerates the riveting process to previously impossible speeds, meeting the requirements of any production line. It's reliability in an otherwise unreliable world. For more information, call us at 203-925-4424 or visit us on the web at [www.emhart.com](http://www.emhart.com)

**Emhart®  
POPMATIC**

A BLACK & DECKER COMPANY

CERTIFIED  
ISO 9001 • QS 9000

might be able to make a drawing on the paper, but they get no benefit out of having a simple paper drawing. When it comes to changing designs, there is tremendous opportunity for errors if you don't have 3D."

Primrose also sees ease of use as a barrier to 3D that still exists. "Going forward, if you ask people what the most important attributes of a CAD system are, I don't think we — ourselves or our competitors — have come up with a radical change in usability. While we have lots of people talking about clever, cool features, the next thing is to come up with a whole new paradigm that will make CAD systems a whole generation easier to use."

Until that happens, 3D won't be the dominant technology, according to IronCAD's Murphy. "It's still probably a 2D design world," he predicted. "Do I believe 95 percent of people will be using 3D in the near future? No, I don't. It doesn't always make sense to use 3D," he added. "Many 2D users will tell you that the value they would get from moving to 3D is not worth the pain. You have a toolbox, and you pull out the right tool for the job. You wouldn't say, 'In the future, all repairs will be done with a hammer.' Design also has a bit of that, even though you don't have as many tools. There are certain tools you use because they are the best for the job. You have to make the call," Murphy said.

IBM, Autodesk, and SolidWorks have products designed specifically to help users move "painlessly" to 3D, which they feel will be the majority of the CAD world very soon. "I think 98 to 100 percent of people will use 3D tools. I think it needs to happen," said Kross. "If you



Solo Golf used IBM's Product Lifecycle Management (PLM) solutions to design its new putter.

make machines and you use 2D, and you're trying to compete with the machine maker down the street who's using 3D, you can't compete. He'll make a better machine he can understand better, and even more importantly, he can use his design data and product data in different ways — in his brochures, on his Web site."

SolidWorks' McEleney agrees, but adds that the migration will happen more quickly than most think. "The fact is it won't happen this year, but it won't take ten years — I can tell you that. The world will move to 3D for a number of reasons, and the drivers behind it are simple," he said. "The average workforce is getting older, and as the older workers retire, today's graduates are the ones who grew up playing video games. They learned and work in a world based on 3D. As the older generation with a 2D legacy retire, the resistance level to 3D will come down."

Is a completely 3D world a better one? McEleney has mixed feelings about that. "The scary thing is as we adopt these 3D tools, are we going to lose any of the elegance and simplicity of engineering? As a vendor, I'm hard-pressed to fight that, because I think it's true. But it's a change for the better," he said. "If you look at the products manufactured today, they're all better because of 3D design tools."

**Get Connected to the Companies Featured in this Article:**

Autodesk .....	<a href="http://www.autodesk.com">www.autodesk.com</a>
EDS PLM Solutions .....	<a href="http://www.eds.com/products/plm">www.eds.com/products/plm</a>
IBM .....	<a href="http://www.ibm.com/catia">www.ibm.com/catia</a>
IMSI .....	<a href="http://www.turbocad.com">www.turbocad.com</a>
IronCAD .....	<a href="http://www.ironcad.com">www.ironcad.com</a>
PTC .....	<a href="http://www.ptc.com">www.ptc.com</a>
SolidWorks .....	<a href="http://www.solidworks.com">www.solidworks.com</a>
VX Corporation .....	<a href="http://www.vx.com">www.vx.com</a>






IF YOU CAN THINK IT, WE CAN DO IT.

Emhart is a world leader in the design and supply of innovative fastening and assembly technology. From concept through installation, whether you're manufacturing around the corner or around the globe, Emhart provides cost-effective solutions for assembly applications. Visit us at [www.emhart.com](http://www.emhart.com)

**Emhart**<sup>®</sup>

A  BLACK & DECKER COMPANY



# Technologies of the Month

Sponsored by **yet2.com**

For more information on these and other new, licensable inventions,  
visit [www.nasatech.com/techsearch](http://www.nasatech.com/techsearch)

## Afterburning Ericsson Cycle Engine Is Low-Cost Fuel Cell Alternative

*Proe Power Systems*

Ericsson Cycle hot air engines produce power by externally heating one cylinder and cooling another. As the heated engine cylinder grows hotter, it requires more energy, which is wasted in the burner exhaust, reducing the overall engine-burner efficiency. Proe Power Systems' Afterburning Ericsson Cycle (AEC) engine recovers over 90% of the exhaust heat for higher thermodynamic efficiency, and has virtually no burner efficiency loss because there is no external burner. The AEC engine provides continuous combustion, obtaining the full heating value of any available fuel, including gasoline, methane, and propane.

The AEC engine is suitable for combined heat and power (CHP) and distributed power generation applications. It also can be used as a heat engine in hybrid vehicles, as a clean replacement for marine diesel engines, and as an auxiliary power source for the trucking industry to reduce noise and pollution from idling trucks.

Get the complete report on this technology at:  
[www.nasatech.com/techsearch/tow/proe.html](http://www.nasatech.com/techsearch/tow/proe.html)  
e-mail: [nasatech@yet2.com](mailto:nasatech@yet2.com); phone: 617-557-3837

## Aluminothermic Process Reduces Cost, Improves Yield for Chromium Metal Manufacturing

*Devdutt Mohanty*

Chromium is used extensively in the alloying of nonferrous metals like copper and aluminum. By itself, chromium is brittle, but when alloyed with other metals, a wide range of durable alloys can be produced. Using traditional methods

such as the electrolytic process, chromium metals are expensive to produce. A new chromium manufacturing technology uses a proprietary process in which sodium dichromate is treated with acid and heated until sodium sulfate and chromic acid are separated. The chromic acid lumps that are left are finely ground, mixed with carbon

black, fired, and converted to chromic oxide. This chromic oxide is passed through a process to produce 98% to 99% pure chromic oxide. This aluminothermic process does not use electricity for extraction, thus reducing production costs.

Get the complete report on this technology at:  
[www.nasatech.com/techsearch/tow/mohanty.html](http://www.nasatech.com/techsearch/tow/mohanty.html)  
e-mail: [nasatech@yet2.com](mailto:nasatech@yet2.com); phone: 617-557-3837



## Biodegradable Plastic from Renewable Resources

*Dr. Johan-Fredrik Selin, Development Manager, New Technology Business, Fortum*

Conventional plastics are made from petrochemicals, which pose environmental disposal problems. A new biodegradable plastic is created using polylactides, an organic product formed by the fermentation of carbohydrates, which



produces lactic acid. The lactic acid is transformed into a polymer, which breaks down into environmentally safe elements that are then completely metabolized by normal soil microflora in a short period of time. Once exposed to light, humidity,

oxygen, and soil microorganisms, polylactide plastics convert into humus, carbon dioxide, and water.

Manufacturers can use the same machinery currently used for traditional plastics to convert to the new polylactide plastic, and can use less energy compared to traditional hydrocarbon plastics.

Get the complete report on this technology at:  
[www.nasatech.com/techsearch/tow/fortum.html](http://www.nasatech.com/techsearch/tow/fortum.html)  
e-mail: [nasatech@yet2.com](mailto:nasatech@yet2.com); phone: 617-557-3837

## Hydrogen-Driven Actuators

*Sachiko Matsuyama, Sensor Control Group, Ltd.*

Actuators have a wide variety of applications including robotics, simulators, positioning systems, and opening devices. A new actuator absorbs and desorbs 1,000 times its own volume in hydrogen, creating gas pressure to drive the actuator. This actuator employs metal bellows lined with a metal-hydrogen (MH) alloy ranging in thickness from 3 to 10 mm. The alloy is then heated, causing it to release hydrogen, increasing gas pressure and extending the bellows. When the alloy is allowed to cool, hydrogen is absorbed, decreasing gas pressure and causing the bellows to contract.

A flexible polymer film that is currently being designed into an MH actuator for robotic applications might also be used to create artificial muscles for humans. Other applications include stabilizing earthquake-damaged structures, and as a lifter to move people and equipment in multi-story buildings.

Get the complete report on this technology at:  
[www.nasatech.com/techsearch/tow/sensor.html](http://www.nasatech.com/techsearch/tow/sensor.html)  
e-mail: [nasatech@yet2.com](mailto:nasatech@yet2.com); phone: 617-557-383



**NEW**  
TEST AND  
MEASUREMENT  
TOOLS

# Get to analysis faster. Take live measurements in MATLAB.

New test and measurement tools for MATLAB combine data acquisition, instrument



*New test and measurement tools allow you to communicate with data acquisition devices and instruments directly from MATLAB.*

control, and data analysis in a single, interactive environment. Now you can acquire live data from popular data acquisition devices and control your test

equipment directly from MATLAB. Use proven tools for signal processing, statistical analysis, graphics, and reporting to analyze your data as it streams into MATLAB.

**Get your free 30-day trial today.**


Call 508-647-7040 to request your trial. Or get a free technical information kit at [www.mathworks.com/nttm](http://www.mathworks.com/nttm).

**MATLAB®  
& SIMULINK®**

Data Acquisition  
Instrument Control  
Signal Processing  
Statistics  
Training  
Consulting

MATLAB  
training  
offered in  
15 locations.

*These new MATLAB tools provide a complete solution for test, measurement, analysis, graphics, and reporting.*



Visit [www.mathworks.com/nttm](http://www.mathworks.com/nttm)  
or call 508-647-7040

© 2001 The MathWorks, Inc.





### Parallel-Processing High-Rate Digital Demodulator ASIC

CMOS circuitry can be used instead of more expensive analog circuitry or GaAs-based kind.

NASA's Jet Propulsion Laboratory, Pasadena, California

An all-digital demodulator has been developed for receiving radio signals with multigigahertz carrier frequencies phase-modulated with digital data signals at bit rates of hundreds of millions of bits per second. The phase modulation could be either binary phase-shift keying (BPSK) or quadrature phase-shift keying (QPSK), including QPSK employing bandwidth efficient pulse-shaping methods. The demodulator has been implemented in complementary metal oxide semiconductor (CMOS) application-specific integrated circuit (ASIC) configured to utilize algorithms that process signal data in multiple parallel streams.

The advantages of all-digital processing over traditional analog processing include greatly increased flexibility and reliability with reduced reproduction costs. Serial digital signal processing would entail processing rates so high as to necessitate the use of non-CMOS (e.g., GaAs-based) circuitry, which costs more and is more power-hungry, relative to CMOS. What makes it possible to implement the present ASIC in CMOS is the parallel-processing scheme, in which the number of parallel data streams is made large enough that the data rate in each stream is low enough to be within the capability of CMOS circuitry.

The present all-digital demodulator is characterized by an advanced parallel receiver (APRX) architecture (see figure), which replaces the receiver functions of the parallel receiver (PRX) architecture reported in "Parallel Digital Demodulators Using Multirate Filter Banks" (NPO-19620), NASA Tech Briefs, Vol. 20, No. 10 (October 1996), page 65. The APRX architecture is essentially one of time-varying frequency-domain detection filtering and symbol-timing correction.

Upstream of this demodulator, the received analog signal is converted to an intermediate frequency (IF) suitable for analog-to-digital (A/D) conversion, band-pass filtered, then digitized at a rate of 4 samples per symbol. The band-pass filtering rejects some noise and prevents the aliasing that would otherwise occur after A/D conversion. The digital signal is split into 32 parallel paths, decimated


by 16 on each path, and digitally mixed on each path with a replica of the sampled IF carrier signal. The discrete Fourier transform (DFT) of the resulting 32 data points is then taken, via a specialized fast Fourier transform (SFFT), and multiplied by the one element of a bank of frequency-domain-matched filters. The correct matched filter is chosen by the closed-loop symbol timing recovery algorithm (see figure).

To suppress the double-frequency terms generated in mixing to baseband, low-pass filtering is performed, zeroing out the middle 16 components (which correspond to the high-frequency terms) in the frequency domain. Then the inverse discrete Fourier transform (IDFT) is computed, via the specialized inverse fast Fourier transform (SIFFT), and the

middle 16 parallel outputs (which are unaliased and correspond to 4 symbol periods) are used for detection, tracking, and other purposes.

The foregoing process is repeated once every 16 cycles of the A/D-converter clock. The 16 points in the SIFFT output are 16 samples of a convolution of the input sequence with the matched-filter impulse-response function. Among these 16 samples are 4 baseband symbols that correspond to the peak signal-to-noise-ratio outputs of the matched filter.

Theoretical analysis, computational simulations, laboratory tests, and live satellite downlinks have shown that the error-rate performance of the APRX demodulator can be expected to be equivalent, and in some cases superior, to that of a conventional serial-processing digi-



The APRX Architecture provides for most digital signal processing to be done in the frequency domain. Here, "z<sup>-1</sup>" denotes a digital sample delay, "↓16" signifies decimation by a factor of 16, and H<sub>i</sub> denotes a complex time-varying matched/detection filter bank that also performs the functions of low-pass digital filter and symbol timing recovery.



tal receiver. In comparison with the PRX architecture, the APRX architecture can be implemented with significantly reduced complexity. In comparison with traditional serial digital receivers, the APRX demodulator ASIC can process much higher data rates. The next gener-

ation implementation of the APRX ASIC is currently being developed to process higher order modulations and data rates in excess of 2 billion bits per second.

*This work was done by Parminder Ghuman, Scott Hoy, and Gerald Grebowsky of Goddard Space Flight Center and Andrew*

*Gray and Meera Srinivasan of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Electronic Components and Systems category. NPO-21230*

## Reusable Software for Autonomous Diagnosis of Complex Systems

**Software incorporates advances in several data analysis disciplines to enable autonomous self-monitoring.**

*NASA's Jet Propulsion Laboratory, Pasadena, California*

A software system designed to provide a purely signal-based diagnosis of virtually any time-varying system has been developed. This software is part of an overall concept called "Beacon-based Exception Analysis for Multimissions," or BEAM. This concept provides for real-time autonomous diagnostics and prognostics of virtually any complex system (e.g., intelligent spacecraft or advanced aircraft) by use of software executed on an embedded computer.

BEAM provides for the onboard identification and isolation of anomalous conditions, making it unnecessary to telemeter large quantities of raw data for analysis on the ground. BEAM thereby reduces operator or pilot workload by isolating all anomalies that could affect safety, navigation, or performance. BEAM was conceived as an incrementable autonomy technology, capable of operating with no human intervention but also supplying condensed infor-

mation to aid human operating decisions. Thus, the system is useful at both extremes, viz, total autonomy and complete operator control, and at every level in between.

This particular component of BEAM, called the System Invariant Estimator (SIE), uses strictly signal-processing methods and is therefore highly reusable. Many approaches to the problem of self-diagnosis exist, such as model-based and neural network solu-



5800 Series



Microtorsion 55MT



S1 Durometer



Dynatup 9250

## When it comes to material testing, these are the standards.

### Demanding Test Applications - 5800 Series

- The most accurate force measurement specifications, cutting edge control and data acquisition electronics.
- Demanding test applications involving biomaterials, metals microelectronics, plastics and components and composites.

### Torsional Testing - MT55

- Simulates a variety of real world applications where torsional stresses are prevalent. Adjustable crosshead allows for easy specimen loading.
- Torsion testing for materials and parts that withstand constant twisting and wrenching such as fasteners, wire, electronic assemblies, medical devices and biomaterials.

### Shore Portable Digital Durometer - S1

- Highly accurate force and displacement measuring system assures consistent results with unmatched flexibility, accuracy and repeatability.
- Precision rubber testing using state of the art technology in an all new digital durometer.

### Instrumented Impact - Dynatup 9250

- Capture, plot and analyze an entire impact event to determine key data such as: ductility and incipient damage.
- Test impact properties of polymers, metals, composites, and full components. Ideal for automotive, aerospace, biomedical and packaging industries.

### Contact Information

United States: +1 800 564 8378  
Canada: +1 905 333 9123  
Europe: +44 1494 456815  
Email: [marcom@instron.com](mailto:marcom@instron.com)

The difference is measurable



**INSTRON**  
[www.instron.com](http://www.instron.com)



tions. However, in many cases these approaches require significant investment in modeling and training, perform poorly beyond the model or training envelopes, and perform poorly in the presence of data uncertainty. Because of BEAM's underlying architectural differences from these approaches, a priori modeling is useful but not necessary, the training process is relatively simple and is incrementable, and the system is capable of correctly isolating anomalies well outside the training envelope.

The SIE provides a standard method for real-time fusion and analysis of all

time-varying system observables, including sensor data as well as derived quantities and certain quantifiable software indications. These data sources can be from similar sensors or from radically varying types. The intermediate information products of the SIE retain considerable physical meaning, which allows complete traceability of the diagnostic state and reconstruction of the BEAM conclusions. The SIE provides detection capability, in both space (signal localization) and time, for both sudden and gradual changes in any system. The approach is readily scalable to

systems of higher complexity and is resistant to the usual problem of combinatoric explosion as system size increases.

The SIE functions by considering the cobehavior of time-varying quantities, in particular their dynamics, as sensed from an operating system. Suitable sensors are widely used and typically include so-called performance sensors, i.e., temperatures, pressures, and the like. Certain repeatable relationships between physical quantities, and, hence, sensor values, exist in the system as dictated by the physics of its operation. These relationships are repeatable and relatively insensitive to changes in the environment or normal fluctuations.

The SIE constructs a single quantitative object to capture this cobehavior across the entire system or subsystem. This object reflects both known relationships, such as voltage/current relationships that are easily modeled, and unknown relationships, such as thermal transmission through system structure that is not well understood. The object is studied with respect to stability, for the purpose of detecting instantaneous changes or mode switches, and its long-term convergence, which reveals the presence of incipient faults, degradations, or minor and local shifts away from desired performance. This allows us to consider the entire space of faults, including those for which model information or even data is not available.


The SIE is a computationally efficient calculation grounded entirely in signal theory. It is trained using raw sensor data during known nominal operation, i.e., "supervised" training. This data would ideally cover all nominal modes. However, should this be impossible to obtain, or if only approximate data is available, the SIE can be executed in a learning mode. This is possible because the SIE is capable of capturing "novel" data as part of its anomaly detection, and should this data prove to be acceptable upon review, it can be incrementally added to the SIE training. The only needed human effort is providence of nominal data; all other training and detection is completely autonomous.

The SIE can accept time-correlated input data from relatively large sources. Its specific outputs are the presence of off-nominal behavior or degradation, the signals implicated in the fault, and a predictive assessment of loss of functionality. It also identifies specific pair-wise resonances contributing to the fault (critical for assessing control-loop-induced failures), renormalization functions to quantify intramodal stability and degradation, and capture of off-nominal

## The power of a programming language The convenience of an application

**Buy before May 31, 2002  
and receive a FREE  
IDL programming book.**

**Call 303.786.9900**  
or visit [ResearchSystems.com/idlbook](http://ResearchSystems.com/idlbook)



- **Create custom applications with far fewer lines of code than traditional languages.**
- **Get more from your data faster with IDL's powerful interactive visualizations.**
- **Develop cross platform applications in a single environment.**

**IDL**

Call 303.786.9900 or visit us at  
[www.ResearchSystems.com/idlbook](http://www.ResearchSystems.com/idlbook)

**RESEARCH  
SYSTEMS**  
A Kodak Company



flight data to allow adaptation to new modes or specific hardware.

Unlike similar neural network approaches, each information product of BEAM has an implicit physical meaning. Where uncertainties about the diagnosis exist, each step towards constructing the ISE (information space estimate) and its analysis can be performed individually. This provides operators the maximum utility in managing system information. This property also allows BEAM to optimally summarize fault information for downlink.

The present software has been applied to a broad variety of systems and has demonstrated enormous potential in improving system operability while reducing operator workload. Systems previously studied have spanned from 6 to 1,600 observables, and at various data rates from 0.016 Hz to 10 kHz.

*This work was done by Sandeep Gulati and Ryan Mackey of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Electronic Components and Systems category.*

*In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to*

*Intellectual Property group*

*JPL*

*Mail Stop 202-233*

*4800 Oak Grove Drive*

*Pasadena, CA 91109*

*(818) 354-2240*

*Refer to NPO-20803, volume and number of this NASA Tech Briefs issue, and the page number.*


## TAXI Direct-to-Disk Interface Demultiplexes Proprietarily Formatted Data

Data can be stored in channel files in a PC in real time.

*Stennis Space Center, Mississippi*

The TAXI Direct-to-Disk interface is a special-purpose interface circuit for demultiplexing of data from a Racal Storeplex (or equivalent) multichannel recorder onto one or more hard disks that reside in, and/or are controlled by, a personal computer (PC). [The name "TAXI" as used here is derived from the acronym TAXI, which signifies transparent asynchronous transceiver interface.] The TAXI Direct-to-Disk interface was developed for original use in capturing data from instrumentation on a test stand in a NASA rocket-testing facility. The control, data-recording, and data-postprocessing equipment of the facility are located in a control room at a safe distance from the test stand. Heretofore, the transfer of data from the instrumentation to the postprocessing equipment has entailed post-test downloading via software, requiring many hours to days of post-test reduction before the data could be viewed in a channelized format. The installation of the TAXI Direct-to-Disk interface, in conjunction with other modifications, causes the transfer of data to take place in real time, so that the data are immediately available for review during or after the test.

The instrumentation is connected to the input terminals of the signal-processing unit of multichannel recorder by standard coaxial cables. The coaxial output of the signal-processing unit is converted to fiber-optic output by means of a commercial coaxial-cable/fiber-optic converter (that is, a fiber-optic transceiver) designed specifically for this application. The fiber-optic link carries the data signals to an identical fiber-optic



The Data-Flow Architecture of the modified test-data-handling system of a rocket-testing facility includes the parallel TAXI Direct-to-Disk interface and the TAXI-100 Direct-to-Disk interface solution.

transceiver in the control room. On the way to the TAXI Direct-to-Disk interface that is the focus of this article, the data signals are processed through a companion special-purpose circuit denoted by the similar name "parallel TAXI interface" (see figure).

The TAXI Direct-to-Disk interface is implemented by means of field-pro-

grammable gate arrays (FPGAs), memory chips, and other integrated circuits on a printed-circuit board that conforms to the peripheral component interface (PCI) standard and is denoted the TAXI-100 card. The TAXI-100 card performs real-time demultiplexing of the data signals from the parallel TAXI Direct-to-Disk interface to individual chan-





# $(R+D)^{\infty}$

Imagine. 25% of the world's R&D expenditures at your fingertips. The ability to see the vision of some of the world's greatest scientists and engineers. To share their thinking.

Now imagine the ability to search out and obtain licensable technologies that could make your job easier and your own products better/faster/smaller/less expensive.

Or maybe post the fruits of your own R&D labor for all the world to see.

**Think of the possibilities.**

yet2.com

You can also view yet2.com's Tech of the Week by logging onto [nasatechbriefs.com](http://nasatechbriefs.com)



nel files within the host PC. The data are provided in a layered interface that consists of the TAXI physical layer with the Racal proprietary data format contained in the application layer. The application layer is stripped off by the parallel TAXI Direct-to-Disk interface. Parallel clock and data signals containing the Racal proprietary data format are received by the TAXI-100 card in the parallel format and demultiplexed, according to formats extracted from within the data, into channel buffers in the form of first-in/first-out (FIFO) memory chips. Other proprietary programmable logic chips provide for the management and buffering of the channel blocks until they are presented to the host PC across a PCI bus interface. Real-time software drivers running under the Microsoft NT 4.0 operating system provide for real-

time handling of interrupts and buffering onto small computer systems interface (SCSI) disks in individual channel files. A host graphical user interface enables the user to select recorder channels.

*This work was done by Bruce G. Newman of Integrated Systems Consultants and Steven F. Ahlport of Pacific Custom Systems, Inc., for Stennis Space Center.*

*In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to*

*Integrated Systems Consultants  
1282 Shasta Ave.*

*Suite 1*

*San Jose, CA 95126*

*Refer to SSC-00141, volume and number of this NASA Tech Briefs issue, and the page number.*

## Program Improves Transfer of Data From CAD to Machine Shops

*Lyndon B. Johnson Space Center, Houston, Texas*

The EMNet computer program has been developed to overcome the difficulties and reduce the errors that, heretofore, have been encountered in transferring data from computer-aided design (CAD) systems to computer numerically controlled (CNC) machines. EMNet could improve operations in almost any industrial machine shop that uses CNC equipment.

The difficulties and errors in question arise because CNC output files (files of numerical control data generated by CAD postprocessing programs) have customarily been transferred either by use of floppy disks or by manual entry of data into CNC equipment. Sometimes these files are too large to fit on floppy disks. Even when floppy disks are used, data transfers often fail. Moreover, although some programs for transfer of data from CAD to CNC operations have been commercially available, those programs are expensive, are usable only by persons who have advanced computer skills, and have caused failures of computer networks.

EMNet was designed for use by machinists who have little or no computer experience and are responsible for entering numerical control data into CNC machinery, as needed, to produce machined parts. EMNet features an easy-to-use "point and click" graphical user interface, and is available in versions for the Windows 3.x, Windows 95, and Windows NT operating systems. EMNet offers a full

complement of Windows-style help displays for both machinists and computer-workstation administrators.

A computer on which EMNet is executed communicates with CNC machines via RS-232 serial interfaces connected according to specifications of the manufacturers of the machines. EMNet is easily configurable, and can be executed on a personal computer connected to two CNC machines. Each CNC machine can be assigned a name, a communication port, a default directory for data files, and options for whether to transmit carriage returns, line feeds, or end-of-block characters to the machine. If two machines are connected to a computer, the communication protocol for each port can be configured for the corresponding machine, separately from the protocol for the other port and its machine. Both the machine options and the communication-port settings are protected by a password that can be changed by a computer-workstation administrator.

After EMNet has been configured, the interaction required by the machinist is minimal. To transmit numerical control data to a CNC machine, the machinist performs the following steps:

1. Choose the machine by use of front-panel option buttons in an EMNet display. EMNet automatically switches to the default directory for the machine and opens the respective communication port.

## Design Your Data Acquisition System!



**DAQ Designer™ 2002**

Deutsch • English • Español • Français • Português • 日本語 • 한국어

Configuration Advisor  
for Measurement  
and Automation  
Windows 2000/NT/XP/Mac/ix  
350401G-01

ni.com/catalog

**NATIONAL  
INSTRUMENTS**

Tel: (512) 682-0100 • Fax: (512) 682-9300  
info@ni.com

© 2001 National Instruments Corporation. All rights reserved.

### FREE Configuration Advisor CD!

DAQ Designer™ 2002 recommends the right software and hardware components for your data acquisition (DAQ) applications, including:

- Acoustic/vibration
- Inspection and placement
- Data logging
- Signal acquisition and generation
- Control and simulation
- Data management
- High-speed digital
- Plus many more

**Design your DAQ system today.**

**ni.com/info**

To order a FREE DAQ Designer 2002 CD or run an online configuration advisor, visit [ni.com/info](http://ni.com/info) and enter naki21.

**NATIONAL  
INSTRUMENTS™**

**(800) 454-2610**

Fax: (512) 682-9300 • [info@ni.com](mailto:info@ni.com)

© 2002 National Instruments Corporation. All rights reserved. Product and company names listed are trademarks or trade names of their respective companies.



2. Click the "File" button on the EMNet display and select the file to transfer.
3. Prepare the CNC machine to receive the file.
4. Click the EMNet "Send" button.

To receive numerical control data from a CNC machine by use of EMNet, the machinist performs the following steps:

1. Choose "Settings," "Transfer," "Receive" from the EMNet menu.
2. Click the "Receive" button.
3. Send the data from the control panel of the CNC machine.

EMNet also offers the capability of performing a byte-by-byte comparison of two

numerical-control-data files. This capability was added to ensure that the data received by a CNC machine are intact; that is, without errors or missing bytes. To initiate a byte-by-byte comparison, the machinist performs the following steps:

1. Choose "File," "Compare" from the EMNet menu.
2. Select the "known good" (original) file.
3. Select the file to compare (typically, a file transferred from a CNC machine back to the computer).
4. Verify whether the CNC machine includes a "program number" in the

downloaded data, and if so, the line where the program number resides (typically line 2).

EMNet then performs a byte-by-byte comparison of the two files and displays the results. If a data mismatch is encountered, the comparison is terminated and the line and byte location of the mismatch is displayed.

*This work was done by W. David Smith of Rothe Joint Venture, L. P., for Johnson Space Center. For further information, contact the Johnson Technology Commercialization Office at (281) 483-3309. MSC-22986*

## Compensating for Motion Errors in UWB SAR Data

Processing is implemented in two stages by a computationally efficient algorithm.


NASA's Jet Propulsion Laboratory, Pasadena, California

A method of processing data acquired by ultra-wide-band (UWB) synthetic-aperture radar (SAR) provides for suppression of those errors that are caused by the undesired relative motion of the radar platform and the targets. This method involves, among other things, processing of data in the wave-number or frequency domain and the application of motion compensation as a function of the positions of a target relative to the radar platform.

The need for this method arises because of two sources of complication in UWB SAR that are not present in narrow-band SAR. One source of complication is that the prior commonly used SAR motion-compensation algorithm depends upon the Doppler shift of a well-defined radar-signal frequency, but the signal frequency in UWB radar is not well defined. The other complication is that the prior motion-compensation algorithm depends on azimuthal narrowness of the radar beam, but in UWB SAR, the requirement to make the range and azimuth resolutions approximately equal translates to a requirement that the radar beam be azimuthally wide (typical width of the order of a radian).

In a wide-beam SAR system, the key dilemma in properly compensating for motion is that one needs to track the location of each target on an SAR strip map, but the locations of the targets are not known from the outset. The present method addresses this dilemma. The method involves two stages of processing (see figure).

In the first stage, a strip parallel to the flight track is processed and targets are motion compensated, assuming that



**Motion Compensation** to first order is effected for a data strip, then refined to second order over small overlapping constituent patches. A motion-compensated image of the large patch is then constructed as a mosaic of the images of the smaller patches.


they are located in the antenna fan beam plane. Following the first-order motion compensation, a frequency-domain SAR processing algorithm is applied. The motion compensation for targets in off-boresight directions is not correct, but the motion compensation for the target(s) in the nominal center of the beam is correct. This stage of processing ensures that target impulse responses are located correctly geometrically, albeit insufficiently focused.

In the second stage of processing, the data strip is divided into overlapping small patches and it is pretended that the target(s) in each small patch lie at the center of the patch. The data processed in stage 1 are reprocessed within each small patch to refine the motion compensation. This reprocessing includes second-order motion compensation that takes the form of fre-

quency and phase shifts applied to the partially motion-compensated UWB SAR data. Inasmuch as the motion compensation is perfect only at the center of each small patch, the smaller the patches, the better the motion-compensation performance. For the sake of computational efficiency, the two-stage processing algorithm has been formulated such that the reprocessing in small patches is much less computationally demanding than is the processing of the wide area patch, such that it is computationally affordable to reprocess many small patches.

*This work was done by Soren Madsen of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Information Sciences category. NPO-21096*





**What does it take**  
to go from a good strip facility to an  
**amazing strip facility?**



One look at all those zeros tells you we've made a sizable investment in our specialty strip manufacturing facility. Carpenter now produces more types of strip — magnetic, controlled expansion, high strength, specialty stainless and others — in more thicknesses than anyone else. Besides boosting capacity, we've improved product quality. Strip shape and surface finish are superior. New furnaces and efficient processes are cutting cycle times. Add to that a global distribution network and you have the finest specialty strip facility money can buy. For details, call 1-800-654-6543 and ask to speak to a sales representative. Or visit [www.cartech.com](http://www.cartech.com)



**CARPENTER**  
Specialty Alloys

Engineered Materials for a Changing World



## Program for International Temperature-Scale Calculations

A computer program implements several aspects of the International Temperature Scale of 1990 (ITS90).

- For platinum resistance thermometers (PRTs), the program can perform reference-function ( $W_{ref}$ ) calculations traceable to the National Institute of Standards and Technology (NIST) through its Technical Note 1265.  $W_{ref}$  represents a perfect PRT that has a resistance of exactly 1  $\Omega$  at the triple-point temperature of water. The program provides for the entry of coefficients generated by a calibration facility and converts a measured resistance to an equivalent temperature with an accuracy of 5 millikelvins. The program also performs measurement calculations for PRTs: In such a calculation, the triple-point temperature of water as determined by a calibration laboratory is multiplied by the applicable NIST reference value.
- The program converts between output voltages and temperatures for several types of thermocouples that yield measurements traceable to NIST through its Monograph 175. These thermocouples are of types T (Cu/Cu-Ni), K (Ni-Cr/Ni-Al), J (Fe/Cu-Ni), E (Ni-Cr/Cu-Ni), N (Ni-Cr-Si/Ni-Si-Mg), B [Pt(30 percent)-Rh/Pt(6 percent)-Rh], S [Pt(10 percent)-Rh/Pt], and R [Pt(13 percent)-Rh/Pt].

*This program was written by Richard T. Deyoe of Dynacs, Inc., for Kennedy Space Center. For further information, access the Technical Support Package (TSP) free online at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Software category.*  
KSC-12166

## Updated Global Atmospheric Reference Model Computer Programs

The 1999 version of the NASA/Marshall Space Flight Center Global Reference Atmospheric Model (GRAM-99) and version 3.8 of the Mars Global Reference Atmospheric Model (Mars-GRAM) are the latest in two series of computer programs for calculating selected physical properties of the atmos-

pheres of Earth and Mars, respectively. GRAM-99, like prior versions of GRAM, implements an amalgamation of empirical models that represent geographical, seasonal, and monthly variations of the state of the terrestrial atmosphere (thermodynamic variables and horizontal and vertical wind components) at all altitudes from the ground up to those of spacecraft orbits. Mars-GRAM provides engineering estimates of density, temperature, pressure, and wind components in the Martian atmosphere as functions of latitude, longitude, altitude, and time.

The 1995 version of GRAM (GRAM-95) and the underlying model were described in "NASA/MSFC Global Reference Atmospheric Model — 1995 Version" (MFS-31105) *NASA Tech Briefs*, Vol. 21, No. 3 (March 1997), page 68. For altitudes from 0 to 27 km, GRAM-99 utilizes either of two sets of data: the binary-formatted Global Upper Air Climatic Atlas (GUACA) [which was also used in GRAM-95] or the newer ASCII-formatted Global Gridded Upper Air Statistics (GGUAS). For altitudes from 20 to 120 km, GRAM-99 uses, as did GRAM-95, a specially developed set of data based on Middle Atmosphere Program (MAP) data. Above 90 km, GRAM-99 uses the 1999 version of the Marshall Engineering Thermosphere (MET) model [also known as the Jacchia model]. Fairing techniques assure smooth transitions among the models and sets of data in the overlap height ranges of 20 to 27 km and 90 to 120 km.

Like GRAM-95, GRAM-99 estimates concentrations of water vapor and of  $O_3$ ,  $N_2O$ ,  $CO$ ,  $CH_4$ ,  $CO_2$ ,  $N_2$ ,  $O_2$ ,  $O$ ,  $A$ ,  $He$ , and  $H$ . For altitudes above 90 km, the Jacchia model can also provide concentrations of  $N_2$ ,  $O_2$ ,  $O$ ,  $A$ ,  $He$ , and  $H$ . Atmospheric-constituent profiles of the Air Force Geophysics Laboratory are also used extensively for altitudes up to 120 km.

GRAM-95 incorporated a then new variable-scale perturbation model that provides both large-scale (wave) and small-scale (stochastic) deviations from mean values for thermodynamic variables and horizontal and vertical wind components. Such perturbations are characterized by time scales of less than a month and are associated with turbulence, storms, atmospheric tides, and other phenomena. GRAM-99 incorpo-

rates improvements in the small-scale perturbation model for representing intermittent phenomena.

A major new feature in GRAM-99 is an option to substitute Range Reference Atmosphere (RRA) data for conventional GRAM climatological data when a trajectory passes sufficiently near any RRA site. This feature makes it possible, for example, to simulate the atmosphere, starting from takeoff at one RRA site (e.g., Edwards Air Force Base), where RRA data are used, then make a smooth transition to an atmosphere characterized by GRAM climatology en route, then make another smooth transition to an atmosphere characterized by RRA data at a landing site (e.g., White Sands, New Mexico).


A complete user's guide for running GRAM-99 is available. The user's guide includes sample input and output. Also included is an example that shows how to incorporate GRAM-99 as a subroutine in another program (e.g., a trajectory code).

Mars-GRAM implements a mathematical model based on surface and atmospheric measurements taken during the Mariner and Viking (orbiter and lander) missions. At altitudes above about 120 km, the Mars-GRAM model is based on the Stewart (1987) Mars thermospheric model. Mars-GRAM can be used as a stand-alone program or can be incorporated into an orbit-propagator or trajectory code.

Version 3.8 of Mars-GRAM incorporates some new features that were suggested by users engaged in the design and operation of spacecraft on missions of robotic exploration of Mars. Mars-GRAM 3.8 uses new values of planetary reference ellipsoid radii, gravitation terms, and the rate of rotation, (consistent values now used by NASA's Jet Propulsion Laboratory), and includes centrifugal effects on gravity. The model now uses the NASA Ames Global Circulation Model low-resolution topography. Curvature corrections are applied to winds, and limits based on speed of sound are applied. The altitude and molecular weight of the ionization peak of the F1 layer of the Martian ionosphere and the density scale height (including the effects of the change of molecular weight with altitude) are computed. A check is performed to dis-



Every engineer knew what was wrong with product development.  
Then suddenly, it was theirs to change.



# Product First™

## The Adventure Begins

From the producers of Pro/ENGINEER® comes an exciting new tale of product development. Starring engineering in the leading role.

WARNING: CONTAINS  
STRONG PRODUCT  
DEVELOPMENT CONTENT



**COMING JUNE 18 TO ENGINEERS EVERYWHERE**  
**RESERVE YOUR FREE TICKET AT [WWW.PTC.COM/GO/ENGINEERING](http://WWW.PTC.COM/GO/ENGINEERING)**

A PRODUCTION OF PTC. ALL CHARACTERS AND EVENTS ARE INTENDED TO PUT ENGINEERS AT THE CENTER OF PRODUCT DEVELOPMENT. ©2002 PARAMETRIC TECHNOLOGY CORPORATION, PTC AND ITS LOGO, SHAPING INNOVATION, PRO/ENGINEER, AND PRODUCT FIRST ARE TRADEMARKS OR REGISTERED TRADEMARKS OF PARAMETRIC TECHNOLOGY CORPORATION OR ITS SUBSIDIARIES IN THE UNITED STATES AND IN OTHER COUNTRIES.



allow temperatures below the sublimation temperature of CO<sub>2</sub>.

The user's guide for Mars-GRAM 3.8 summarizes the changes made for this version and includes an appendix that summarizes changes made for versions 3.5 through 3.7. It includes instructions for running the program, plus sample input and output files.

*These programs were written by Carl G. Justus of Computer Sciences Corp. for Marshall Space Flight Center. For further information, contact Carl G. Justus at Jere.Justus@msfc.nasa.gov. MFS-31461/62*

## Gyroscope Automated Testbed

The Gyroscope Automated Testbed (GAT) is a fully automated inertial device characterization testbed. Rotational response parameterization and short-term noise stability analysis are the fundamental principles behind the system. Complete response characterization, bias stability, sensitivity, and range are supported along with a drift stability and noise analysis through use of a Green chart and calculation of the

power spectral density. GAT is also capable of performing turn-on cycle stability and temperature-dependent testing.

The system is fully automated yet allows complete customization of test parameters. Each of the specific tests may be enabled or disabled as desired, and each test may be individually configured. The state of the system can be saved and loaded at any time providing quick and easy access to various configurations.

The hardware interface layer of the program has been abstracted to provide a flexible yet robust method of input and control. The data-acquisition subsystem provides a universal method of acquiring data from devices. Direct analog inputs are provided and can be individually customized. General-purpose-interface-bus (GPIB-) compliant devices may be used for either input (i.e., voltmeters) or as control or output (i.e., temperature controller). This flexible arrangement allows nearly unlimited expandability and extendibility to future capabilities. An abstract rate table interface permits control of any rate table which supports an analog or GPIB interface.

Results are presented in both summary and complete form. Processed and raw data can be saved to a file during a

test. Key values and data plots are output to a table in real time during a test. At the completion of a testing session, a document is automatically generated which summarizes the results and encapsulates all output charts generated during the session.

The GAT system provides a cost-effective way of characterizing inertial devices. Although designed for analyzing microelectromechanical (MEM) vibratory gyroscopes, it can easily be adapted to accelerometers by simply changing the units of measure. It is also highly efficient as up to five devices can be tested simultaneously.

The GAT system currently is executed on a Pentium III (or equivalent), 550-MHz computer with 256MB of RAM, 10GB hard drive, internal data acquisition card, and GPIB interface card.

*This program was written by Christopher Evans and Roman Gutierrez of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Software category.*

*This software is available for commercial licensing. Please contact Don Hart of the California Institute of Technology at (818) 393-3425. Refer to NPO-20847.*



## Plug-and-Play Spectrometer

### USB2000 Miniature Spectrometer Delivers Hassle-Free Instrument-to-PC Interfacing

**Effortless Interface.** Plugs directly into the USB port of desktop or notebook PCs, or the serial port of handheld PCs.

**Simple Start-Up.** Software recognizes the spectrometer and automatically enters wavelength calibration coefficients.

**Modular Design.** Choose from 2 detectors, 14 gratings, 6 slits and hundreds of accessories to optimize your system.

**Portable Use.** Options such as a battery pack and 470 nm LED (attached to the USB2000 in larger photo) make your spectrometer field-portable.

**Starting at Just \$2,199!**

**Call Today!**  
**727.733.2447**

In Europe:  
**+31 (0) 26 319 05 00**



**Info@OceanOptics.com**

**For all your photonics needs, visit**  
**[OceanOptics.com](http://OceanOptics.com)**



# PHOTONICS

---

## Tech Briefs

March 2002

PHOTONICS SOLUTIONS FOR THE DESIGN ENGINEER

Readers' Choice 2001 Product of the Year .....	11a
OPSLs: a New Generation of Semiconductor Lasers .....	2a
Technologies of the Month .....	6a
Light Recycling and Color Scrolling for Brighter Displays .....	8a
Software Automates Processing of SAR Image Data .....	10a
Liquid-Crystal Phase-Shifting Shearing Interferometer .....	12a
Multi-Screen-Image- and Catalog-Viewing Program .....	12a
Phase-Retrieval Camera for Optical Testing .....	13a
Testing Grazing-Incidence Mirrors at Nearly Normal Incidence .....	14a
Making Digital Composite Images for Technical Illustration .....	16a
Fiber-Optic Phase-Locked Loop Sensitive to Local Strain Only .....	17a
Product Guide: Optical Time Domain Reflectometers .....	18a
New Products .....	22a

Cover photo courtesy Point Source Inc.



# Photonics Tech Briefs 2001 Readers' Choice Product of the Year

Each issue of *Photonics Tech Briefs* in the year 2001 carried a Product of the Month, a photonics product the editors felt was of special interest and value to readers who work with lasers, optics, fiber optics, and video and imaging equipment. The winners of the gold, silver, and bronze awards, described in detail below, were chosen by readers voting for one of these products on *Photonics Tech Briefs*' web site earlier this year. The 2001 winners are:

★ **Gold Winner and Product of the Year:** TNP Instruments (Carson, CA) Model DUV-250 deep-UV microscope;

★ **Silver Winner:** Raytheon Commercial Infrared (Dallas, TX) PalmIR digital thermal imaging camera; and

★ **Bronze Winner:** Polytec PI (Tustin, CA) F-130 nanoalignment system for photonics packaging.

## TNP Instruments DUV-250 Deep-UV Microscope



TNP Instruments DUV-250 Deep-UV Microscope

other benefit, the company says, is significantly reduced cost: the DUV-250 typically operates at less than half the cost of traditional laser systems. Designed to fill a gap between visible-light and scanning electron microscopy, the company says, it represents a major in-

novation for semiconductor premanufacturing and failure analysis, for medical research and testing, for photomask inspection, and for mass storage component manufacturing.

Another advantage of the high magnification of this microscope is that even submicron features can be checked without any sample preparation. It can produce useful images of features 0.1 micron and below.

[www.tnpinstruments.com](http://www.tnpinstruments.com)

## Raytheon Commercial Infrared PalmIR 250 Digital Thermal Imaging Camera

Raytheon Commercial Infrared says that its PalmIR 250 handheld digital thermal imaging camera is the first with zoom capacity. It produces detailed 320-x-240-pixel uncooled ferroelectric thermal images, and offers users a choice between the standard 75-mm f/1.0 lens package or other packages ranging from 25 to 150 mm. An electronic zoom (2x) and expanded menu items, including video peaking, are also standard. It weighs only 2.6 pounds, and is operational with only one hand.

The PalmIR 250 offers VCR-compatible video output through an RCA jack in an NTSC format, and PAL format for international customers. Raytheon Commercial Infrared expects the camera to find applications in public safety, search and rescue, surveillance, industry, and wildland and exterior firefighting. With the zoom capacity, users can both see through darkness up close and also spot a person or an object up to 2400 feet away. With its sharp picture and portable design, the PalmIR 250 is effective for day



Raytheon Commercial Infrared PalmIR Digital Thermal Imaging System

and night surveillance to monitor perimeters, scan long distances, and spot intruders. In industrial applications, the unit can be used for predictive maintenance to inspect machines, electrical conduits, and pipelines for excess heat, leaks, or potential failures.

[www.raytheoninfrared.com](http://www.raytheoninfrared.com)

## Polytec PI F-130 Nanoalignment System for Photonics Packaging

Polytec PI Inc. is marketing the F-130 X-Y-Z nanopositioning system for photonics packaging, originating from its German partner Physik Instrumente. The F-130 combines a 15-x-15-x-15-mm motor-driven travel range with what the company calls ultra-precision piezomanipositioning technology and nanometric-scale resolution. It also has a 100-x-100-x-100-micrometer high-speed piezoelectric travel range for fine alignment. Resolution of the motor is 0.1 micrometer and of the piezoelectric drive 1 nanometer. Other features are fast scanning speed, quick settling, small dimensions, and closed-loop option with either the motor or piezoelectric drive.

Designed for fiber positioning and photonics packaging applications, the F-130 has a large selection of control electronics for easy adaptation. A 2D transverse profile of a single-mode fiber coupling can be acquired in less than four seconds.

Polytec sees typical applications in fiber alignment, semiconductor technology, mass storage, optical instrumentation, and more.

[www.polytecpi.com](http://www.polytecpi.com)



Polytec PI NanoAlignment System for Photonics





A tiny revolution is about to begin.

[www.indigosystems.com](http://www.indigosystems.com)  
Aerosense Orlando 2002  
Booth #413

**indigo**<sup>TM</sup>   
brighter.

SEE US AT OFC, BOOTH #1824

For Free Info Circle No. 485 or Enter No. 485 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



# OPSLs: a New Generation of Semiconductor Lasers

Optically pumped semiconductor lasers bring wavelength flexibility to their class of laser.

**L**aser instrumentation and equipment designers have traditionally been challenged by a combination of wavelength and integration limitations. While trying to develop compact, flexible instruments for contemporary end-user requirements, designers have sought to leverage the power of diode-pumped solid-state lasers in applications that traditionally employed larger and less efficient air-cooled argon ion lasers. In existing diode-pumped lasers that used neodymium-doped crystals, designers found the compact size and efficiency they needed but also found huge gaps of "no-man's land" in the wavelength scale, especially in the blue. Furthermore, the advent of violet laser diodes still did not fill gaps in the blue-green segments of the spectrum. A new generation of semiconductor lasers, namely optically pumped semiconductor lasers (OPSLs), addresses designer and market wavelength issues while facilitating compact packaging and efficiency that opens new opportunities for laser-based instruments.

Optically pumped semiconductor lasers are part of a class of devices called vertical external-cavity surface-emitting lasers (VECSELs). The OPSL implementation is based on a patented technology from Coherent that uses this technology in its sapphire laser product line. Most VECSELs are driven by electrical current, as are standard diode lasers. In contrast, the OPSL uses optical pumping to drive the laser emission. This provides an excellent spatial mode quality that electrical pumping cannot offer.

The main building blocks for an OPSL include a continuous-wave 808-nm semiconductor pump laser, identical to those used for pumping Nd:YAG or Nd:YVO<sub>4</sub> diode-pumped solid-state lasers; focusing optics; the optically pumped semiconductor (OPS) chip that acts as a gain medium and high reflector; and an output coupler. Figure 1 is a schematic of this arrangement.

The enabling technology is the GaAs OPS chip, grown using molecular beam epitaxy (MBE), the process well known for wafer manufacturing consistency

(see Figure 2). The lower section of the OPS chip consists of several epitaxially grown high- and low-index layers that form a distributed Bragg reflector, which serves as the OPSL's rear cavity mirror. Several planar quantum wells, designed to emit at the desired wavelength, are grown on top of the index layers. Cladding layers separate the emission quantum wells and absorb the pump photons. The top layer of the OPS chip is given an antireflection coating.

Leveraging extensive GaAs knowledge accrued over time in the semiconductor industry, the OPS chip is fabricated using the same standard GaAs-based material and MBE wafer growth as DPSS pump diodes. The technology also gives the precise control over epitaxial growth made possible by the MBE method. In addition, the intracavity second harmonic generation (SHG) method, used extensively in fabricating existing Nd:YAG and Nd:YVO<sub>4</sub> DPSS product lines, is also used in OPSL fabrication.

OPSL fabrication uses the proprietary Permalign™ process, a high-



# This is about the only kind of coating we don't make.



## Standard and Custom Coatings. R&D. OEM. Sheet Stock.

With so many capabilities, we never have to sugar coat the truth about our coatings. From custom R&D development to OEM production, ZC&R has exactly what you're looking for. Providing, of course, you're looking for quality. To say nothing of our flexibility in helping design an optimal coating for your project, from micro optics to 29" diameter. To get a real taste of what we can do for you, call 800-426-2864 or visit [zcrcoatings.com](http://zcrcoatings.com) today.

[zcrcoatings.com](http://zcrcoatings.com)



ISO 9002 • AS 9000  
Registered

1401 Abalone Ave. / Torrance, CA 90501 / 310-381-3060 / 800-426-2864 / FAX: 310-782-9951  
e-mail: [info@zcrcoatings.com](mailto:info@zcrcoatings.com) / [www.zcrcoatings.com](http://www.zcrcoatings.com)

For Free Info Circle No. 469 or Enter No. 469 at [www.nasatech.com/rs](http://www.nasatech.com/rs)






Figure 1. Schematic of the OPSL.

volume clean-room manufacturing method. This method uses robotics to accurately align optical components while permanently soldering or welding each into place. The laser cavity is then hermetically sealed for environmental stability and long lifetime with no user intervention.

The design significance of the OPSL technology is that, for the first time, wavelengths can be developed to the specifications of an OEM application. This is because OPSL wavelengths can be engineered simply by varying the semiconductor growth, unlike DPSS lasers, where the fundamental wavelength is defined by fixed atomic transitions. OPSLS can also be easily designed with high intracavity powers, making them ideal for intracavity frequency doubling.

Freeing the designer of wavelength gaps and limitations, this technology fa-

cilitates the flexibility for OPSL development at several wavelengths in the IR and blue at powers ranging from tens of milliwatts to multiple watts.

### OEM Integration Advantages

The solid-state foundation and power efficiencies of the OPSL have spawned new possibilities for OEM instrumentation integration and packaging. The laser head itself measures less than three inches by five inches. This compact form factor permits deep integration in instrumentation, bringing the laser source nearer to samples or work surfaces. Supplanting bulky and inefficient air-cooled argon ion lasers, OPSL technology integration can shrink a large instrumentation package down to a simpler and more cost-effective tabletop format that requires no supplemental cooling for the laser source. For some applications, this represents a significant reduction in instrument footprint.

The Coherent OPSL technology can dramatically reduce a design's power and heat dissipation requirements. For example, the 488-nm laser draws a maximum of 60 W of electrical power, up to 50 W of which goes to the thermoelectric cooler to stabilize the resonator independently of the environmental conditions. The remaining 10 W is used to generate blue output. By comparison, the earlier air-cooled argon ion laser requires at least 1.5 kW of power. Typically the OPSL de-

signs consume 98 percent less power, with 98 percent lower heat dissipation requirements, which represents a much-needed breakthrough in efficiency.

With the trend in laboratory and research management moving toward populating laboratories with ever-increasing numbers of analytical instruments, product design efficiency and compact packaging become critical. Compact instrumentation based on OPSL technology can be deployed in clustered environments without the heat dissipation or ambient cooling fan noise problems that argon-ion-laser-equipped instruments would generate. Thus energy is conserved and ergonomic issues are minimized.

OPSLS are available today that produce 10 to 20 mW at 460 nm and 488 nm with very low noise (less than 0.25 percent RMS) and TEM<sub>00</sub> spatial characteristics with an M<sup>2</sup> of less than 1.1. These factors improve signal-to-noise ratios, sensitivities, and focus properties, which are key for OEM designs to meet end-user application demands.

### Wavelength Independence Spurs Growth

Customization for wavelength requirements is now the response to market and application pressures. Products at 488 nm, 460 nm, and 980 nm have been commercialized. So far, the 488-nm laser




Figure 3. OPSL can extend the limits of laser-induced fluorescence.




Figure 2. The OPS chip.

serves the bioinstrumentation and inspection fields, while the blue device at 460 nm serves graphic arts and display. The 980-nm product is driven by the growing demands of the telecommunications industry. The inherent flexibility of the OPSL design will permit additional wavelengths to be developed to meet other evolving market requirements.

The potential wavelength span of OPSLS can initiate developments to ex-






Figure 4. The OPSL's stability and TEM<sub>00</sub> beam quality promise to increase precision in applications such as silicon wafer and mask inspection.

tend today's laser-induced fluorescence (LIF) dye chemistry for cell sorting, hematology, or DNA sequencing beyond the limits currently set by argon ion and Nd:YAG wavelengths (Figure 3). With the availability of multiple and new wavelengths, OEM designers can increase the diagnostic capability of a single instrument, with which 15 or 20 tests could be run, not just a few.

For the inspection market, OPSL stability and TEM<sub>00</sub> beam quality promise to increase the precision in applications spanning from silicon wafers to mask inspection (Figure 4). Within these applications, current light-scattering techniques suffer from laser noise masking the return signal from the sample. Since the OPSL is a low-noise laser or "quiet" excitation source, OEMs could design future instruments with a much higher sensitivity. For inspection systems, this can mean the detection of much smaller sample flaws or the detection of even smaller dust particles on surfaces.

The graphic arts fields stand to benefit from the cost efficiency resulting from reliable and efficient OPSL sources with tailored wavelengths and low-amplitude noise properties (Figure 5). For example, in digital photofinishing, where traditional methods employ argon ion

As the demand for dense wavelength division multiplexed systems and other high-performance fiber optic communications uses grows, OPSLs will keep pace with higher pump power.




Figure 5. OPSL technology may unseat traditional approaches to photofinishing.


Previous iterations of lasers have eventually scaled in wavelength to meet a range of OEM and customer needs. The design flexibility in the new-generation OPSL technology should permit even wider implementation, dictated by the needs of today's and tomorrow's applications.

For further information, please contact the author of this article, Matthias Schulze, product line manager at Coherent Laser Division. He can be reached at +49-451-3000-303, or by e-mail at [matthias.schulze@coherent.com](mailto:matthias.schulze@coherent.com).

lasers at 457 nm, a 460-nm OPSL wavelength matches the absorption of photo emulsions perfectly. OPSL's low-noise performance could also translate into a distortion-free end result, even under close scrutiny by the very sensitive human eye. And in the display market, OPSLs could finally bring the coveted high-power blue component to drive RGB applications.

At near-IR wavelengths, OPSLs offer the highest single-mode fiber-coupled 980-nm output power available, making them ideal for pumping erbium-doped fiber amplifiers.

## Powerful Motion/Vision Integration



**Integrate motion with vision and data acquisition.**

### Motion Control

- Servo and stepper
- Updatable firmware
- Configuration utilities

### Machine Vision

- Easy to program
- High-level machine vision functions
- Flexible hardware

### Integration

- High-speed, synchronized bus
- Platform choices – PXI™/CompactPCI™
- LabVIEW™ and Measurement Studio™

[ni.com/info](http://ni.com/info)

Visit [ni.com/info](http://ni.com/info) and enter nadr23 for motion/vision solutions

**NATIONAL INSTRUMENTS™**

**(800) 811-0742**

Fax: (512) 683-9300 • [info@ni.com](mailto:info@ni.com)

© Copyright 2001 National Instruments Corporation. All rights reserved. Product and company names listed are trademarks or trade names of their respective companies.



## Miniature Spectros reliable & low cost Instrumentation

### UV-VIS-NIR

#### Fiber Optic SPECTROMETERS

MEASURE Absorbance, Transmittance, Reflectance, Irradiance, Fluorescence, Chemical concentrations, Colors, LEDs, Laser  $\lambda$ , power, Plasma, and Thin Films.

Turnkey Systems for SpectroRadiometers  
SpectroColorimeters SpectroFluorimeters  
UV-VIS 190-850nm VIS-NIR 350-1150nm  
Optical Spectrum Analyzers to... 1620nm

CCD/PDA detectors with built-in A2D  
Superb spectral imaging & resolution  
Suite of measurement applications via

#### SpectraWiz® Software

Free Win9x/NT/00 Program & Drivers

### EPP2000 Portable

2048 Wavelengths



multi-beam daisy-plug&play  
pcmcia/pci fast parallel xfer

### ISA2000

Multi-channel  
SpectroSystems

also powered by LabVIEW



[www.stellarnet-inc.com](http://www.stellarnet-inc.com)



13801 McCormick Drive  
Tampa, FL 33626 USA  
813-855-8687 / 813-855-2279 fax

# Technologies of the Month

Sponsored by **yet2.com**

For more information on these and other new,  
licensable inventions, visit [www.nasatech.com/techsearch](http://www.nasatech.com/techsearch)

## A Very Thin Flexible Laminate of Transparent Plastic and Glass

### AGFA

A laminate of a thin borosilicate glass layer and a plastic support layer is provided. The advantages of a glass layer, e.g., dimensional stability, high density, hardness, barrier properties against moisture, solvents and oxygen, are combined with the properties of a polymer layer, e.g. flexibility, by laminating a glass layer together with a polymer layer. One of the layers in the laminate can be a functional layer for such things as security cards, photomasks, semiconductor or electroconductive devices with, or functional layers for use in, flat panel displays. Another application for the laminate is as packaging for electronic chips. The laminate combines all the advantages of a glass material (strong, undeformable, impermeable) with the advantages of a polymer (flexible, lightweight), while both materials are transparent.

For more information go to:  
[www.nasatech.com/techsearch/  
tow/agfa2.html](http://www.nasatech.com/techsearch/tow/agfa2.html)  
email: [nasatech@yet2.com](mailto:nasatech@yet2.com);  
phone: 617-557-3837

## Glass Substrate for a Thin Film Solar Cell Having a Curved Surface

This technology provides a glass substrate having a transparent electroconductive film suitable for a solar cell having a curved surface shape, which is superior in weather-resistance and crack-resistance to a solar cell using a plastic film as a substrate, and it is thereby possible to produce solar cells of various curved surface shapes. According to the method for producing a glass substrate of this technology, a curve-shape glass substrate having a transparent electroconductive film with good quality can be produced at a low cost by forming the transparent electroconductive film on a glass sheet and then subjecting the resul-

tant glass substrate to a bending treatment without substantially deteriorating the transparent electroconductive film. The solar cell for a sunroof of this technology has the advantages of good aerodynamics, an automobile body efficiently utilizing light incident on the sunroof, and also having a good design.

For more information go to:  
[www.nasatech.com/techsearch/  
tow/substrate.html](http://www.nasatech.com/techsearch/tow/substrate.html)  
email: [nasatech@yet2.com](mailto:nasatech@yet2.com);  
phone: 617-557-3837


## New Device Corrects Myopia

Pneumatic keratology is a new procedure that corrects refractive errors, most notably myopia or nearsightedness, without the risks, complications, and expense of laser keratectomy, laser *in situ* keratomileusis (LASIK), or other invasive surgical procedures. Pneumatic keratology uses a simple device, the EyeModel, which corrects by means of a vacuum. The method and device is a patented invention capable of modeling the shape of the cornea of the eye. The basis of pneumatic keratology is described in a U.S. patent, "Method of Altering the Shape of the Cornea." Pneumatic keratology provides a revolutionary means to correct all refractive errors, such as myopia, hyperopia, and astigmatism with unprecedented simplicity. Unlike other methods, the cornea is not cut, burnt, ablated, or damaged. No tissue is removed and nothing is implanted. The EyeModel has elongated openings that are connected to a vacuum pump with a thin tube. By placing the device on the surface of the cornea and then applying a vacuum, a plastic deformation of the area of the cornea below the openings is achieved. The resulting effect is that the curvature and the refractive power of the cornea and the eye are changed.

For more information go to  
[www.nasatech.com/techsearch/tow/  
myopia.html](http://www.nasatech.com/techsearch/tow/myopia.html)  
email: [nasatech@yet2.com](mailto:nasatech@yet2.com);  
phone 617-557-3837



# Building a laser or just want to buy one?



*We can help you with either.*

What you may not know is that we've always been able to. **CEO's** diode division, known as **Industrial Microphotonics Company**, has united with our laser division under one name, **Cutting Edge Optonics (CEO)**. And with the addition of our new extreme ultraviolet light source division, **CEO** now also has a brand new look.

But don't worry. Only our look has changed. At **CEO**, you'll still get the same quality service and products, whether you need diodes, modules or full laser systems. With our expertise across the range of laser products, we can provide just the right laser to meet your needs, or just the right components for you to build your own. It's that simple.

20 Point West Boulevard • St. Charles, MO 63301  
636-916-4900 • fax 636-916-4994  
[www.ceolaser.com](http://www.ceolaser.com) • [info@ceolaser.com](mailto:info@ceolaser.com)

**CEO**  
CUTTING EDGE OPTONICS  
A T2000 Company

For Free Info Circle No. 421 or Enter No. 421 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



# Light Recycling and Color Scrolling for Brighter Displays

Two efficiency-enhancing techniques would be combined.

NASA's Jet Propulsion Laboratory, Pasadena, California

The efficiencies and thus the brightnesses of flat-panel projectors based on liquid-crystal devices (LCDs) and digital mirror devices (DMDs) would be increased by the combination of a color-scrolling technique and a light-recycling technique, according to a proposal. These techniques were originally proposed separately for the purpose of increasing the efficiencies of LCD-based display devices.

The scrolling-color technique was reported previously in "Using Surface-Plasmon Filters to Generate Scrolling Colors" (NPO-20110), *NASA Tech Briefs*, Vol. 23, No. 2 (February 1999), page 14a. To recapitulate: by use of prisms and surface-plasmon tunable filters, white light from a lamp or other illumination source would be converted into a pattern of scrolling primary colors. The advantage of this scheme is that both polarization components and all colors would be utilized, whereas in prior schemes, most of the light power is wasted through color and/or polarization filtering.

The light-recycling technique was reported in "Low-Absorption Color Filters for Flat-Panel Display Devices" (NPO-20435), *NASA Tech Briefs*, Vol. 23, No. 12 (December 1999), page 34. In this technique, one would replace traditional dye filters with surface-plasmon or interference filters, which are more reflective than absorptive. In addition, the filter and illumination optics would be arranged so that much of the light in all colors and both polarizations reflected from the filters would be sent back through the light-source optics to be reused as illumination.

The present proposal calls for, among other things, a white light source equipped with a reflector and a color-recycling and -scrolling panel (CRSP), as shown schematically in the upper part of Figure 1. The CRSP would contain an array of voltage-tunable or voltage-switchable filters, each of which would transmit one primary color [red (R), green (G), or blue (B), depending on the applied voltage] and reflect the other two primary colors. The reflected light would be bounced back and forth between the CRSP and the light-source reflector until light of each color impinged on its proper color filter. Thus, light in the three colors would be redistributed as needed and relatively little would be lost.

At the first phase of a three-phase operating cycle, the color-filter array could be energized to a color pattern as RGB . . . , for example. In the next phase, the color pattern could be changed to BRG . . . . In the third phase, the color pattern could be changed again to GBR . . . . The net result is that recycling and scrolling of colors would occur in combination. The number of color filters need not match the number of pixels in the display panel to be illuminated panel pixels; the only requirement on the number of filters is that it be an integer multiple 3.

The voltage-tunable or voltage-switchable color filters could be surface-plas-

mon tunable filters [see "Voltage-Tunable Surface-Plasmon Band-Pass Optical Filters" (NPO-19988), *NASA Tech Briefs*, Vol. 22, No. 8 (August 1998), page 18a]. Alternatively, they could be assemblies of interference or thin-metal film filters, high-index-of-refraction prisms, and total-internal-reflection switches [see "Digitally Tunable Color Filters and Beam Scanners" (NPO-20240), *NASA Tech Briefs*, Vol. 23, No. 9 (September 1999), page 65] that would include layers of an electro-optical material between prisms, as shown in the lower part of Figure 1. In the absence of applied voltage, the electro-optical layer in each switch would have a low index of refraction, so




Figure 1. Scrolling Colors Would Be Generated, and light not used to generate scrolling colors on the first pass would be recycled and so used on subsequent passes.



# Top Ten Innovations in Optical Analysis Software.

10. Volume Scatter
9. RepTile™
8. Advanced Ray Sorting
7. Birefringence
6. Anisotropic Surfaces
5. Source Spreadsheet
4. Diffraction Gratings
3. Thin Film Stacks
2. Volume Flux Viewers

1.

## TracePro®

TracePro is number one because it's the only optical analysis software that has all of the innovative features listed above.

We've added these nine features to TracePro in just 18 months. That tells you what you can expect from our award-winning technical excellence now—and in the future.

TracePro is easy to learn and easy to use. Most important, it reduces your product development time by 30 to 50 percent.

**Call Lambda Research today to receive a free demo CD.**

**TracePro**

LAMBDA RESEARCH CORPORATION • (978) 486-0766 • [sales@lambdares.com](mailto:sales@lambdares.com) • [www.lambdares.com](http://www.lambdares.com)

**Lambda Research**  
Corporation



# new! Plug & Play Camera Kit



**\$1495**  
complete system

**SILICON VIDEO® 2112** 1.3 megapixel, 10 bit, progressive scan, monochrome or color, with a programmable resolution to 1288 x 1032 pixels.

**PIXCI® D2X PCI Interface** supplies power and programmable pixel clock for the camera. Trigger input for async reset.

**XCAP-Lite Software** provides camera control including sub-windowing/sampling, mirror & flip modes, RGB balance, and user-selectable pixel clock.

**2 Meter Cable** supplies power, pixel clock, and control.

**SILICON VIDEO® 2112**

**PIXCI® D2X**

**XCAP-Lite**



Buffalo Grove, IL USA  
Tel - 847 465 1818  
Fax - 847 465 1919  
epixinc.com/nt

©2002 EPIX, Inc.

For Free Info Circle No. 419 or  
Visit [www.nasatech.com/419](http://www.nasatech.com/419)




Automation Doesn't Get Any Easier!




Precision Linear Positioners

From \$399



Motorized Mirror Mounts

From \$999



I/O and A/D Products

From \$199



Chain Multiple Units to Single Port

Controller Built Into Each Unit

toll free: 1-866-409-2237 fax: 604-648-8033

**www.zaber.com**

For Free Info Circle No. 444 or  
Enter No. 444 at [www.nasatech.com/rs](http://www.nasatech.com/rs)




Figure 2. A Flat-Panel Projector based on an LCD would utilize the scrolling-color and light-recycling techniques for maximum light-utilization efficiency.

that total internal reflection would occur at the prism/switch interfaces. The application of a sufficient voltage to the switch would increase the index of refraction of the electro-optical layer sufficiently to allow light to pass through. By appropriate switching in this manner, one can cause light of the various colors to travel along various paths in the prisms to obtain various output color patterns.

Figure 2 presents an example of an LCD-based display system that would include a CRSP. The image of the CRSP would be projected into a monochrome LCD panel by a relay lens. A zoom lens would project an image of the LCD onto a screen. It would be necessary to use an electronic driver that would synchronize the scrolling of colors and the modulation of light by the LCD.

Similar geometry can be applied to DMDs.

This work was done by Yu Wang of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Physical Sciences category.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Intellectual Property group

JPL

Mail Stop 202-233

4800 Oak Grove Drive

Pasadena, CA 91109

(818) 354-2240

Refer to NPO-21052, volume and number of this NASA Tech Briefs issue, and the page number.

## Software Automates Processing of SAR Image Data

NASA's Jet Propulsion Laboratory, Pasadena, California


The Automated SAR Image Processor (ASIP) computer program increases the efficiency of production of scientifically useful imagery from raw synthetic-aperture-radar (SAR) image data. In the absence of ASIP, the processing of SAR data is a labor-intensive task, often involving supporting personnel, that requires expertise in the use of a variety of image-data-processing programs, as well as expertise in the scientific specialty of the end user. ASIP captures the diverse components of expertise to assist the scientific end user in obtaining the scientific end product without supporting personnel. ASIP applies artificial-intelligence planning techniques to reason about the interactions and interfaces among the many specialized programs needed to process SAR data. The planning component of ASIP then manages the

flow of information and control in order to produce the desired scientific data product efficiently. In one application, for example, ASIP made it possible to produce special maps pertaining to the study of surface winds with only 1/10 the number of manual inputs and 30 percent less central-processing-unit time than would otherwise be necessary.

This program was written by Steve Chien, Forest Fisher, Ronald Greeley, and Edisanter Lo of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Physical Sciences category.


This software is available for commercial licensing. Please contact Don Hart of the California Institute of Technology at (818) 393-3425. Refer to NPO-20509.





## Cutting Edge, Cutting Costs: Millennia.

With the latest 5 W Millennia® Spectra-Physics has significantly cut the long-term cost of ownership for this industry-leading 532 nm laser. We've not only reduced the number of pump diodes from two to one, but also redesigned these pump diodes to deliver even longer lifetime—typically exceeding 10,000 hours. That means you'll replace the diodes less often, and you'll only have one diode to replace. We've also redesigned the power supply, which now uses thermoelectric cooling for the pump diode. The result is an all solid state, rack-mountable power supply that consumes less electricity and requires less valuable floor space.



At Spectra-Physics we believe that cutting edge lasers are built on superior components, which is why we build all the critical elements of the Millennia in house—from the long lifetime ProLite™ series pump diodes to the optics and the power supply. To find out more about how Millennia can cut your overall costs, call 1-800-775-5273 today.



 **Spectra-Physics**

The Solid State Laser Company™

Call: 1-800-SPL-LASER (775-5273) Web: <http://www.spectra-physics.com> E-mail: [sales@splasers.com](mailto:sales@splasers.com)

© 2002 Spectra-Physics Lasers

For Free Info Circle No. 511 or Enter No. 511 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



# Liquid-Crystal Phase-Shifting Shearing Interferometer

**There is no need for critical alignment or focus adjustment.**

*John H. Glenn Research Center, Cleveland, Ohio*

The liquid-crystal phase-shifting shearing interferometer is a common-path interferometer based partly on a lateral-shear-plate interferometer. It bears a partial similarity to the liquid-crystal point-diffraction interferometer (LCPDI), which is also of the common-path type. The phase-shifting nature of this interferometer is expected to increase (relative to prior shearing interferometers) resolution by up to two orders of magnitude. The liquid-crystal phase-shifting shearing interferometer is expected to be useful for measuring spatially varying optical density in a laboratory or manufacturing setting; examples of such densities include the index of refraction of a liquid in a production process, the density and/or temperature of a gas in a combustion system, and the temperature of a fluid in a boiler.

The proper functioning of the LCPDI depends on focusing a laser beam onto a transparent microsphere and, hence, depends on the critical adjustment of a focusing lens by a highly trained technician. Unlike the LCPDI and many other interferometers, the liquid-crystal phase-shifting shearing interferometer can be aligned easily, with no need for critical adjustments by a highly trained technician. Moreover, elimination of the need for focusing on a microsphere also eliminates phase noise associated with inhomogeneities in a focusing lens.

In the liquid-crystal phase-shifting shearing interferometer, collimated light from a laser is incident on a shear plate oriented at an angle of 45° (see figure). Unlike a traditional shear plate, this shear plate contains a liquid-crystal layer that can be used to vary the phase of the light reflected from its rear surface. The amount of shear depends on the effective optical thickness of the shear plate, which is comparable to the

combined optical thicknesses of its glass layers. When a voltage is applied across the liquid-crystal layer, the index of refraction of the layer changes, causing the phase of the portion of the incident light reflected from the rear surface to be stepped relative to the phase of this portion when the voltage is not present. Calibration of the phase shift as a function of voltage can produce the phase steps required to implement common phases-stepping algorithms.


The amount of shear varies roughly inversely with index of refraction and thus with the phase. However, calculations for the case of a total shift of one wavelength have shown that the total shift in beam position can be safely neglected because it is more than an order of magnitude below the size of a typical pixel in a charge-coupled-device camera that would be used in implementing a practical version of this interferometer.

In a prototype of this liquid-crystal

phase-shifting shearing interferometer, the shear plate is a commercial liquid-crystal phase retarder originally intended for use as an extended-range, variable-retardance wave plate rather than an interferometer component. The manufacturer's specification for reflectance at each surface is less than half of one percent. The device would perform optimally if its front surface were coated with a partially reflective film and its rear surface with a totally reflecting film.

*This work was done by DeVon W. Griffin of Glenn Research Center. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Physical Sciences category.*

*Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-17165.*



**The Liquid-Crystal Layer in the Shear Plate is used to vary the phase of the light reflected from its rear surface.**

## Multi-Screen-Image- and Catalog-Viewing Program

*NASA's Jet Propulsion Laboratory, Pasadena, California*

A computer program enables the single- or multi-screen display of multispectral, multiresolution images — especially astronomical ones — stored as sets of data that range upward in size from hundreds of gigabytes. In cases of multi-

screen displays, the software synchronizes the screens so that they act as a single ultrahigh-resolution display. It is possible to pan and zoom smoothly to any part of the data at any resolution. The software can automatically generate composites of

multiple sets of data, making it possible, for example, to overlay high-resolution insets on background images or to display a separate source image for each video channel (red, green, or blue). The software includes special features to aid



viewing of astronomical data: these include a capability for displaying catalogs as ASCII text or as image overlays, and a catalog-to-image relational capability that enables the user do such things as select a region of the image and view those objects in the region that are highlighted in both the image and in the catalog. Alternatively, when an object in the catalog is selected, the user can see that object highlighted in the image or can jump to

the position of the object in the image.

*This program was written by Joseph Jacob of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Information Sciences category.*

*This software is available for commercial licensing. Please contact Don Hart of the California Institute of Technology at (818) 393-3425. Refer to NPO-30133.*

## Phase-Retrieval Camera for Optical Testing

**Effects of vibrations and turbulence are removed with the help of a fast shutter.**


*NASA's Jet Propulsion Laboratory, Pasadena, California*

A portable instrument denoted a phase-retrieval camera (PRC) is designed to enable the testing of large, lightweight optics in the presence of vibrations and atmospheric turbulence. The development of the PRC was prompted by the fact that conventional optical-testing techniques are not sufficiently accurate or robust for optical testing in high-vibration environments.

The PRC (see figure) includes a source module and an optics module. The source module contains laser diodes and integrated optical devices that, acting together, constitute a point source of light

of three wavelengths. The use of the three wavelengths makes it possible to measure the relative axial displacement (called "piston" in the art) of a segment of an optic under test. The optics module contains a wavefront-sensing (phase-retrieval) camera on a motorized translation stage, a reference (boresight) camera, a short-exposure (millisecond) shutter to "freeze" vibrations and turbulence, selectable calibration optics, attenuators, and other optics. A defocused image of the optic under test is formed on the focal plane of the wavefront-sensing camera.

The PRC also includes a computer



The PRC in This Example of a typical application is used to test a concave mirror.

**Get the  
right answer.**

**The first time...  
...every time**

**Photon Inc.  
your  
Beam Profiling  
Experts.**

In the R&D laboratory or on the production floor, saving time and improving yields has never been more important. Photon's profilers measure beam size and position for one or many beams, beam power and irradiance profiles — providing best focus, divergence or collimation,  $M^2$ , near-field or far-field patterns, and more. Trust the experts and get the accuracy, reliability, and repeatability you need the first time... every time.

**Learn how beam  
profiling can save  
you time and money.**

**[www.photon-inc.com](http://www.photon-inc.com)**



**PHOTON Inc.**  
Light Measurement Solutions

For Free Info Circle No. 438 or  
Enter No. 438 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



programmed with software that provides a graphical user interface, displays data, controls the operation of the instrument, enables data communication and remote control via the Internet, and performs phase-retrieval, phase-unwrapping, and calibration computations. The phase-retrieval algorithm processes multiple short-expo-

sure images from the wavefront-sensing camera and aligns them with each other by use of boresight calibration images acquired simultaneously by the reference camera. The algorithm generates data and imagery that characterize the wavefront generated by (and thus the surface figure of) the optic under test.

*This work was done by David Redding, Andrew Lowman, David Cohen, Fang Shi, and Scott Basinger of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Physical Sciences category. NPO-21217*

## Testing Grazing-Incidence Mirrors at Nearly Normal Incidence

**This system enables adequate testing in visible light, without need for a vacuum system.**

*Goddard Space Flight Center, Greenbelt, Maryland*

An optical system that utilizes visible light at nearly perpendicular incidence has been invented for use in testing the surface figures of nominally axisymmetric (paraboloidal, ellipsoidal, or conical) mirrors designed to function at grazing incidence. Such mirrors can be used as the focusing optical elements of x-ray telescopes and x-ray cameras. As explained below, the present system offers advantages over prior systems used to test such mirrors.

It is possible to test a grazing-incidence x-ray mirror by use of visible light at grazing incidence, but diffraction at visible wavelengths limits the achievable angular resolution to the order of one arc minute, whereas a resolution of 15 arc seconds or finer is typically needed for proper diagnosis of the surface figure. It is possible to test such a mirror at finer resolution by use of x rays at grazing incidence in the intended operational configuration, but testing in this way is of limited diagnostic value. Moreover, to prevent excessive absorption of x rays, x-ray testing must be performed in a vacuum chamber: this makes it difficult and time-consuming to manipulate the mirror and test equipment, thereby making testing expensive. The present system utilizes nearly perpendicular incidence to overcome the deleterious effect of diffraction, making it possible to obtain angular resolution of a few arc seconds with visible light and, hence, without need for a vacuum system.

The system (see Figure 1) includes the following components:

- A source of a parallel visible light beam of sufficient diameter,
- The nominally axisymmetric mirror under test,
- A prism that has (1) reflective conical faces with angles and diameter suitably matched to the mirror under test and (2) an axis of symmetry nominally parallel to the light beam,
- A focusing lens, and
- A screen or a charge-coupled-device video camera, located at the nominal

focal plane, that captures the image formed by the prism, the mirror under test, and the focusing lens.

The image on the focal plane consists of three components: Component 1 is nominally a point image formed by focusing of that part of the incident parallel light beam that passes directly through the lens. Component 2 is nominally a circular image formed by reflection of the incident light beam from the first conical surface of the prism, fol-




Figure 1. A Prism With Conical Reflective Surfaces, suitably dimensioned and aligned, acts in conjunction with a focusing lens and with the mirror under test to form images indicative of the surface figure of the mirror and the alignment of the mirror with respect to the prism.



# See the Possibilities.

**Imagine.** Some of the most brilliant ideas in photonics, assembled for your review. R&D by the world's leading companies in fiberoptics, imaging, transmission, and optical devices, to name a few.

Now imagine the ability to search out and obtain licensable technologies that could help your photonics project see the light of day. Save

your searches and have new technologies pushed out to you as they become available.

Got some brilliant ideas of your own? Then post the results of your own R&D labor for a chance to shine and catch the eye of someone looking to license. **Who knows the possibilities?**

$(R+D)^\infty$



yet2.com

You can also view yet2.com's Tech of the Week by logging onto [nasatechbriefs.com](http://nasatechbriefs.com)



lowed by reflection from the mirror under test, followed by reflection from the second conical surface of the prism, followed by focusing via the lens.

Component 3 nominally consists of one or more point image(s) formed by passage of part of the incident parallel beam through the central part of the prism and then through the lens. The precise nature of component 3 depends on the specific design of the entrance and exit faces of the central part of the prism: If, for example, the prism is made of optical glass with flat entrance and exit surfaces, then depending on the precision of parallelarity between these surfaces, the resulting single point image may or may not coincide with the point image of beam 1. If, for another example, the prism is made of a metal, then the central core of the prism can be drilled out and a glass refractor with, say, three facets can be inserted to refract the incident parallel beam into three detected beams that, in turn, are focused to three point images on the screen (see Figure 2). These point images, in conjunction with the component-1 point image, can be used as fiducial marks for monitoring the orientation of the prism with respect to the incident parallel beam.

Among the most important features of this system are that the parallel light beam is the sole reference for the entire

setup and the system inherently provides fiducial marks for its own alignment: The parallel light beam defines the direction of the optical axis. Once the axis of symmetry of the conical prism has been made parallel to the incident light beam and its position fixed, then the optical axis of the entire setup is fixed. The positions of the three component-3 point images with respect to the single component-1 point image serve as real-time indications of the alignment of the axis of symmetry of the prism.

When the optical axes of the conical prism and the mirror under test and the conical prism are perfectly aligned with each other, and provided that the mirror under test is perfect, then the image on the focal plane is as shown in the upper part of Figure 2. If these two optical axes do not coincide and/or if the mirror under test is not perfect, then the image becomes distorted, as shown by example in the lower part of Figure 2.

*This work was done by William W. Zhang of Goddard Space Flight Center. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Physical Sciences category. GSC-14365*




Figure 2. These Images Are Typical of a system like that of Figure 1 in which perfect optics are tested in perfect and imperfect alignment, respectively.

## Making Digital Composite Images for Technical Illustration

Drawings of facilities to be modified can be made in less time.

*John F. Kennedy Space Center, Florida*

A method of generating three-dimensional composite digital images can serve multiple purposes in technical illustration. The method was devised to accelerate and facilitate the design of new electric lights and receptacles for large buildings, and can just as well be applied to the design, redesign, and analysis of other buildings and equipment.

In the original application that motivated the development of this method, it would have taken an excessively long time to make traditional-style drawings by the traditional method, because of the complexity of the facilities. Accordingly, a major element of the method is that one makes detailed three-dimensional drawings of only those parts of the facilities and equipment that are to be modified. Data on the parts not to be modified are acquired by photographing the facilities in their present state by

use of a digital camera and, if necessary, retouching the digital photographs by use of commercial software developed for that purpose.

Computer-aided-design (CAD) software is used to generate three-dimensional computational models from the new drawing data. Materials are assigned to the surfaces of the models. The models are rotated to match the perspective and lighting of the digital photographs, and are then composed onto the photographs. If necessary, hidden-line isometric profiles are created from the three-dimensional models and rendered as details in drawings. The models are created only once and are reused in different views; they can also be reused on different projects.

This method greatly reduces the amount of time needed to make drawings for modifications of facilities. In this method, unlike in the traditional method,

little or no time is spent in research of prior drawings or in measuring dimensions. The composite images generated by this method have higher levels of detail and are easier to understand, relative to traditional drawings. An additional and unobvious advantage afforded by these images is that they can reveal conflicts in original designs of facilities and equipment. The composite images can be printed in color, generated as dozens of different file formats [including portable document format (.pdf)] that can be transmitted by electronic mail, incorporated into CAD drawings, or documents generated by word-processing software, and/or attached to MAXIMO work orders.

*This work was done by Arlene S. Reese, Thomas Bigelow, and Robert C. Kemmerling of United Space Alliance for Kennedy Space Center. KSC-12288*



# Fiber-Optic Phase-Locked Loop Sensitive to Local Strain Only

Optical fibers are made insensitive to strain except over a short sensory length.

Langley Research Center, Hampton, Virginia

The figure schematically depicts an apparatus for measuring strain at only one designated location on a structure. The apparatus is a fiber-optic phase-locked loop, wherein strain in a multimode optical fiber gives rise to a change in the phase of modulation of a laser beam that propagates along the fiber. The optical phase-locked loop makes it possible to perform sensing by use of a multimode optical fiber (in contradistinction to a single- or few-mode fiber as in some other fiber-optic sensor systems). Unlike in other fiber-optic-based sensor systems, the phase change in this system does not occur in response to strain integrated along the entire fiber-optic path. Instead, this system includes lead-in and lead-out strain-insensitive lengths of optical fiber connected to a short strain-sensitive length of optical fiber that is affixed to the structure at the desired measurement location. Strain in the short sensory length produces a phase change, but strain in the lead-in and lead-out portions does not.

The output of a voltage-controlled oscillator (VCO) is used to modulate the laser light and to supply a reference signal to a double balanced

mixer. After traveling along the strain-insensitive and strain-sensitive lengths of optical fiber, the modulated laser signal impinges on a photodetector, the output of which is amplified and mixed with the reference signal. A filter removes the radio-frequency component of the mixer output, passing only the DC or low-frequency component, which component constitutes a DC error voltage. The phases of the fiber-optic-propagated and reference signals are maintained at quadrature by feedback of the DC error voltage to the VCO. A change (caused by strain) in the phase of the modulation manifests itself as an error voltage and, by virtue of the feedback, is compensated by a change in the modulation frequency. The frequency is monitored by a counter.

A multimode optical fiber can be made more or less sensitive to strain through selection of the fiber core and cladding materials. Assuming that the fiber can be approximated as weakly guiding (meaning, essentially, that the index of refraction of the core exceeds that of the cladding by an amount  $\ll 1$ ), it can be shown that the condition for complete insensitivity to strain

(zero phase shift in response to strain) is given by

$$n_{\text{core}} = (2/P_{\text{eff}})^{1/2},$$

where  $n_{\text{core}}$  is the index of refraction,


$$P_{\text{eff}} = [P_{12} - \nu_f(P_{11} - P_{12})]/2,$$

$\nu_f$  is the Poisson's ratio of the fiber, and  $P_{11}$  and  $P_{12}$  are the strain-optic coefficients of the fiber.

The insertion of appropriate parameters in these equations leads to the conclusion that a strain-insensitive optical fiber is one in which the core has a very high index of refraction (4.5 is an approximate representative value). Germanium is one example of a material suitable for a multimode optical fiber with a very high index of refraction.

This work was done by Claudio O. Egeon and Robert S. Rogowski of Langley Research Center. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Electronic Components and Systems category.

This invention has been patented by NASA (U.S. Patent No. 5,780,844). Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to Rheel Turcotte, Technology Commercialization Program Office, NASA Langley Research Center at (757) 864-8881 or e-mail at [r.p.turcotte@larc.nasa.gov](mailto:r.p.turcotte@larc.nasa.gov). Refer to LAR-15159.



The Frequency of the VCO in this optical phase-locked loop changes in response to strain in the short sensory length of optical fiber. Strain in the lead-in and lead-out lengths of fiber does not cause the frequency to change.



# PRODUCT GUIDE: OPTICAL TIME DOMAIN REFLECTOMETERS

**W**ith the Internet, Ethernet, and metropolitan area networks (MANs) again beginning to put pressure on the installed capacity of fiber optics, the importance of test instrumentation cannot be overstated. That's where the optical time domain reflectometer (OTDR) comes in. It is the premier instrument in testing a fiber optic link, for several reasons, first and foremost its ability to perform and store multiple tests. Such measurements as splice and connector location, fiber attenuation across the link, reflectance, and fiber length and break location can all be determined with an OTDR. If the user is interested in attenuation of the signal through the fiber's length, he can obtain only the total of the loss with an optical power meter. But the OTDR will give him an event map on a monitor, showing the attenuation across the whole fiber span, as well as indicating signal level versus distance, the location of any fusion splices or bend loss and of any breaks in the fiber.

## AGILENT TECHNOLOGIES

[www.agilent.com](http://www.agilent.com)

**A**gilent's flagship OTDR is the series E6000-B mini-OTDRs for single-mode networks. Two in the series are designed for 1310-nm single-mode fiber, and three others for 1310 and 1550 nm. Dynamic range varies, from 28 dB to 45 dB (1310). A fiber break locator looks exclusively for breaks, which are displayed quickly. The E6000B combines 16,000 data points with a minimum sample spacing of 8 cm. The E6010B is aimed at testing at 1625 nm, with a dynamic range of 40 dB, and can be used to test the optical supervisory channel capability of WDM links. A series of modules enables the basic design to cover the wavelengths 850 nm and 1300 nm. Out-of-band testing also allows users to do a fiber test while transmitting data at 1310 or 1550 nm. The series comes in 10 standard models.

❖ The series of rack OTDRs—the E6053A, E6058A, and E6060A—based on the design of the E6000B—can be built into a system and controlled remotely by a PC. Dynamic range varies from 34 dB (1550) to 40 dB (1310). When used with an optical switch and a PC, these instruments can be used for commissioning and monitoring a fiber optic link automatically. With a keyboard and a VGA monitor, these devices can serve as standalone mini-OTDRs.

❖ The 8147 is designed for installation, commissioning and bench applications. Its "Easy Mode" feature lets the user preprogram complete procedures, so that with just a few key-

strokes, he gets standardized measurements. Extended in-depth analysis, including two-way measurements, delta measurements, and comparison of up to four traces, is available on-line. A return loss graph permits the user to see the reflectance of individual events at a glance, as well as the total return loss of the link. The 8147 series comes in 11 standard versions, with dynamic ranges spanning from 30 dB (1310) to 45 dB (1550).

❖ The E6091A OTDR Toolkit II is described by Agilent as ideal for post-processing, analyzing, and batch processing Bellcore GR-196 based OTDR files. Systems employing the E6091 software can transfer data serially to a PC running Windows 95, 98, or Windows NT. The data can be saved for use in a spreadsheet or database. Other features include comparison of up to four traces simultaneously; Trace Manager, to enable high-speed multiple trace transfer between the OTDR and PC; and two-way averaging for accurate loss calculations.

## EXFO

[www.exfo.com](http://www.exfo.com)

**E**xfo says that its FTB-7000B series has more than 20 models, with instruments suitable for the shorter distances of local area networks (LAN) and metropolitan area networks (MAN) as well as the greater distances in long-haul networks. The company claims links exceeding 200 km can be characterized using the 45-dB dynamic range model. Single-mode modules are available at

Another factor that sets the OTDR apart is that, because its principle is like that of a radar and the transmitter and receiver are on the same instrument, the user needs access to just one end of a fiber to test a link. Most manufacturers, however, recommend that the testing be done from both ends if both are available. Exfo, for one, notes that bidirectional OTDR averaging is essential for users who must do extensive fiber link commissioning and documentation, as well as for those who are sensitive to their cable plant loss budgets.

The basic components of an OTDR include a light source, pulse generator, coupler, detector, A/D converter, and controller, in addition to software. The source emits pulses of light that are directed through the coupler into the fiber under test. The pulses are averaged and the fiber characterized. Most manufacturers offer one or more "mini-OTDRs," handheld or relatively compact instruments that can be taken into the field.



EXFO's FTB-400 Universal Test System

1310 nm, 1410 nm, 1550 nm, and 1625 nm, and multimode at 850 nm and 1300 nm. A Visual Fault Locator option gives the user troubleshooting capability in LAN/WAN and metropolitan networks.

❖ Exfo recommends its FTB-9000 optical switch module combined with the FTB-7000 OTDR for batch fiber testing in patch panels or bare ribbon testing during installation. Dynamic ranges go from 31 dB to 42 dB. The company offers complete OTDR testing kits, including multifiber, ribbonized, and bare ribbon configurations. For unconventional wavelength windows, the company's 1625-nm module can characterize L-band systems, and the 1400-nm module can be used with the new fiber that has no water-peak attenuation.

❖ The ToolBox software in the FTB-7000B module has two modes: auto





# SENSORS EXPO<sup>®</sup> & CONFERENCE

May 20-23, 2002 Conference  
May 21-23, 2002 Exhibits  
San Jose Convention Center  
San Jose, CA

**FREE Exhibit Hall  
Admission**

Register today at  
[www.sensorexpo.com](http://www.sensorexpo.com)



## Discover —

- Ways to shorten your time to market
- How to increase your competitive advantage
- Emerging technologies and how to use them

## Plus!

Special keynote address by Paul Saffo—  
Sensors Are Only Half the Revolution. . .  
Tuesday, May 21, 2002.



FREE networking reception and exhibit hall admission when you register before April 22, 2002 (\$65 value) at  
[www.sensorexpo.com](http://www.sensorexpo.com) or by calling 800-331-5706 (or 218-723-9130), M-F 8 a.m. - 7 p.m. CST



mode and advanced mode. The first has preset test parameters and a choice of single- or dual-wavelength OTDR testing. The second allows the user to manually set all acquisition parameters, including index of refraction and helix factor.

- ❖ The FTB-100B mini-OTDR has an internal memory of 70 traces, and additional storage capacity of up to 6000 traces. The module is available at four wavelengths: 1310 nm, 1410 nm, 1550 nm, and 1625 nm. Dynamic ranges to up to 45 dB. It contains an InGaAs detector power meter that can measure in dB, dBm, and watts. The trace has 52,000 data points, and a sampling resolution down to 8 cm.
- ❖ Exfo's FTB-400 Universal Test System comes in two configurations: a two-slot OTDR and loss testing combination that has more than 500 OTDR and loss capabilities, and a seven-slot configuration that has more than 1000 testing combinations, including polarization mode dispersion, DWDM modules, ribbon test kits, switches for high-fiber-count testing, and OTDR and loss testing. It has more than 20 OTDR modules, mated to four single-mode and two multimode wavelengths.

**TEKTRONIX**  
www.tektronix.com

**T**ektronix calls its line of mini-OTDRs its "next-generation entry" into long-haul fiber installations of 300 km and up, but says it also addresses short- and mid-range fiber optic networks. The line, called NetTek™ OTDR, combines OTDRs and optical power meter modules with the NetTek Analyzer, the control and display platform that houses these modules. There are nine OTDR modules, with wavelengths ranging from 850/1300 nm to 1550/1625 nm, and dynamic range from 34 dB to 44 dB.

- ❖ Tektronix says that the OTDRs address virtually every prevailing mode, wavelength, and fiber optic network, and both in-band and out-of-band measurements. The NetTek platform simultaneously accepts up to four OTDRs plus an optical power meter. The platform is designed to accommodate an expanding line of measurement modules, including the YBT250, used for Base Station testing, and others currently in development.
- ❖ The NetTek platform has standard internal memory of 7 MB available for storage and running WinCe applications. A floppy disk and a 128-MB memory card are optional. A port supports standard PCMCIA memory



Tektronix's NetTek mini-OTDR

cards. Display range is 0 to 320 km for single-mode fiber and 0 to 32 for multimode. The OTDRs can operate with pulse widths from 10 nanoseconds to 20 microseconds. Thirty-two thousand measurement points is standard.

- ❖ NetTek OTDR modules use Tektronix's IntelliTrace Plus technology, which automatically optimizes test parameters so the user does not have to.

**FOTEC**  
www.fotec.com

**F**otec says that its Fiber U OTDR converts any Windows PC into a full-function optical time domain reflectometer. It consists of a mainframe and separate optical plug-in units for measuring characteristics of either single-mode or multimode fiber. Dynamic ranges are 25 dB for the 850/1300-nm multimode devices and 28/27 dB for the 1310/1550-nm single-mode devices and the combination multimode/single-mode device. Fotec says the unit can be ordered in a field kit with carrying case and launch cable. It can read from 2 to 180 kilometers, and display 8 traces simultaneously.

**NOYES**  
www.noyes-fiber.com

**N**oyes's M600 line of mini-OTDRs has user-installable modules for testing multimode (850/1300 nm) and single-mode (1310/1550 nm) fiber links. For the multimode M600-K-MM1-xx dynamic range is 21/23 dB; for the single-mode M600-K-SM1-yy it is 26 dB; for the multimode/single-mode M600-QUAD-xx-yy it is 21 dB (850 nm), 23 (1300 nm), 26 (1310 nm), and 26 (1550 nm).

- ❖ The standard mainframe includes a

color LCD display, a floppy disk drive, and nonvolatile memory that can store up to 50 traces. The software supports trace manipulations such as two-way averaging, trace overlay, graphing, and batch printing. Pulswidth and range can be set automatically or manually for maximum flexibility. The M600 can automatically increment and include a fiber number in each file name to speed up identification.

**ANDO**  
www.ando.com

**A**ndo's AQ7250 mini-OTDR is described by the company as offering a range of functions and capabilities ideal for field use. The single-mode unit's wide dynamic range of 41.5 dB (1310 nm) and 39.5 dB (1550 nm) enables measurement of cables over extra-long distances, the company says, and its high measuring speed means that it can measure a splice loss of 0.5 dB from 70 km away in just 20 seconds. The screen updates a minimum of twice per second in preview mode, allowing real time checking of changes in the state of optical fibers in less than a second. On batteries the AQ7250 has an operational life of about eight hours under normal service conditions, so the user can get a full day's work on one charge.



Ando's AQ7250 mini-OTDR

Automatic detection of splice losses, return losses, and other items exceeding preset levels is possible. When calculations are complete, the list screen is displayed, enabling the user to view distances to splice points, splice loss, return loss, and total losses, and other items at a glance.

- ❖ Ando also offers the AQ7410 and AQ7410B reflectometers for measuring high-resolution return loss distribution of waveguides and optical modules. Using a wavelength-tunable narrow-band light source unit, it is possible to obtain optical loss distributions of waveguides and optical modules by observing Rayleigh backscattered light.



# There Are So Many Reasons To Attend

## 2002 CLEO/QELS

CONFERENCE ON LASERS AND ELECTRO-OPTICS

QUANTUM ELECTRONICS & LASER SCIENCE CONFERENCE

**LONG BEACH CONVENTION CENTER, LONG BEACH, CALIFORNIA  
MAY 19-24, 2002**

### **SHORT COURSES**

- Choose from over 50 courses — customize your curriculum to best suit your needs.

### **LASERS AND ELECTRO-OPTICS APPLICATIONS PROGRAM (LEAP)**

- Always a highlight of CLEO, these complimentary sessions feature the leading experts and cutting edge topics the whole industry is watching.

### **LAUNCH PAD**

- Special pavilion on the show floor provides the perfect venue to introduce your company to the industry.

### **HANDS-ON WORKSHOP**

- Ideal forum for interactive demonstrations and discussions with leading companies.

### **EXHIBITS**

- More than 300 exhibitors showcasing the latest technology and applications.

#### **CONFERENCE INFORMATION:**

Phone (202) 416-1907 • Fax (202) 416-6140 • Email [custserv@osa.org](mailto:custserv@osa.org)

#### **EXHIBIT INFORMATION:**

Phone (202) 416-1995 • Fax (202) 416-6100 • Email [cleoexhibits@osa.org](mailto:cleoexhibits@osa.org)

Sponsored by:



[www.cleoconference.org](http://www.cleoconference.org)



## UV-SCOPE THE ULTRA VIOLET FIND-R-SCOPE



**VERSATILE**  
**SENSITIVITY 180nm-1250nm**  
**(OPTIONAL TO 1550nm)**  
**LIGHTWEIGHT, SIMPLE TO OPERATE**  
**RUNS ON ONE "C"-CELL BATTERY**  
**AVAILABLE WITH EITHER:**

- 3 ELEMENT UV GRADE FUSED SILICA FJW UVITAR OR
  - 5 ELEMENT UV GRADE SILICA AND CALCIUM FLUORIDE FJW UVAGON ACHROMAT
- APPROPRIATE BANDPASS & BLOCK FILTERS AVAILABLE**  
**1/4-20 SOCKET FOR TRIPOD OR TABLE TOP MOUNTING**  
**FULL OR MOMENTARY OPERATION**

FJW OPTICAL SYSTEMS, INC. 629 S. VERMONT ST., PALATINE IL 60067

**847-358-2500 FAX: 847-358-2533**  
INTERNET: [www.findscope.com](http://www.findscope.com) e-mail: [fjwopt@concentric.net](mailto:fjwopt@concentric.net)

For Free Info Circle No. 452 or  
visit [www.nasatech.com/452](http://www.nasatech.com/452)

## From the publishers of NASA Tech Briefs New in the NTB Store

### Kid's Aviator Flight Jacket



Made to military specifications, this MA-1 flight jacket looks and feels like the real thing, with high-quality authentic aviation patches. \$49.95

### Astronaut Flight Jacket

Authentic polycotton twill jacket features U.S. flag and NASA logo patches, aviator collar, and protective inner lining. \$99.95



### Space Shuttle Thermal Tile




A unique educational item and a must for collectors! Actual piece of protective tile made for Columbia — the first space shuttle. Packaged in a clear display box, with certificate of authenticity. \$15.95

**Order online at**  
**[www.nasatech.com/store](http://www.nasatech.com/store)**

# New Products

## PRODUCT OF THE MONTH



### Fiber Bragg Grating Write Optics


Alpine Research Optics, Boulder, CO, introduces a series of optical components intended for fiber Bragg grating (FBG) writing applications with excimer, ion, or solid-state lasers. The product line encompasses mirrors, beamsplitters, and spherical and cylindrical lenses. Offered, with the beamsplitters, in 1-in. and 2-in. diameters, the mirrors nominally provide reflectivity of greater than 99.5 percent at 244 nm, 266 nm, or 248 nm and greater than 96 percent at 193 nm, at either 0- or 45-degree angle of incidence. The lenses come in sizes of up to 75 mm with radii of curvature between 0.05 and 10 meters and antireflection coatings for the same wavelengths.

For Free Info Circle No. 730 or Enter No. 730 at [www.nasatech.com/rs](http://www.nasatech.com/rs)

## Liquid Crystal Polarimeter

Meadowlark Optics, Frederick, CO, offers a compact liquid crystal polarimeter that, with no moving parts, measures the state and degree of polarization on an incident beam. The polarimeter uses Meadowlark's proprietary Versalight technology. Available in both free-space and optical-fiber versions, it has accuracy to 1 percent, according to the company. The two versions of the polarimeter cover the entire spectrum, from visible to near-IR (400-1100 nm) and into the IR (1100-2200 nm). The accompanying software displays the polarization state as a Stokes parameter, a vector on a Poincaré sphere, and a polarization ellipse.

For Free Info Circle No. 731 or Enter No. 731 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## Compact Lead Screw Positioners




From Del-Tron Precision, Bethel, CT, come new compact lead screw positioners, which the company calls the smallest-ever member of the company's Posi-Drive line of stages. Their height is 1.250 in. and their width 1.380 in. Del-Tron says the stages provide the same 0.0001-in. straight-line accuracy per inch of travel and 0.0001-in. repeatability as the existing Posi-Drive line. The stages have a 0.125-in. diameter lead screw, an anti-backlash nut, and a flexible zero-backlash coupling that accepts a NEMA 14 motor. They provide a load-bearing capacity of up to 40 lb. Available in travel lengths from 1 in. to 4 in., the positioners can have either linear ball or crossed roller slides.

For Free Info Circle No. 734 or Enter No. 734 at [www.nasatech.com/rs](http://www.nasatech.com/rs)

## Stray Light Analysis Software

Stellar Optics Research International, Thornhill, Canada, introduces SOLEXIS™ software Version 2.1.2 for stray light analysis in ground- and space-based applications. The software can perform optical design and materials selection in development of systems for which optical, thermal, stray light, and scatter performance is critical, including cameras, scanners, telescopes, and so forth. Scatter data is bidirectional reflectance and transmittance distribution function data (BDRF and BTDF) essential to improve image quality, spot size, contrast, signal-to-noise ratio, ghosting, and sharpness. TracePro® and ASAP™ both accept scatter data from SOLEXIS.

For Free Info Circle No. 738 or Enter No. 738 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## Spectroscopic Detectors with High Speed

Roper Scientific, Trenton, NJ, offers its Princeton Instruments family of Spec-10® detectors for spectroscopy in speeds of 2 MHz and 50 kHz in addition to 100 kHz and 1 MHz. The company says that the 50-kHz speed lowers the read noise for several of the models to less than 3 electrons per pixel per second, and is intended for applications such as high-sensitivity Raman and fluorescence spectroscopy. The 2-MHz setting delivers faster spectral acquisition and is useful for pump-probe methods and high-repetition-rate experiments. Spec-10 systems can be configured with a number of exclusive front- and back-illuminated CCDs.



For Free Info Circle No. 739 or Enter No. 739 at [www.nasatech.com/rs](http://www.nasatech.com/rs)





## Nanoelectronic Devices With Precise Atomic-Scale Structures

Field-effect transistors with nanometer dimensions are under development.

*Ames Research Center, Moffett Field, California*

Since its invention in 1948, the transistor has revolutionized everyday life. The electronics revolution is based on miniaturization of transistors; smaller transistors are faster, and denser circuitry has more functionality. Transistors in the present generation of integrated-circuit chips have sizes of  $\approx 0.18 \mu\text{m}$ , and the electronics industry has completed development of  $0.13\text{-}\mu\text{m}$  transistors, which will enter production within the next few years. Industry researchers are now working to reduce transistor sizes below  $0.1 \mu\text{m}$  — a thousandth of the width of a human hair. However, studies indicate that the miniaturization of silicon transistors will soon reach its limit.

For further progress in microelectronics, it is necessary to turn to nanotechnology. Rather than continuing to miniaturize transistors to a point where they become unreliable, nanotechnology offers the new approach of building devices on the atomic scale. One vision for the next generation of miniature electronic circuitry is that of atomic-chain electronics; according to this vision, each device is composed of atoms aligned on top of a substrate surface in a regular pattern. The Atomic Chain Electronics Project (ACEP) — part of a nanotechnology group at Ames Research Center — has been developing the theory for understanding atomic-chain devices, and a patent for atomic-chain electronics has been filed and is now pending.

The use of dopants is critical to the functionality of transistors. Dopants are impurities intentionally added to the semiconducting tran-

sistor channel to raise or lower the device switch-on voltage. Typically, a macroscopic transistor (one with a size of the order of  $10^{-6}$  m) contains several thousand dopant atoms that, on the scale of the overall device, appear to be smeared out as a dopant "jelly," as illustrated in the top part of Figure 1. Because of the large number of dopant atoms, the precise location of each dopant atom is not

very important to the functioning of the transistor. However, when the size of a transistor is reduced to the range of  $10^{-8}$  to  $10^{-7}$  m, as illustrated in the middle part of Figure 1, the number of dopant atoms is less than about 100, in which case the position of each dopant atom does matter. Current manufacturing techniques do not provide the means to control the locations of the few dopant

atoms precisely, and as a result, small variations in functioning occur among transistors. Such variations are fatal when millions or billions of transistors are integrated in a computer chip, because the variations can cascade from one device to the next, eventually giving rise to a malfunction. A solution of this aspect of the miniaturization problem, devised by the ACEP, is to create all the device structures with atomic chains laid out in a regular precise pattern by anchoring atoms to a substrate, as illustrated in the bottom part of Figure 1.

A second critical aspect of the functioning of a transistor is gain: the output of the transistor should be a magnified version of its input. ACEP research has led to the conclusion that in designing atomic-chain transistors to produce gain, one should exploit the field effect, which is the only mechanism verified experimentally so far at the atomic scale. Semiconductors conduct current only when a gate voltage is (is not) applied — field effect. Metals always conduct current. A field-effect transistor uses a semiconductor for the channel




Figure 1. Transistors Have Been Miniaturized, starting from the macroscopic scale, where thousands of dopant atoms can be regarded as being in a smooth distribution that determines the switch-on voltage. At the mesoscopic scale, transistors have different switch-on voltages, depending on precisely where the dopant atoms are located. To prevent such unit-to-unit variations, the next step in miniaturization will not be accomplished by making conventional transistors smaller; instead, transistors with dimensions  $<1$  nm will be made from chains of precisely positioned atoms.



and a metal for electrodes, and this is how it achieves large gain. Thus, it is necessary to devise chains with semiconductor and metal properties. First, the ACEP team tackled a simple problem theoretically: If one can arrange silicon atoms along a line floating in air, is this chain semiconducting? The answer is surprising: although bulk or thin-film silicon is semiconducting, an isolated chain of silicon atoms is always metallic.

Fortunately, ACEP research also leads to the finding that a magnesium chain is semiconducting, even though bulk magnesium is metallic.

Of course, it is not possible to float atoms in air: it is necessary to place them on top of a substrate. Surface atoms of the substrate attract atoms in the chain and hold them at fixed positions. The surface of a substrate can be made to have atomic-scale corrugations, and these can be used to create a precise pattern for atomic-chain electronics. However, the attractive force between the substrate and chain atoms that are simply placed in the corrugations is too weak to secure atoms reliably. ACEP research has led to the conclusion that a chemical bonding scheme is needed to secure chain atoms reliably, and to the further conclusion that the properties of a chain are strongly influenced by the substrate material and surface orientation when chemical bonding is used. Indeed, the same atomic chain can be either metallic

or semiconducting, depending on the number of chemical bonds between a chain atom and the substrate atoms.

A further concern is that electrons traveling along an atomic chain can detour into the substrate through chemical bonds and possibly leave through a neighboring chain, resulting in the short-circuiting of two atomic chains. Such short circuits are fatal for elec-

tronic applications and must be avoided. ACEP research has clarified the conditions under which the substrate surface can be made electrically insulating in a chemical-bonding scheme. Among the findings of this research are that silicon and germanium crystals can be good insulating substrates.

Thus far, the ACEP team has made the first step toward the development of

atomic-chain electronic devices. On top of a silicon substrate, it is possible to attach germanium atoms with two chemical bonds each, as shown in Figure 2. The resulting structure is a semiconducting chain on an insulating substrate. Nearby chemical bonds on the substrate are saturated with hydrogen atoms, so that they are electronically inactive. Such a chain can be a component of a field-effect transistor on an atomic scale.

*This work was done by Toshishige Yamada of Computer Sciences Corp. for Ames Research Center. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Electronic Components and Systems category.*

*This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Ames Research Center, (650) 604-5104. Refer to ARC-14246.*




Figure 2. A Semiconducting Chain of Germanium Atoms electrically insulated from other atoms present is formed on top of a (100) silicon substrate, the unused regions of which are hydrogenated.

## Mounting Flip Chips on Heat-Dissipating, Matched-CTE Boards

Integrated-circuit chips can run cooler, and solder joints are less likely to fail.

John H. Glenn Research Center, Cleveland, Ohio

"Flip chip on board (FCOB) with high thermal conductivity and tailored coefficient of thermal expansion (CTE)" denotes a developmental concept for relatively inexpensive, lightweight packaging of electronic circuits to accommodate high densities of components and of interconnections. The concept addresses several issues that

pertain to flip-chip performance and reliability and to the integration of flip chips with other components: These issues include minimization of undesired mismatches of CTEs between flip chips and printed-wiring boards (PWBs), removal of heat from high-power flip chips, and the need to maximize stiffness while minimizing weight.

Usually, a conventional PWB is made of an epoxy-matrix/glass-fiber laminate, called "FR-4," with copper surface layers that can be etched to form signal and power conductors. A PWB of the present developmental type includes a core layer that contains a carbon cloth, sandwiched between FR-4 outer layers. Typically, the thickness of the carbon-



A true pioneer  
in data acquisition  
wouldn't offer you  
just one choice.



The simple fact is that no single solution—be it plug-in or instrument based—is right for every application. That's why Keithley offers both. And we're the only company that does, which means you can trust us to be completely objective about which solution is right for you. What's more, every solution we offer is as reliable and accurate as they come. After all, we helped

pioneer this industry over 50 years ago. So if you're looking for someone to shed a little objective light on your data acquisition problems, log on to [keithley.com/dac](http://keithley.com/dac) and download your **FREE StraightStuff Data Acquisition Kit**. It's the first step toward making buying decisions based on what's right for your application. Isn't choice a wonderful thing?

Learn more at 1.888.KEITHLEY or [www.keithley.com](http://www.keithley.com)

**KEITHLEY**

A GREATER MEASURE OF CONFIDENCE

For Free Info Circle No. 509 or Enter No. 509 at [www.pasatech.com/cr](http://www.pasatech.com/cr)




cloth layer is about one-third the overall thickness of the laminate.

Carbon cloth is used in the core layer because it has several properties that are desirable with respect to the issues mentioned above. These properties include the high thermal conductivity of carbon fibers (up to 1,100 W/m-K), low CTE [ $<10^{-6}$  ( $^{\circ}\text{C}$ ) $^{-1}$  in some cases], low mass density [ $\approx 0.07$  lb/in. $^3$  (1.9 kg/m $^3$ ) for carbon versus  $\approx 0.1$  lb/in. $^3$  (2.8 kg/m $^3$ ) for aluminum], and high stiffness [up to  $\approx 42$  Mpsi ( $\approx 290$  GPa) for carbon versus  $\approx 10$  Mpsi ( $\approx 69$  GPa) for aluminum].

The use of a carbon-fiber core layer to increase the thermal conductance of a PWB and thus the ability of the PWB to dissipate heat offers two benefits. One benefit is higher reliability: It has been estimated that in many cases, lowering the temperature of operation of electronic components by 10  $^{\circ}\text{C}$  approximately doubles the mean time between failures of the components. The other benefit is that lower operating temperatures enable components (especially data processors) to function at greater speeds and efficiencies.

Thus far, thermal testing of specimens and finite-element modeling of carbon-fiber-core FCOBs have shown the potential for matching of CTEs and lowering operating temperatures of components. In one example in the temperature analysis (see figure), the peak temperature under a flip chip was estimated to be  $\approx 277$   $^{\circ}\text{F}$  ( $\approx 136$   $^{\circ}\text{C}$ ) on a conventional FR-4 PWB but only  $\approx 129$   $^{\circ}\text{F}$  ( $\approx 54$   $^{\circ}\text{C}$ ) on a carbon-fiber-core PWB.

In one example in the CTE-mismatch analysis, the effective CTE of the region of a carbon-fiber-core where flip chips would be mounted was found to be  $\approx 1.0 \times 10^{-5}$  ( $^{\circ}\text{C}$ ) $^{-1}$ ; in contrast, the corresponding CTE of a conventional FR-4 PWB was found to be  $\approx 2.1 \times 10^{-5}$  ( $^{\circ}\text{C}$ ) $^{-1}$ . Thus, the carbon-fiber core exhibits less CTE mismatch with the chip substrate material — silicon — for which the CTE ranges from  $3 \times 10^{-6}$  to  $5 \times 10^{-6}$  ( $^{\circ}\text{C}$ ) $^{-1}$ . Ultrasonic imaging of carbon-fiber-core FCOB specimens after thermal tests of



These Temperature Maps were computed in a finite-element simulation of thermal conditions on a PWB on which four heat-generating flip chips are mounted. For each of the two cases shown here, the peak temperature mentioned in the text was calculated as an average over all nodal values within the "footprints" of the flip chips.

the specimens revealed that the thermal tests did not result in any detectable increase in the incidence of failures of flip-chip-mounting solder joints.

This work was done by Eyan Lee and William E. Davis of Applied Material Technologies, Inc., for Glenn Research Center.

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16890.

## Lightweight, Dimensionally Stable Printed-Wiring Boards

In comparison with traditional PWBs, these offer better heat dissipation and CTE matching.

John H. Glenn Research Center, Cleveland, Ohio

Printed-wiring boards (PWBs) that are especially suitable as substrates for highly reliable, lightweight electronic circuits for aircraft and spacecraft have been developed. Like traditional

PWBs, these PWBs are laminated composites that include dielectric inner layers plus copper outer layers that can be etched to form signal and power conductors. Going beyond the designs

of traditional PWBs, these PWBs include multiple copper layers separated by dielectric (e.g., polyimide) layers, plus inner cores that contain carbon cloth.

(Continued on pg. 48)



# Slow the Motion...



## ...Solve the Problem!

### New *MotionPro*™ High-Speed CMOS Digital Imaging System Sets New Standards from Laboratories to Production Lines



*MotionPro* is more than the world's premiere PCI-based high-speed CMOS digital camera. It's a complete system for capturing high-speed events and delivering outstanding digital images directly into a PC for "slow-motion" analysis and documentation. And it sets new price performance standards for both laboratory and production line diagnostic applications.

*MotionPro* includes:

- High-speed, compact, mega-pixel CMOS camera head.
- PCI camera control and memory board, with up to 9.8 seconds of record time at 500 full-resolution frames per second.
- Intuitive, easy-to-use Windows-based control software.
- Motion analysis software.
- Optional video image synchronization with up to 64 channels of external sensor data.

*MotionPro* delivers full frame color or monochrome resolution of 1280 x 1024 pixels. Up to four *MotionPro* systems can operate from a single PC for multiple synchronous "slow-motion" views of an event. Three models [with recording speeds up to 500, 2,000 and 10,000 frames per second] let you choose the right system for today, and easily upgrade later if necessary.

Comprehensive integrated solutions – including *MotionPro*, computer, software and instrumentation accessories – are available.

See how to **slow the motion** and **solve the problem** with *MotionPro* by contacting Redlake MASD, Inc. at your choice of the following:

Phone: 1-800-462-4307 or 1-858-481-8182

Fax: 1-858-792-3179

E-mail: [sales@redlake.com](mailto:sales@redlake.com)

Website: [www.redlake.com](http://www.redlake.com)



## REDLAKE®





These PWBs are intended to accommodate high densities of electronic components and of interconnections among them. The designs of these PWBs can be optimized to satisfy several requirements, including removal of heat generated in electronic components, maximization of stiffness with minimization of weight, and minimization of mismatches between the coefficients of thermal expansion (CTEs) of the PWBs and the components (e.g., leadless chip carriers) mounted on them. Previous solutions to the heat-dissipation and CTE problems have included the use of copper/Invar/copper (CIC) cores. While CIC cores contribute to reduced CTEs and increased thermal conductivities, they also contribute to increases in weights and costs.


Carbon cloth is used in the core layers of the present PWBs because it affords a combination of

properties (low CTE, high thermal conductivity, low mass density, and high stiffness) that help to satisfy the requirements mentioned above. [The use of carbon cloth in the core layers of PWBs for this reason is reported in the preceding arti-

cle, "Mounting Flip Chips on Heat-Dissipating, Matched-CTE Boards" (LEW-16890).] The present carbon-core PWBs offer the advantages, but not the disadvantages, of PWBs with CIC cores; that is, unlike those with CIC cores, these are lightweight and relatively inexpensive. Because of its superior heat-dissipating and CTE characteristics, a PWB of this type (see figure) can accommodate about 40 percent more electronic components than can a traditional PWB.


*This work was done by Richard A. Bohner and William E. Davis of Applied Materials and Technologies, Inc., for Glenn Research Center.*

*Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16648.*



This PWB Contains a Carbon-Cloth Core and a total of eight copper layers. The overall dimensions of the board are approximately 3.25 by 4.25 in. (about 8.3 by 10.8 cm).

There's always something new at Photron.



## Introducing the FASTCAM-X 1280 PCI.

Now you can easily install megapixel high-speed video into one slot on your PC. The 1280 digital imaging system includes: ♦ Latest CMOS sensor technology ♦ PanelLink™ digital output for real-time image transfer to frame grabber ♦ Photron Motion Tools software ♦ Electronic global shutter to 7.8 μs ♦ Up to 16,000 fps ♦ Run up to four cameras from one PC ♦ And much more...

Photron proudly offers the smartest, fastest, largest line of high-speed video systems in the industry.

**High-speed, high-resolution, and high-G video systems.** Known for years as the designer and manufacturer of Kodak 4540 and Motion Corder systems, as well as our own FASTCAM and ULTIMA systems, Photron has an impressive history of imaging technology leadership. Now we want everyone to know about the most extensive product line of digital video systems available.

**Leadership through innovation.** We are constantly expanding our product offering, and have several more exciting developments coming soon. Get to know the leader. Get to know Photron.

**PHOTRON™**

Photron USA, Inc. [www.fastcam.info](http://www.fastcam.info) 800-585-2129



## What threatens your high speed PCB design?

As clock speeds approach 1 GHz even the simplest passive elements cause propagation delay, cross talk, and ground bounce. Eliminate glitches, resets, and logic errors by simulating entire signal paths.

Rely on Ansoft's high performance EDA solutions for your signal integrity and EMI needs.

Contact us for a free evaluation at  
412-261-3200 or [info@ansoft.com](mailto:info@ansoft.com).

**For Free Info Circle No. 566 or  
Visit [www.nasatech.com/566](http://www.nasatech.com/566)**



*Unmatched speed and accuracy in parasitic extraction and signal integrity simulation.*

# Eradicate



  
**ANSOFT**

[www.ansoft.com](http://www.ansoft.com)





## Protective Solid Electrolyte Films for Thin Li-Ion Cells

These films would simplify fabrication and afford greater flexibility in design.

NASA's Jet Propulsion Laboratory, Pasadena, California

Thin films of  $\text{Li}_2\text{CO}_3$  are under consideration for use as passivating layers between electrodes and solid electrolytes in advanced thin-film lithium-ion electrochemical cells. By suppressing undesired chemical reactions as described below, the  $\text{Li}_2\text{CO}_3$  films could help to prolong the shelf lives, increase the specific energies, and simplify the fabrication of the cells. Batteries comprising one or more cells of this type could be used as sources of power in such miniature electronic circuits as those in "smart" cards, implantable electronic medical devices, sensors, portable communication devices, and hand-held computers.

The need for passivation arises as follows:

- A state-of-the-art thin-film Li-ion cell typically consists of a lithium metal anode, a glassy solid electrolyte, and a cathode made of a lithiated transition-metal oxide (e.g.,  $\text{LiCoO}_2$ ). The Li anode and most solid electrolytes are very sensitive to humidity. To prevent destruction of the anode and solid-electrolyte films by reactions with airborne moisture, it is necessary to adhere to strict handling procedures during fabrication; in particular, the electrode and electrolyte films must be handled in a glove box. As a consequence, the overall process of fabrication of thin-film Li-ion cells and batteries is more complex than it would otherwise be.
- Many solid electrolytes are not chemically or electrochemically stable when in contact with Li or when exposed to high charging potentials. Intermediate passivating films that could protect such solid electrolytes at the anode and cathode potentials would be very desirable.

The selection of materials for thin-film Li-ion batteries involves concerns similar to those for conventional bulk Li-ion batteries. However, the techniques used to fabricate thin-film batteries offer distinct advantages over those used to fabricate conventional batteries by affording the flexibility to design cells


with multilayer thin-film structures that can be made to exhibit properties not attainable in bulk structures. As an especially relevant example, a thin-film electrolyte structure can comprise a film of a high-ionic-conductivity material coated with a film of a material of lower ionic conductivity but greater stability versus Li. The development of films that can provide stability at anode and cathode potentials enables the use of many electrolyte materials, including both novel electrolytes and electrolytes that were known previously and were considered unusable because of poor chemical or electrochemical stability.

$\text{Li}_2\text{CO}_3$  is electronically insulating and somewhat ionically conductive. In research conducted thus far, solid electrolyte films of  $\text{Li}_2\text{CO}_3$  have been prepared by magnetron sputtering. These films have been found to be stable in air and to be useful for protecting components of Li-ion cells as described above. More specifically, the  $\text{Li}_2\text{CO}_3$  films have been found to afford (1) excellent passivation against reactions between electrolytes and anodes; (2) excellent stability against oxidation at

high voltage, as evidenced by the oxidative stability of carbonate-based liquid electrolytes at potentials up to 4.8 V, and (3) a high degree of stability in presence of humidity. The resistance to attack by airborne moisture is an important advantage in that during fabrication, air-sensitive components passivated by  $\text{Li}_2\text{CO}_3$  can be moved between processing tools in ambient air.

In impedance-spectroscopy tests,  $\text{Li}_2\text{CO}_3$  films sandwiched between Mo electrodes exhibited electrical characteristics similar to those of other solid electrolyte films. The room-temperature ionic conductivity of the  $\text{LiCoO}_2$  was found to be rather poor ( $\approx 5 \times 10^{-9} \text{ S/cm}$ ), though it was found to fit to an Arrhenius activation curve (see figure). Given this low ionic conductivity,  $\text{Li}_2\text{CO}_3$  would likely not be suitable for main electrolyte layers, but would be better suited for thin passivating films.

This work was done by Ratnakumar Bugga and William West of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Materials category. NPO-20953



An Arrhenius Activation Curve with a relatively low activation energy of  $\approx 0.35 \text{ eV}$  appears to be consistent with the temperature dependence of the measured ionic conductivity of  $\text{Li}_2\text{CO}_3$ .



VISIT US AT NDES,  
BOOTH 9026

**DuPont™ Krytox®**  
performance lubricants



## WHEN FAILURE IS NOT AN OPTION, DUPONT™ KRYTOX® IS THE ONLY CHOICE.

When you're designing for critical applications, there's no room for doubt. Maximum durability isn't just desired, it's required. That's when you need the most advanced lubricant formulated from space-age fluoropolymer technology. Krytox®. At temperatures from -70°F to 650°F (conditions that would cause most lubricants to degrade), Krytox® excels—extending the life of critical components. Krytox® is nonflammable, chemically inert, and compatible with metals, elastomers and engineering plastics. It also stands up to harsh solvents. And it won't migrate. So, when you can't afford failure, opt for Krytox®. For more information on Krytox® and other DuPont performance lubricants, call 1-800-424-7502. Or visit our new, redesigned website at [www.krytox.com](http://www.krytox.com).

### **NEW KRYTOX® XHT GREASES!**

The DuPont Oval Logo, DuPont™, The miracles of science™, and Krytox® are trademarks or registered trademarks of E.I. du Pont de Nemours and Company.



#### **INTRODUCING KRYTOX® XHT** **OUR HIGHEST-TEMPERATURE** **GREASE FORMULATIONS YET**

- > Most stable high-temperature greases available
- > All the same benefits of current Krytox®
- > Ideal for conveyor systems, oven bearings, valves, and other high-temperature applications up to 800°F (425°C)
- > Several grades available to meet specific application needs



*The miracles of science™*



## Study of Turbulent Boundary Layer on the F-15B Airplane

**Automated hot-wire anemometry has been demonstrated in flight tests.**

*Dryden Flight Research Center, Edwards, California*

NASA's F-15B #836 is a two-seat version of the F-15, which is a high-performance, supersonic, all-weather fighter airplane. The F-15B is used as a test-bed aircraft for a wide variety of flight experiments. In support of this use, a flight-test fixture (FTF) was developed to provide a space for flight experiments in a region with known aerodynamic conditions. The FTF is a fully instrumented test article mounted on the center line of the bottom of the fuselage of an F-15B airplane. The FTF includes an interchangeable experiment panel and is 107 in. (2.72 m) long, 32 in. (0.81 m) high, and 8 in. (20.3 cm) wide, with a 12-in. (30.5-cm) elliptical nose section. The FTF has been used in many flight experiments during the past several years and can be modified to satisfy a variety of research requirements.

One method of measuring turbulent fluctuations of density and velocity across the compressible boundary layer of an aircraft surface in flight (which fluctuations give rise to Reynolds stresses) involves the use of a recently developed automated hot-wire anemometry system. Prior to the development of the automated hot-wire anemometry system, a method of measuring turbulent velocity fluctuations in flight had not been perfected and routinely used in NASA's flight experiments, primarily because of the limitations of conventional anemometry systems. Conventional anemometry systems are characterized by difficulties in tuning, poor signal-to-noise ratios and low bandwidths at low overheat ratios, sensitivity to electromagnetic interference, and vulnerability to effects of cable capacitance. The automated hot-wire anemometry system is, more specifically, a constant-voltage anemometry (CVA) system that has been shown not to be subject to the aforementioned deficiencies of conventional anemometry systems. The CVA system was selected for flight testing on the FTF on the F-15B airplane.

It is essential to characterize the turbulent boundary layer in flight experiments because the length scales characteristic of turbulence in wind-

tunnel experiments are significantly different from those of turbulence in flight. Thus, flight measurements in turbulent boundary layers are necessary

for validation of computational fluid dynamics (CFD) computer codes and for predicting transitions from laminar to turbulent flow. The specific objective of




Figure 1. The inside of the Experiment Panel and the Hot-Wire Assembly are depicted in this photograph.





Figure 2. These Power Spectral Densities were computed from hot-wire-anemometer measurements taken at mach 0.9, an altitude of 15,000 ft ( $\approx 4.6$  km), and a local Reynolds number of  $2.8 \times 10^7$ .




# Survive the rigors of deep space. *Do More.*




In order for Alliance Spacesystems Inc. to design the robotic arm for the front of the Mars Exploration Rover, they needed an optimal combination of strength and light weight. With COSMOS/, they were able to reduce the weight 15-20% while still meeting NASA/JPL's exacting standards.




For stress, strain, displacement and buckling analysis, nothing is as fast, accurate, and easy to use as COSMOS/.



For electromagnetic/ electromechanical applications, COSMOS/ is up to 100 times faster than conventional technologies.



From designing the wing of an airplane to an exhaust valve, COSMOS/ offers a wide array of fluid flow and heat transfer capabilities.



COSMOS/ gives engineers an integrated tool to simulate plastics, rubbers, other nonlinear materials and much much more!



Are you sure you have a good design? Will it break? Will it overheat? If you aren't using COSMOS/ then you might be risking a potential part failure, without even realizing it. Don't take unnecessary chances with your design.

COSMOS/ offers a full suite of design analysis products. Fast, accurate, and easy to use, no other mainstream analysis product can match COSMOS/ for performance and functionality.

Save time and money try COSMOS/ FREE for 15 days and see for yourself why it is rapidly becoming the most popular analysis program on Earth....and beyond.


For information on how COSMOS/ can help you work smarter instead of harder and a **FREE** 15-day trial, call us today at **1-800-469-7287** or visit us online at <http://nasa.cosmosm.com>.

## COSMOS/™

© Copyright 2002, Structural Research & Analysis Corp. Trademarks are the property of their respective owners.



# INNOVATIVE



## ACCURIDE. THE PIONEER IN PRECISION SLIDES AND SOLUTIONS.


Accuride is the largest company in the world dedicated to the design and manufacture of precision ball bearing slides. For more than 35 years, we've worked side-by-side with our customers to pioneer new applications and solve tough design challenges through sound engineering, expert tooling and innovative solutions.

### MORE SLIDES

- ▶ 8" to 60" in length
- ▶ 35 to 500 lb. load capacity
- ▶ Standard and customized designs
- ▶ Range of brackets and accessories
- ▶ Network of stocking distributors

### MORE SOLUTIONS

- ▶ Engineering and tooling expertise
- ▶ Expert technical assistance
- ▶ Worldwide sales and service
- ▶ Global manufacturing
- ▶ ISO 9001 certified facilities



the flight tests was to validate the concept of CVA for measuring velocity fluctuations in turbulent boundary layers in flight.

The flight-tested CVA system included four hot wires (two wires of 5- $\mu$ m and two of 10- $\mu$ m diameter) mounted on probes on the aft panel of the F-15B FTF (see Figure 1). The measurements taken with the wires of each diameter were used to verify the sensitivity and repeatability of measurements. The hot-wire probes were mounted under the airfoil skin and were extended just prior to collection of data. The probes were extended at an angle of 45° into the boundary-layer flow to distances of 1, 2, 3, and 4 cm from the skin. Data were taken simultaneously for each wire during a time interval of 32 seconds at each flight condition. After collection of data, the probes were retracted. The associated electronic circuits, (including the power supply, CVA subsystem, and data-acquisition subsystem) were installed aboard the FTF.

In the tests, data were taken under various flight conditions ranging between mach 0.6 and mach 1.3 at an altitude of between 15,000 feet ( $\approx$ 4.6 km) and 30,000 feet ( $\approx$ 9.1 km). At the time of reporting the information for this article, analysis of the data was underway. Figure 2 presents a sample of processed data obtained from the flight tests. The raw data were sampled at a rate of 50 kHz and low-pass filtered at frequency of 20 kHz. The plots in Figure 2 show that there was significant turbulence at distances of 1, 2, and 3 cm from the skin. The turbulence was considerably lower at 4 cm from the skin, indicating the edge of the boundary layer. The peaks of the power spectral densities occurred at frequencies between 1,000 and 1,200 Hz. The turbulent energy cascade is clearly indicated, at frequencies above 12 kHz, by approximately constant negative slope at all four boundary-layer locations.

The turbulent data signals were analyzed to determine the degree to which they approximated Gaussian functions. Those obtained at the distances of 1 and 2 cm from the skin were found to be Gaussian, while changes from Gaussian to non-Gaussian were found to occur at distances of 3 and 4 cm.

*This work was done by Angela K. Beaver and Donald S. Greer of Dryden Flight Research Center. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Mechanics category.*  
DRC-01-15



## Improved Alignment Mechanism for Robotic Drilling

The improved design prevents jamming of an alignment key in an incorrect position.

*NASA's Jet Propulsion Laboratory,  
Pasadena, California*

An improved alignment mechanism and mating procedure have been devised for a robotic drilling system in which there is a need to assemble drill stem rods for sampling soils and rocks on a distant planet or asteroid. This mechanism is applicable to systems requiring positive axial alignment between segments. Similar mechanisms could be used on Earth, not only for assembling long drills but also for any system where a series of rods must be robotically assembled, such as in truss construction.





Figure 1. Conventional Mating Schemes incorporating polygonal configuration are susceptible to jamming.

Conventional robotically actuated drill-stem segmenting systems use alignment keys that often feature polygonal protrusions. Figure 1 shows a conceptual example. These mechanisms, while ensuring correct rotational alignment, are susceptible to jamming in a misaligned position. To prevent such jamming, complex control systems must be implemented that can provide fairly accurate alignment between the stem segments

# INNOVATION



## THE 2907. THE NARROWEST BALL BEARING SLIDE FOR 1U TO 4U CHASSIS.

Introducing the industry's narrowest, 100% ball bearing slide for 1U to 4U chassis. This versatile server slide offers superior movement and unparalleled mounting flexibility to work with an array of rail configurations. It's just another smart product innovation from Accuride.

### MORE ACCESS

- ▶ .38" wide
- ▶ 1.62" high
- ▶ 2" of over travel for access to entire unit
- ▶ Lock-out feature holds chassis stable while servicing

### MORE FLEXIBILITY

- ▶ 100 lb. load rating
- ▶ Lever disconnect provides easy chassis removal & reinsertion
- ▶ Adapts to a wide range of chassis sizes
- ▶ Even lengths: 12 to 30 inches



CALL 562-903-0263  
OR VISIT [WWW.ACCURIDE.COM](http://WWW.ACCURIDE.COM)  
FOR YOUR SOLUTION.

**Accuride®**

*The Leader In Precision Slide Solutions*

This product is covered by U.S. patents issued and pending. ©2002 Accuride International Inc.



prior to any mechanical engagement. Additional control must also be implemented to deal with the possibility that jamming occurs.

The improved alignment mechanism and mating procedure preclude any chance of jamming during assembly. The mechanism also does not require rotational alignment prior to engagement. The interface is a "half dog clutch," a mating scheme where two half cylinders are mated together (see Figure 2). However, the alignment keys are cut so as to produce a helical face. These keys are used for rotational align-

ment as well as torque transfer between segments. In the current implementation, an additional pilot is used to ensure axial alignment, but this feature may not always be necessary. The following steps are used to mate the segments:

1. The segments to be aligned are moved toward each other until contact between them is sensed. It may be beneficial to slowly rotate one of the rods in the direction opposite that of a flat cut that is part of the alignment key to help ensure that the helical faces of the dogs contact first.

## HOW TO GET SILICONE THAT'S OFF THE RADAR SCREEN . . .

When Stealth project engineers needed a

specific silicone that hadn't been

invented yet, they called Nusil

Technology. Why? They knew they

had to . . . **FIND THE RIGHT**

**PARTNER TO CREATE IT . . .**

Working with you, Nusil creates

silicone with the properties specific to your

individual application. Just the way it was done for the Stealth bomber. The result can

decrease the cost and increase the ease of manufacture. Of course you need to . . . **BE**

**SURE THEY HAVE THE FACILITIES TO PRODUCE IT . . .** Nusil's facilities

in North America and in Europe are spacious, state-of-the-art labs and processing

plants. NuSil Technology is ISO-9001 certified. From small highly specialized orders,

to large, off-the shelf 'standard' purchases, every batch is tested for quality and

consistency. Nusil has . . . **THE EXPERTISE TO PRICE IT RIGHT . . .**

As masters of silicone technology, Nusil has over 400 fully characterized silicone

formulations. Customizing these 'standards' to provide or impart specific properties

affords tremendous economies. Nusil makes it happen with . . . **THE GLOBAL**

**REPUTATION TO BACK IT UP . . .** Nusil's people are known for being hands-on,

can-do professionals. Nusil's reputation is second to none. At Nusil, we look forward

to being your . . . Creative partners in a material world.

### Nusil Technology

1050 Cindy Lane  
Carpinteria, CA 93013  
Telephone: (805) 684-8780  
Fax: (805) 566-9905

### Nusil Technology - Europe Technical Services Center

2740 Route des crêtes  
BP325 06906  
SOPHIA ANTIPOLIS cedex, FRANCE  
Telephone +33 (0)4 92 96 93 31  
Fax +33 (0)4 92 96 06 37



SILICONE  
TECHNOLOGY

[www.nusil.com/nbt](http://www.nusil.com/nbt)




Figure 2. An Improved Alignment Mechanism does not require rotational alignment prior to engagement.

2. The rods are moved apart to a distance that is fraction of the height of the alignment key.
3. The rods are re-engaged by simultaneous rotation and translation in such a way that the tip of the alignment key travels parallel to the helical alignment-key surface. This motion ensures that next contact will be between driving faces, at which time positive axial alignment is achieved.
4. The axial-rotational movement can continue until full engagement of the segments is achieved and detected, assuming that one segment is held freely so that the other may drive it.

Note that for this entire process only two simple sensory inputs are required. At no point must the control system know the rotational position of either segment.

This work was done by Benjamin Dolgin and Stephen Askins of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Mechanics category.  
NPO-21164



The DuPont Oval Logo, DuPont™, the miracles of science™, and Vespel® are trademarks or registered trademarks of E. I. du Pont de Nemours and company.

DuPont™ Vespel®  
forward engineering

AS A KID, TIM DIDN'T WATCH MUCH TV.  
HE WAS TOO BUSY TAKING IT APART.

Now that you're all grown up, you not only want to understand how things work, but how to make them work better. That's why DuPont™ Vespel® Parts and Shapes were developed with the flexibility to help you meet customer requirements and maybe even make some new discoveries while you're at it. After all, making things lighter, stronger, faster, and subsequently, more efficient is what Vespel® Forward Engineering is all about. So, if you're looking to move the industry forward, think Vespel® Parts and Shapes first. Chances are, you'll find the design process as rewarding as dissecting your dad's old hi-fi. To find out what our extensive new line of materials can do for you, go to [www.dupont.com/vespel](http://www.dupont.com/vespel) or call 1-800-972-7252. If you can dream it, we can make it.

VISIT US AT NDES, BOOTH 9026




The miracles of science™



# SEAL MASTER® INFLATABLE SEALS



**Improve Many  
Production  
Operations  
With New  
Efficiency!**



**SEAL IT**



**LIFT IT**



**PUSH IT**



**STOP IT**



**SQUEEZE IT**



Sealing is just one of many tasks for custom-built, fabric-reinforced, elastomeric inflatable seals. With their simplicity and versatility, they're ideal for use as actuators, brakes, valves, clutches, wipers and for many other innovative applications. They'll replace cumbersome, hard-to-maintain processing and handling components to minimize downtime.

Ask about our RSVP Design Assistance Program.



**SEAL MASTER CORPORATION**

*Inflatable seals and other custom rubber products*


368 MARTINEL DRIVE, KENT, OH 44240-4368 USA

800.477.8436 • 330.673.8410 • FAX 330.673-8242

E-mail: info@sealmaster.com • www.sealmaster.com

For Free Info Circle No. 557 or  
Enter No. 557 at [www.nasatech.com/rs](http://www.nasatech.com/rs)

[www.globe-motors.com](http://www.globe-motors.com)



**emotion™**



Design next-generation  
**VEHICLES** with assurance  
that our motors and  
devices will meet tight  
tolerances and extreme  
specifications. Get the  
facts about standard  
and custom motors from  
The Experts in Motion  
Control!™

**937-228-3171**

Fax: 937-229-8531

**QS9000  
CERTIFIED**

**Globe Motors™**

For Free Info Circle No. 422 or  
Enter No. 422 at [www.nasatech.com/rs](http://www.nasatech.com/rs)

## Mechanics

### Measuring Volume of Incompressible Liquid in a Rigid Tank

The measurement is unaffected by the shape  
of the liquid or tank.

*NASA's Jet Propulsion Laboratory, Pasadena, California*


A technique for measuring the volume of an incompressible liquid in a rigid tank involves measurement of the total volume of gas in those parts of the tank not occupied by the liquid. The volume of liquid is then computed by subtracting  $V$  from the total volume of the tank and the associated plumbing.

Unlike liquid-level-measuring techniques, this technique works whether or not a gravitational field is present and is unaffected by the shape of the liquid or tank. Even if bubbles of gas are present in the liquid or if the liquid has broken up into separate globules or pools, the measurement of the total volume of gas is unaffected.

The pressure in the tank is measured while the total volume of the tank is varied by use of a piston or bellows (see figure). It is assumed that the gas is a noncondensable ideal gas, that the alternating compression and decompression of gas is adiabatic, and that the variation in volume is a small fraction of the total volume of gas. Under these assumptions, the total volume ( $V$ ) of gas in the tank is given by  $V = -\gamma P(\Delta V/\Delta P)$ , where  $\gamma$  is the specific heat of the gas at constant pressure ÷ the specific heat of the gas at constant volume,  $P$  is the pressure,  $\Delta V$  is the change in volume, and  $\Delta P$  is the change in pressure that accompanies the change in volume. In a demonstration of this technique, the volume of water in a 94-liter tank was determined within 1 liter.

*This work was done by Frank T. Hartley of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Mechanics category.*

NPO-19211



The Volume of Gas (including bubbles) in the tank is determined by measuring the small change in pressure that accompanies a small change in volume. The volume of liquid is then computed by subtracting the volume of gas from the total volume of the tank and plumbing.




## Vision-Based Maneuvering and Manipulation by a Mobile Robot

**Mobility is used to augment limited dexterity.**

*NASA's Jet Propulsion Laboratory, Pasadena, California*

A small mobile robot equipped with a stereoscopic machine vision system and two manipulator arms that have limited degrees of freedom has been given the ability to perform moderately dexterous manipulation autonomously, under control by an onboard computer. The approach taken in this development has been one of formulating vision-based control software to utilize the mobility of the vehicle to compensate for the limitation on the dexterity of the manipulator arms. Although the goal was selected visually, it is tracked onboard using information about its shape; in particular, the target is assumed to be a local elevation maximum (i.e., the highest point within a small patch of area).



**A Six-Wheeled Robotic Vehicle Is Moved** — in this case, backward along a series of circular arc segments — while visually tracking the target, so that the manipulator-arm workspace initially at position A can be robustly moved onto the target at position B.

## the **WAVE** you've been waiting for...

Introducing **PV-WAVE<sup>®</sup> 7.5** with more features to help you solve complex problems. PV-WAVE is an easy-to-use analysis and visualization environment that enables engineers, scientists, researchers and business analysts to understand complex data sets and rapidly build visual data analysis applications.

PV-WAVE 7.5 strengths include:

- A Visualization Toolkit (VTK) approach that offers a high-level, easy-to-use interface to OpenGL.
- High-quality, reliable analysis through the integration of the Visual Numerics' IMSL<sup>®</sup> C Numerical Library.
- Efficient memory utilization, critical to working with large data sets.


Discover what customers worldwide have known for 30 years. Visual Numerics' PV-WAVE can increase productivity, accelerate development and illustrate key knowledge contained in your data.



Register to win **FREE**  
**PV-WAVE 7.5** product at:

[www.vni.com/product](http://www.vni.com/product)

PV-WAVE - HELPING CUSTOMERS **SOLVE** COMPLEX PROBLEMS



"Visual Numerics has partnered with us by providing not only the best technology, but also service that is unparalleled in the industry!"

Brian Young  
Senior software engineer  
Marquette Medical Systems

**PV-WAVE<sup>®</sup> 7.5** Visual Numerics



The mobile robot in question is Rocky 7 — a prototype "rover"-type vehicle used in research on robotic-vehicle concepts for the exploration of Mars. The mobility system of Rocky 7 is based on a six-wheel-drive rocker-bogie mechanism that includes two steerable front wheels and four nonsteerable back wheels. One of the manipulator arms is equipped with two independently actuated scoops for acquiring samples. Not counting the motions of the scoops, this arm has two degrees of freedom — shoulder roll and a shoulder pitch. The other manipulator arm

is a mast on which is mounted a stereoscopic pair of video cameras and that can, if desired, be tipped with a scientific instrument. The mast has three degrees of freedom (shoulder pitch, shoulder roll, and elbow pitch). The mast can be used to position and orient its cameras and/or to place its tip instrument on a target object to acquire a sample or take a reading. Additional stereoscopic pairs of cameras are located at the front and rear ends of the main body of the vehicle.

At the beginning of an operation, one or more target objects a small dis-

tance away are selected, and then the robot is commanded to perform autonomously some manipulations that involve the objects. Following the basic approach of using mobility to augment dexterity, the navigation and mobility control subsystems of the vehicle cause the vehicle to maneuver into a position and orientation in which the target lies within the range of one of the manipulators (see figure), and then the manipulator control subsystem causes the manipulator to perform the remaining fine positioning and manipulation.

The key to ensuring that the rover reaches its target is to move in small steps, and lock onto the target by automatically tracking its shape. The computer processes the image data from the stereoscopic camera pairs into an elevation map of the nearby terrain and locates the target on the elevation map. The computer plans the route of the vehicle across the terrain toward the target, using an approximate kinematical model (assuming flat terrain and no slippage of wheels). At frequent intervals along the route, updated elevation maps are generated from newly acquired stereoscopic-image data, the target is identified on the updated maps, and the planned route is corrected accordingly. Here the scale-invariant features (i.e., shape, elevation, and centroids) are tracked: this allows one to track the target even as its image grows dramatically in size during the final approach, a situation that often causes traditional visual servoing techniques to fail. This process of iterative, vision-based refinement of the route continues until the vehicle arrives at the desired location near the target.

Once the vehicle is in the desired position and orientation relative to the target, the designated manipulator arm is lowered toward the target; tactile sensing is used to signal contact with the target or with the ground adjacent to the target. The manipulator arm is then commanded to perform the assigned manipulation. Manipulations that Rocky 7 has performed in demonstrations include grasping several small rocks that were initially at a distance of >1 m and placing an instrument on a boulder that was initially at a distance of >5 m.

*This work was done by Mark Maimone, Issa Nesnas, and Hari Das of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Machinery/Automation category.*  
NPO-21011

When you need to visualize large, complex data sets naturally and interactively, you need the best visualization tools. Used by industry leaders, StereoGraphics CrystalEyes3 and Monitor ZScreen are the professional's choice. Whether you are looking for active shutter eyewear or a passive polarizing system, StereoGraphics Corporation has the best solution for your stereo viewing needs.



For More Information:  
Call Toll Free: 866-455-1490  
Visit: [www.stereographics.com/ntb/](http://www.stereographics.com/ntb/)  
Email: Stereo3D@stereographics.com

*GIS/Mapping • Molecular Modelling • CAD • Industrial VR • Medical Imaging • Simulation*

NTB0302





## Photolithographic Fine Patterning of Difficult-To-Etch Metals

Copper is used as a liftoff material.

*John H. Glenn Research Center, Cleveland, Ohio*

A process that includes photolithography, liftoff, etching, and sputter deposition has been developed to enable the fabrication of thin, finely patterned layers of gold, platinum, and other difficult-to-etch materials in advanced miniature sensors and associated electronic circuitry. Heretofore, photolithography has been used in conjunction with liftoff and etching to produce finely detailed structures in easy-to-etch materials. The present process is needed because conventional photolithography cannot be used to pattern difficult-to-etch materials and the alternative processes heretofore available for patterning difficult-to-etch materials are limited to spatial resolution of about 0.005 in. ( $\approx 0.13$  mm) or coarser.

The process (see figure) includes some new steps plus some steps from prior processes that are used with modifications and in a different sequence. The sequence is the following:

1. Copper is deposited over an entire face of a substrate of suitable material (e.g., alumina). If the substrate material is one to which copper does not adhere well, aluminum or nickel can be used instead of copper. The thickness of the copper (or aluminum or nickel, as the case may be) should be made roughly three times that of the final desired difficult-to-etch metal layer.
2. The copper is covered with positive photoresist.
3. The photoresist is soft-baked.
4. The photoresist is exposed through a photomask in the desired pattern.
5. The photoresist is developed.
6. It is hard baked at 110 °C for 30 minutes.
7. The entire workpiece is washed with a half-and-half mixture of nitric acid and water to remove the copper from the regions in which the difficult-to-etch metal is to be deposited. This removal of copper is facilitated by a slight undercutting of the photoresist.

The most significant aspect of this process is the use of copper as the liftoff material. Partly because of the rapidity with which copper is etched, it is possible to control the amount of undercutting of the photoresist and to




# Now Scanning Improves Originals

## Announcing ... XEScan Solutions

Wide-format scanning so sensitive it sees colors and gradations other scanners can't. So attentive, it adjusts image quality automatically. So flexible, it scans images up to  $\frac{1}{2}$ " thick. So easy, it outputs to any of your network printers. **XEScan Solution.** Scalable investment protection. Contact your XES representative at 1-877-XES-8212 ext.262.

Visit [www.XES.com](http://www.XES.com) to register for a free telescoping drawing tube (retail value \$15.00)

 **XEROX  
ENGINEERING  
SYSTEMS**



ensure that the undercutting occurs uniformly and cleanly. Undercutting is very important to the success of this process: it expedites removal of unwanted material later in the process and increases the sharpness of the final pattern of difficult-to-etch metal.

8. The substrate holder is precooled to 10 °C before the piece is loaded into the sputtering system.
9. The difficult-to-etch metal is sputter-deposited at a relatively low power density (0.14 W/cm<sup>2</sup>) over the entire substrate. In the regions from which the copper and photoresist

were previously removed, difficult-to-etch metal becomes deposited directly onto the substrate. During the deposition of the difficult-to-etch metal, the substrate is cooled to prevent the carbonization of the photoresist; this is necessary because carbonization would make the subsequent removal of the photoresist more difficult.


10. The workpiece is washed with acetone to remove all the photoresist plus the portion of difficult-to-etch metal deposited on top of the photoresist.

11. The workpiece is washed with the nitric acid/water mixture to etch away all the remaining copper, leaving the desired difficult-to-etch metal pattern.

*This work was done by Charles A. Blaha of Akima Corp. for Glenn Research Center. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Manufacturing category.*

*Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-17079.*

TRANTEKDRIVESYSTEMS.COM



## GO FASTER. GO FURTHER. GO HEAVIER.

The new DriTran® Screw Drive System gives engineers the freedom to design machinery without the critical speed and length concerns associated with conventional screw drive systems.

Imagine being able to move a 10,000 lb. load 30 feet in 10 seconds with a 2.75" diameter screw delivering 6" of travel per revolution. This new system handles dynamic loads up to 30,000 lbs. and standoffs allow joining multiple sections up to 40 feet.


Cast epoxy-threads inside the nut make it all happen. The best part—the low friction, extended wear nut is easy to service, and it can be changed out in minutes instead of days.

To find out more,  
Call us today at 231-946-6270 or  
visit [www.trantekdrivesystems.com](http://www.trantekdrivesystems.com)

# TRANTEK

DRIVE SYSTEMS INCORPORATED

2470 N. AERO PARK COURT TRAVERSE CITY, MICHIGAN 49686



A Mask for Sputter Deposition of a difficult-to-etch metal is made of copper with overhanging photoresist. The photoresist and copper are removed after the deposition.



# Software for Optimized Flattening From 3D to 2D

Manufacturing considerations can be taken into account in designing minimally wasteful 2D patterns.

John H. Glenn Research Center, Cleveland, Ohio

A computer program offers enhanced capabilities for calculating two-dimensional (2D) patterns needed to construct specified three-dimensional (3D) surfaces to within acceptably close approximations, with minimal waste of sheet material. Examples of complexly shaped sheet-material items that could be designed by use of this program include aircraft fuselages, hulls of ships, clothing, and automotive bodies.

This program offers two advantages over the flattening subprograms of prior computer-aided-design, computer-aided manufacturing (CAD-CAM) programs:

- The program utilizes all available pertinent information, including not only information on the desired 3D shape but also information about the manufacturing process in which the two-dimensional pattern(s) would be formed into the 3D surface. The more information about the 3D surface and the manufacturing process that is available, the better can be the match between the 3D surface and the 2D pattern(s) used to construct it.
- The program affords options that enable the user to define and build a method of solution based on the unique characteristics of, and the available data about, the 3D surface. In particular, the program can implement any or all of four independent procedures, and for each procedure there is a choice of several algorithms. This array of options enables the user to integrate any available pertinent information into the solution via at least one procedure.

In the event that the desired 3D surface is one that can be fabricated by bending only (such a surface is termed "developable" in the art) then procedures 1 and 2 are the only ones needed. However, if in-plane deformations (stretching or shrinking) are needed, or if there is a need to fold any portion of sheet material upon itself to form multiple layers, then procedure 3 or procedures 3 and 4 must also be used.

In procedure 1, boundaries that divide a 3D surface into regions are placed into a plane. Because the algorithms defining these boundaries can be chosen from a library of algorithms, these boundaries serve as initial conditions which help define a unique flattening process. The placement of these boundaries depends on several factors unique to the 3D surface. One factor, which can be controlled by placement of the boundaries, is to allow or not allow distortions to move from one 2D region into another 2D region. Also, the user might want to satisfy some general 2D outer-boundary constraints, which can be addressed only at the boundary-placement level. Some 3D surface boundaries cannot be placed directly into the 2D plane by procedure 1. Such a boundary is not amenable to placement by use of one or two algorithms alone; instead, it is necessary to "grow" the boundary into the 2D plane during the execution of procedure(s) 2, 3, and/or 4.

In procedure 2, 3D cell walls are placed into the plane, such that the lengths of the 3D arcs of each cell wall are preserved in the plane. At this point, the program is working in the 2D plane but is using information which geometrically defines the corresponding 3D surface triangle. After procedure 2 has been performed at the local level on an individual cell, the user is then given the option of using either procedure 3 or procedures 3 and 4. These two procedures involve the relationship between the area and geometry of a 3D cell and the area and geometry of the corresponding recently formed 2D cell. In par-


ticular, if the user knows there was a local expansion, contraction, or folding of the 2D sheet during the manufacturing process, then procedure 3 or procedures 3 and 4 must be used. These procedures modify the local 2D cell by incorporating, into the 2D cell, the inverse stresses and strains inherent in the manufacturing process of forming a 3D surface from a 2D surface. Procedure 4 is used and coupled to procedure 3 if the expansion or contraction factors are associated with preferred directions.

Another important element of the program logic is the coupling of procedure 2 directly to procedure 3 by feeding the geometric solution of procedure 2 into procedure 3. The geometric solution from procedure 2 serves as an initial geometry from which procedure 3 (or 3 and 4) can geometrically and algebraically iterate. During this iteration, the 3D cell is transformed from a predefined 3D cell geometry to a 2D cell geometry which satisfies input data defining the manufacturing process.

*This work was done by Bruce M. Auer of Glenn Research Center. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Manufacturing category.*

*Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-17029.*

## Thermofoil™ Heaters put the heat where you need it



Flexible etched-foil heaters • Odd shapes, profiled or multiple elements • Efficient heat transfer: Up to 110 W/in<sup>2</sup> • 200°C polyimide, 235°C rubber, 600°C mica, 120°C transparent insulations • Optional sensors & controllers

Precise, reliable heating • Minimal space, mass, & design overhead • Medical diagnostic instruments • Aerospace devices • Commercial appliances • Packaging machinery • Scientific instruments • Electronics

## MINCO

Minco Products, Inc.

7300 Commerce Lane / Minneapolis, MN 55432-3177 U.S.A.  
Tel: (763) 571-3121 / Fax: (763) 571-0927 / [www.minco.com](http://www.minco.com)



## Electron-Beam Welding of Superalloys at High Temperatures

Strain age cracks can be prevented.

John H. Glenn Research Center, Cleveland, Ohio

Electron-beam welding at high temperatures has been found to be a suitable process for joining structural components made by casting certain superalloys. This process can be used in the fabrication of superalloy parts that must withstand high operating temperatures. Examples of such parts include

exhaust ducts of advanced aerospace engines and end caps on turbine buckets.

The superalloys in question are  $\gamma$ -strengthened nickel-base alloys that contain either >3 weight percent Al or >6 percent Ti. Strain age cracks form in such alloys upon cooling after welding or on subsequent reheating to aging


temperatures. The cracks result from a combination of residual stresses produced during welding and aging cycles. Heretofore, the formation of the strain age cracks has made it impossible to utilize these superalloys to make welded structures.

The development of the present process brought electron-beam welding together with vacuum heat treatment to provide a new industrial capability. Electron-beam welding has long been used to produce structural weldments in a wide variety of alloys, but, heretofore, has not been successful for welding nickel-base superalloy structures. Nickel-base superalloys are frequently heat-treated in vacuum furnaces to impart the very properties for which they were selected.

In the present process, a heat-treating furnace is placed in the vacuum chamber of an electron-beam welding machine. A superalloy structure to be welded is placed in the furnace. Prior to and during welding, the furnace is used to heat the entire superalloy structure to a temperature at or near the solution temperature of the alloy. Maintaining the entire structure at this temperature reduces or eliminates the thermal stresses produced by the differential thermal expansion during welding. Further, maintaining this temperature for a while after welding affords some relief of solidification stresses, thereby helping to prevent subsequent strain age cracking. The structure can then be cooled rapidly and later aged or can be aged during the cooling cycle after welding has been completed. An additional advantage is that the reduction in thermal stress prevents the formation of liquation cracks in the heat-affected zones of the welds.

*This work was done by Thomas J. Kelly of General Electric Co. for Glenn Research Center. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Manufacturing category.*

*Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16686.*



**HERE'S THE CLINCHER**


for anyone  
who designs  
for assembly.

### Less is more.

Less parts, less assembly steps, less assembly time – all yield more productivity and more cost reductions. To achieve this, designing for assembly (DFA) is critical.

PEM® products are made for DFA. Just punch or drill a hole and press a PEM fastener into place. PEM self-clinching fasteners install permanently into thin sheets. There are fewer parts and fewer total pieces to handle during assembly which translates into cost savings. We also offer threadless and multi-function fasteners to further meet your DFA needs.

These include SNAP-TOP® (shown in photo above) standoffs which eliminate the need for screws, locating pins for quick alignment of mating parts, P.C. board fasteners and many others.



For automated installation, our line of PEMSERTER® presses quickly install PEM fasteners, further reducing assembly time.

**Clinch it with PEM®**  
FASTENERS & PRESSES

PEM Fastening Systems  
a PennEngineering® company

©2001 210

800-237-4736 • [www.pemnet.com](http://www.pemnet.com)







**Bio-Medical**

## **Petri-Dish Spreaders Sterilized by Electrical Heating**

**Sterilization is faster, easier, and less expensive than it is for conventional glass spreaders.**

*Lyndon B. Johnson Space Center, Houston, Texas*


An improved method of sterilizing petri-dish spreaders and a spreader design to implement the method have been developed. In comparison with the conventional methods of sterilizing petri-dish spreaders, the improved method is expected to prove easier, safer, less time-consuming, and less costly, and to require less laboratory space. This improved method could be used in microbiological investigations in microgravity (e.g., aboard the International Space Station) or in normal Earth gravity (e.g., in government and clinical laboratories and research institutions). Particularly, when used in spaceflight, the improved method will prove safer than the traditional flame sterilization method.

The prior art in the design, use, and sterilization of petri-dish spreaders is relatively straightforward. A conventional petri-dish spreader is a glass rod bent like a hockey stick. The longer straight segment of the rod is used as a handle, while the shorter straight segment is used to spread a suspension of micro-organisms with a small volume (typically 0.1-mL) evenly over the surface of the growth medium in a petri dish. After a suitable incubation time, colonies of the

microbes grow on the surface of the medium. Provided that a known volume of a microbial suspension is spread evenly over the medium, an accurate count can be made, and the types of organisms in the suspension can be identified. If the suspension is not spread correctly, the growing colonies converge and become so crowded that it is hard to see the boundaries between them.

Each time a suspension of micro-organisms is spread over a different dish, a sterile glass spreader must be used. A spreader that was used on another dish can be reused if it is dipped into 95-percent ethyl alcohol and the alcohol is then ignited with a flame to sterilize the spreader. If multiple dishes are to be inoculated and insufficient time is available for sterilization of a single spreader between dishes, then multiple sterile spreaders must be prepared in advance, and considerable laboratory space must be allocated for storing them. Moreover, the use of alcohol and an open flame to sterilize spreaders introduces a fire hazard.

In the improved method, the spreader comprises a forked handle and a rake made of a coil of chromel electrical-resistance heater wire (see figure) that draws



**A Rake Made of Coiled Wire** is heated by placing the ends of the wire in contact with the 6-volt secondary terminals of a step-down transformer. The heating sterilizes the rake, so that it can be used to spread micro-organisms over a petri dish.

eddy current  
**displacement**  
**sensors**

non-contact - wear free



**MICRO-EPSILON**

**unmatched  
precision**

resolution **0.005 %**

linearity **0.2 %**

stability **0.008 %**  
FSO/F



**eddyNCDT DT 3300**

- new robust sensors IP 67
- measuring ranges 0.5 ... 80 mm
- $\mu$ -controller touch key calibration
- scaleable display
- limit switches, peak-to-peak, auto-zero, min, max, average

eddy-current measurement - online  
[www.micro-epsilon.com](http://www.micro-epsilon.com)

MICRO-EPSILON  
Raleigh, NC 27617-7419  
Tel. 919 787 9707 · Fax 919 787 9706  
e-mail: [me@micro-epsilon.com](mailto:me@micro-epsilon.com)

For Free Info Circle No. 426 or  
Enter No. 426 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



a current of 3 A when a potential of 6 V is applied. All that one need do to sterilize the rake is to place the end terminals of the wire in contact with the output terminals of a 6-V power source, which can be the secondary terminals of a 120-to-6-V step-down transformer. In this method, one does not attempt to sterilize the entire spreader; only the rake is sterilized. Tests have shown that the rake becomes heated to sterilizing temperature within only 2 to 3 seconds of heating at 6 V. After electrical heating, the rake can be cooled quickly on a damp sterile pad and is then

ready to use. The sterility of the spreader in this improved method has been verified by extensive testing involving spreading on sterile media after spreading 0.1 mL of a bacterial solution on a petri dish.

The improved method has proved to be very reliable. Although it involves heat, this method, unlike the flame sterilization method, does not involve either alcohol or an open flame, and thus introduces less of a fire hazard. Because this method makes it unnecessary to use multiple presterilized glass spreaders, it reduces (relative to the flame sterilization

method) the amount of storage space needed. Because sterilization and cooling before each use take only a few seconds in this method, preparation time is reduced, relative to that of the flame sterilization method. A further advantage of this method is that, because of its simplicity, little (if any) maintenance is needed.

*This work was done by Duane Pierson of Johnson Space Center and Thomas C. Molina of KRUG Life Sciences. For further information contact the Johnson Technology Commercialization Office at 281-483-3809. MSC-22903*



Superior image and data transfer...

## From the furthest star to the smallest microbe.



There are many reasons EDT data/camera interface boards are used in astronomy, medicine,

industry, aerospace — anywhere where exceptional and dependable performance is crucial.

- Exceptional speed, using the computer's own memory for high-speed access.
- Simple and practical designs that easily handle the most

sophisticated data or camera interface tasks.

- PCI/RCI fiber-optic interface available on several models for flawless image transfer and total flexibility in locating your computer.
- Engineering customer-support that ensures seamless integration of your system.

Wherever your research or innovation takes you, contact EDT today and see how our

products provide the extraordinary interface performance your work demands.



**Engineering Design Team, Inc.**

1100 NW Compton Dr., Suite 306, Beaverton, Oregon 97006

Phone: (503) 690-1234 • Fax: (503) 690-1243

email: info@edt.com • www.edt.com

## Quantifying Microbial Diversity Through Dilution/Extinction

*John F. Kennedy Space Center, Florida*

A method of relatively easily, rapidly, and inexpensively quantifying the structural diversity of a multiple-species community of micro-organisms is based on the rate of extinction of phenotypic traits across a dilution gradient of a sample of the community. In this context, the concept of structural diversity encompasses the number (richness) and distribution (evenness) of separate or interacting biological entities responsible for given functions within the overall set of functions performed by the community. It is assumed that the rate of loss of character (as measured through testing for a given function) from the community upon dilution/extinction is proportional to the diversity of biological entities in the community. This assumption should be true as long as the average metabolic versatility of individuals (the width of a nutritional niche) does not increase with structural diversity. Inasmuch as most experimental evidence suggests that the widths of nutritional niches decrease with increasing diversity, the assumption appears valid. In experiments performed to evaluate the method, the nonlinear relationship between the number of positive tests and the density of cells across a dilution series was successfully fit to a rectangular hyperbola, yielding regression variables related to the structural diversity of the samples.

*This work was done by Jay Garland of Dynamac Corp. and R. Michael Lehman of Bechtel BWXT, LLC for Kennedy Space Center. For more information, contact the Kennedy Commercial Technology Office at 321-867-6224. KSC-12226*





*some day, you'll use virtual prototyping.  
unfortunately, your competitors are doing it now.*

*Eliminate physical prototyping with MSC.Marc*

While you're making prototypes, MSC.Marc users are making progress. MSC.Marc's unparalleled nonlinear FEA capabilities allow them to iterate and perfect their design virtually, for unprecedented speed to market. Proven by 30 years of use in over 5000 customer installations, MSC.Marc scales from small Intel workstations to distributed computing and supercomputers.

To learn more about solving real world engineering problems and get your free technical white paper F $\neq$ Ku, visit <http://marc.mscsoftware.com>

[marc.mscsoftware.com](http://marc.mscsoftware.com)

MQ02

MSC.evisualNastran  
Simulation, motion, and  
stress online—anywhere.

MSC.visualNastran Desktop  
Motion and stress simulation  
on your desktop.

MSC.visualNastran Professional  
Powerful analysis on  
the Windows platform.

MSC.visualNastran Enterprise  
World's leading mission-critical  
analysis software.

DO IMPOSSIBLE THINGS WITH MSC.VISUALNASTRAN PRODUCTS

MSC.Marc

**MSC SOFTWARE**  
SIMULATING REALITY



# The Leader in Advanced Composite Training

- Advanced Composite Structures: Fabrication and Damage Repair Phase 1, 2 and 3
- Composite Laminate Design
- Repair Analysis and Substantiation
- Design of Composite Structures
- Design and Analysis of Composite Structural Joints

Training at our Nevada or Georgia facility or yours.  
Contact us for a complete course catalog.


**www.abaris.com**  
**(800) 638-8441**

Abaris Training Resources, Inc.  
5401 Longley Lane, Suite 49  
Reno, NV 89511 USA  
(775) 827-6568 • Fax: (775) 827-6599  
e-mail: info@abaris.com

**ABARIS**  
TRAINING

For Free Info Circle No. 425 or  
Enter No. 425 at [www.nasatech.com/rs](http://www.nasatech.com/rs)

## UNISLIDE® ASSEMBLIES



**www.velmex.com**  
**sales@velmex.com**  
**Tel: 800 642-6446**  
**NY: 585 657-6151**

**Manual &  
Motorized**  
**VELMEX, INC.**

For Free Info Circle No. 486 or  
Enter No. 486 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## Physical Sciences


### Electrochemical Systems Generate Ozone and Ozonated Water

The only inputs needed are electric energy and mildly pressurized water.

*Lyndon B. Johnson Space Center, Houston, Texas*

Improved electrochemical systems for generating ozone (in gaseous form and/or dissolved in water) have been invented for use in disinfection and in industrial processes in which the unique, highly oxidizing chemical properties of ozone are needed. More accurately, these systems generate oxygen along with high (relative

to prior systems) concentrations of ozone and, optionally, with hydrogen as a byproduct. These systems contain no pumps and very few moving or wearing components, and the only inputs needed to operate these systems are electric energy and water supplied at mild pressure. Moreover, these systems can readily be designed and con-



This System Adds Dissolved Ozone to a stream of water. The system also generates hydrogen and  $O_2/O_3$  mixture as optional byproducts.



structed on any scale (e.g., from research laboratory to industrial) to suit a wide variety of applications.

A basic system of this type (see figure) includes a power supply, an ozone-generator/anode-reservoir unit, a cathode phase separator, and a gas-destruction unit. At the bottom of the anode reservoir lies the active part of the ozone generator, which preferably is an electrolytic cell that contains a proton-exchange membrane with a porous anode on its upper face and a porous cathode on its lower face. A catalyst on the anode promotes the electrolytic production of oxygen and ozone, some of which dissolves into the water in the anode reservoir. The anode reservoir also serves as part of a liquid/gas separator, wherein oxygen and ozone generated at the anode form into bubbles or diffuse from the water and rise to the top of the reservoir. The rest of this phase separator is a hydrophobic membrane at the top of the reservoir that allows the  $O_2$  and  $O_3$  gases, but not water, to pass through to the top side. The mixture of  $O_2$  and  $O_3$  gases can be fed either to an  $O_3$ -consuming process or to the gas-destruction unit.

A tube connects the cathode with the cathode phase separator. A hydrophobic membrane in the cathode phase separator allows hydrogen gas, but not water, to pass through to the top side. Hydrogen gas from the dry (top) side of the membrane is either sent to the gas-destruction unit or discharged to a hydrogen-consuming external process. Preferably, water that has been transferred from the anode to the cathode by electroosmosis is returned from the bottom of the cathode phase separator to the input (top) end of the anode reservoir through the tube depicted as the longest in the figure.

The source of water is connected directly to the anode reservoir. The liquid/gas-separator membranes make it possible for the water from the source to displace any gases from anode reservoir and from the lower compartment of the anode phase separator. Once these gases have been displaced, the water comes into direct contact with these membranes and the transfer of water ceases as the pressures in the anode reservoir and cathode phase separator equalize with the pressure in the source of water. Provided that the pressure in the source equals or exceeds the pressure in the anode reservoir, the anode reservoir and the cathode phase separator remain full of water during all phases of operation.

Preferably, a cooling unit (e.g., comprising heat spreaders, thermoelectric devices, and a heat sink) is attached to the anode reservoir to remove waste heat and to chill the reservoir in order to re-

duce the rate of degradation of dissolved ozone and increase the solubility of ozone in the water. The output stream of ozonated water is taken from just above the anode at the bottom of the anode reservoir.

The gas-destruction unit includes a source of combustion air, a hydrogen/air-mixing region, a hydrogen-destruction zone that contains a hydrogen/air-combustion catalyst, an air/ozone-mixing region, and an ozone-destruction region that contains an ozone-destruction catalyst. The products of the gas-destruction unit are vented and/or drained.

This work was done by Oliver J. Murphy, Craig C. Andrews, and Thomas D. Rogers of Lynntech, Inc., for Johnson Space Center.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Lynntech, Inc.  
7610 Eastmark Drive  
Suite 202  
College Station, TX 77840  
Tel. No: (409) 693-0017  
Fax No: (409) 764-7479

Refer to MSC-23046, volume and number of this NASA Tech Briefs issue, and the page number.



## COMPLIMENTARY EXHIBITS PASS

to the most important event in 2002

# SAMPE 2002

"Technology at the Highest Level"

May 13-15, 2002

TECH BRIEFS Long Beach, CA

Long Beach Convention Center



### CONTACT

<b>Program</b> Priscilla: 626/331-0616 ext. 610 sampereg@aol.com	<b>Exhibits</b> Rosemary: 626/331-0616 ext. 601 exhibits@sampe.org	<b>Membership</b> Patricia: 626/331-0616 ext. 632 sampembr@aol.com
--	--	--

[www.sampe.org](http://www.sampe.org)

Events planned (partial list):

<ul style="list-style-type: none"> <li>• Keynote Address</li> <li>• Keynote Panel</li> <li>• Exhibition</li> <li>• Panels</li> <li>• Technical Sessions</li> <li>• Plenary Session</li> <li>• Bookstore</li> </ul>	<ul style="list-style-type: none"> <li>• NASA's Advanced Materials Program—Technology Briefings</li> <li>• Bridge Building Contest</li> <li>• Job Fair</li> <li>• Tutorials</li> </ul>	<ul style="list-style-type: none"> <li>• Networking Opportunities</li> <li>• SAMPE Award Luncheon</li> <li>• SAMPE Fellow Banquet</li> </ul>
--	--	--

\* Nearly 300 companies on site eager to discuss their products and services. There is still some exhibit space available—contact SAMPE now to arrange space for your company or just come by to see the newest technology.



**PLEASE PRINT—Bring completed form with you to Long Beach.**

☐ (CM) SAMPE Member

☐ (CN) SAMPE Non-Member

Name \_\_\_\_\_ Title \_\_\_\_\_

Company \_\_\_\_\_

Address \_\_\_\_\_

City \_\_\_\_\_ State \_\_\_\_\_ Zip \_\_\_\_\_

Country \_\_\_\_\_ E-Mail \_\_\_\_\_

Phone \_\_\_\_\_ Fax \_\_\_\_\_

**SAMPE INTERNATIONAL BUSINESS OFFICE**  
PO Box 2459 Covina, CA 91722-8459 • [sampeibo@aol.com](mailto:sampeibo@aol.com)

"Visit the SAMPE Show, and meet with NASA's hottest innovators"



# Solar Simulator for a Portable Solar-Absorptance Instrument

The principal advantages are portability and accurate normalized AM0 spectrum.

John F. Kennedy Space Center, Florida

A special-purpose solar simulator includes (1) a tungsten lamp that serves as a gray-body radiator with a temperature of 3,200 K and (2) a mosaic of filters such that the filtered lamp output has the same normalized spectral irradiance as that of sunlight outside the atmosphere of the Earth. This solar simulator is intended for use as the illuminator in a portable instrument

that measures solar absorptances and total emittances of samples of materials.

The extra-atmospheric sunlight spectrum [also known as the air mass zero (AM0) spectrum] in question is the one described in standard E490-73a of the American Society for Testing and Materials (ASTM). The present solar simulator was developed because previously devel-

oped solar simulators are unsuitable for a variety of reasons: some do not cover the wavelength range (300 to 2,800 nm) required in the design specification for the instrument, some are too power-hungry and/or not durable enough for inclusion in a portable instrument, and some deviate too much from the ASTM standard.

The mosaic of filters includes commercially available filters plus a keystone filter developed specifically for this application. The mosaic was designed by use of a mathematical model based on the transmittance characteristics of the filters. The model was evaluated against optical "bread board" measurements. Areas, overlaps, and other design parameters were determined for the finished filter configuration.

A prototype instrument was built for proof of design. All design specifications relating to the filter were met: The filtered lamp output covers the spectral range from 300 to 2,800 and agrees more than 95 percent with the ASTM standard sun. Solar-absorptance measurements taken by the instrument are characterized by errors with magnitudes of less than 3 percent (that is, within a range of  $\pm 3$  percent) of total absorptance.

The major benefit afforded by the design of this solar simulator is portability arising from low power consumption (relative to other solar simulators) and robustness. In addition, the compactness of the solar simulator (relative to other solar simulators) made it possible to integrate both the measurement of solar absorptance and the measurement of emittance into a single instrument package, whereas it would otherwise have been necessary to package them as separate instruments. Other benefits afforded by the design of the overall instrument are that a measurement can be made in <1 minute, and the instrument is more economical than are spectroradiometric systems.

The original intended use of the instrument is in measuring the radiative properties of components of the International Space Station. The instrument could also be used to measure the radiative properties (especially with respect to thermal radiation) of coatings and other materials, particularly in the aerospace industry.

*This work was done by David G. Crandall and John S. Harchanko of AZ Technology, Inc., for Kennedy Space Center. For more information, contact the Kennedy Commercial Technology Office at 321-867-6224. KSC-12069*

## HIGH FLOW pressure control to 30,000<sup>1</sup> scfm!

- Inlet pressures up to 6,000 PSIG
- Control pressure ranges of 1-6,000 PSIG
- Heavy duty construction - choice of brass or 316 SST
- Modular construction style allows easy servicing
- Inlet and outlet port sizes to 1 1/4"
- SAE, NPT or MS 33649 ports are standard
- Welded flanges available

**TESCOM**  
CORPORATION

1-800-447-1250  
www.tescom.com



Global support & distribution • Design/manufacture in the US, Germany & Asia

<sup>1</sup> with 6,000 PSIG inlet, 3,000 PSIG outlet,  $C_v=12$ , media: N<sub>2</sub>




## Portable Instrument Detects Very Dilute Airborne Organics

This instrument offers an attractive alternative to GC/MS.

NASA's Jet Propulsion Laboratory, Pasadena, California

A small, lightweight, low-power instrument, denoted a proton-transfer-reaction/ion-mobility spectrometer (PTR-IMS) has been developed for detecting airborne organic compounds at concentrations in the sub-parts-per-billion range. Instruments like this one could be used on distant planets (such as Mars) to search for trace organic compounds indicative of life as well as



HOLLOW-CATHODE IONIZER



ION-MOBILITY SPECTROMETER AND ASSOCIATED COMPONENTS

The Hollow-Cathode Ionizer generates reactant ions which then ionize target organic species. The target ions are then analyzed in the ion-mobility spectrometer.

numerous potential terrestrial uses: A few examples include medical applications (e.g., analyzing human breath to detect compounds associated with certain deadly diseases such as lung cancer and cirrhosis of the liver), law-enforcement applications (detecting airborne traces of explosives and drugs), environmental monitoring (detecting airborne pollutants and toxins), and military applications (detecting chemical warfare agents).

Portable gas-chromatography/mass-spectrometry (GC-MS) instruments that have commonly been used heretofore for detecting airborne organic compounds are characterized by three major shortcomings: (1) insufficient sensitivity for detecting sub-parts-per-billion concentrations, (2) susceptibility to undesired fragmentation of large organic molecules, and (3) the need for high vacuum and thus for high-vacuum equipment, which contributes greatly to size, weight, and mechanical complexity. In contrast, the PTR-IMS offers sensitivity adequate for detecting concentrations at the parts-per-billion level; operates in such a manner as not to fragment large organic molecules; and requires only a partial vacuum that can be generated by equipment smaller, lighter, and less complex than that needed for GC/MS.

The PTR-IMS includes a hollow-cathode ionizer, HCI (see figure), that

## Optical Liquids Catalog



Write or call for free catalog.

New catalog of specialty optical liquids features high-transmission, safe-handling, laser liquids, plus fused silica matching liquids, and specific refractive index liquids (1.300-2.11  $n_D$ ). Now includes comparative diagrams of glasses and optical liquids.



**Cargille Laboratories Inc.**

55 Commerce Road, Cedar Grove, NJ 07009  
973-239-6633 • Fax 973-239-6096

For Free Info Circle No. 451 or  
Enter No. 451 at [www.nasatech.com/rs](http://www.nasatech.com/rs)

## High Precision Non-contact Displacement, Position, Vibration and Thickness Measurements



In-process Displacement Measurements

### CMOS Laser Sensors:

- Range 0 - 40 mm
- Resolution 0.1  $\mu\text{m}$
- Linearity  $\pm 0.03\%$  FS
- Frequency 20 kHz



Vibration Monitoring

### Fiber-optic Sensors:

- Range: 0 - 25 mm
- Resolution 0.00025  $\mu\text{m}$
- Linearity  $\pm 0.2$  FS
- Frequency 1MHz



Micro positioning

### Capacitance Sensors:


- Range 0 - 25 mm
- Resolution 0.0001  $\mu\text{m}$
- Linearity  $\pm 0.02\%$
- Frequency 20 kHz



325 Washington Avenue Extension, Albany, NY 12205  
800-342-2203 (USA toll-free) • 518-218-2550 (phone) • 518-218-2506 (fax)  
[sales@mtiinstruments.com](mailto:sales@mtiinstruments.com) (e-mail) • [www.mtiinstruments.com](http://www.mtiinstruments.com)



is designed to generate reactant ions ( $RH^+$ , where R is a reactant molecule) and to exploit a proton-transfer reaction. The HCI operates at a pressure in the approximate range of 1 to 5 torr ( $\approx 0.1$  to  $0.7$  kPa).  $H_2O$  is introduced into the discharge region inside the HCI, giving rise to the proton-transfer reaction



where M is the target molecule and  $MH^+$  is the desired product ion. R is chosen to be a molecule that has a proton affinity slightly less than that

of M, in which case the probability for fragmentation channels of the proton-transfer reaction is low and the process of "soft" ionization is dominant. Moreover, the reaction is highly selective: Molecules that have proton affinities lower than that of R do not enter the reaction.  $H_3O^+$  is the most suitable proton-donor reactant ion for investigating trace chemical species in either Martian or Earth air because  $H_3O^+$  does not react with  $CO_2$ , CO,  $H_2O$ ,  $O_2$ ,  $N_2$ , He, Ne, Ar, or Xe.

The ions produced by the HCI are introduced along with a sample of air into a reaction chamber. Product ions generated in the reaction chamber are detected and analyzed in the IMS, which was chosen over conventional mass spectrometers and other instruments because it offers the sensitivity needed for detection in the sub-part-per-billion range, can handle a wider range of molecules, and does not require a high vacuum (it can even operate at normal terrestrial atmospheric pressure). In the IMS, a bias voltage produces an electric field that causes the reactant and product ions to drift in a desired direction. At the downstream end of the drift region, ions are detected by use of a high-gain electrometer; typically, the detected ion current can be on the order of a picoampere. A microprocessor controls the operation of the instrument and the acquisition, processing, and display of data.

In order to enable the determination of drift velocities, the ions are introduced into the drift region in pulses at time intervals typically between 20 and 40 ms. Within the drift region, the ions undergo spatial separation based on both mass and shape. For a given electric-field strength, the drift velocity of a given ion species is directly proportional to its specific mobility. Smaller ions tend to travel faster. By measuring the ion-drift times under a particular set of conditions, one can construct ion-mobility tables that can be used for identification of unidentified target ion species.

*This work was done by Isik Kanik and Luther Beegle of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Physical Sciences category.*

*In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to*

*Intellectual Property group  
JPL*

*Mail Stop 202-233  
4800 Oak Grove Drive  
Pasadena, CA 91109  
(818) 354-2240*

*Refer to NPO-21187, volume and number of this NASA Tech Briefs issue, and the page number.*

**MAGNETIC SHIELD**

**The Perfect Shield**  
for magnetic interference problems

...and custom engineered solutions by shape, size & configuration and finish using co-netic® or netic® alloys and foils for your OEM applications

©2001 Magnetic Shield Corporation  
co-netic & netic—RegTM Magnetic Shield Corporation

**FREE Magnetic Shield Calculator**  
... ask for it today!

**MAGNETIC SHIELD CORP.**  
CO-NETIC  
NETIC  
PERFECTION MICA CO.

The cylinder is the most perfect shield. Our customers know this ... and they know Electro Magnetic Interference (EMI) problems require custom designs that are not always cylindrical. For sixty years, they have been relying on our knowledgeable engineers to solve EMI problems with shielding designs that fit

tight tolerances or entire buildings.

Visit our web site for "Magnetic Shielding Lab Kit & Catalog Guide" ... eliminate EMI in your OEM designs.

MAGNETIC SHIELD CORP.  
740 N. Thomas Dr., Bensenville, IL 60106

TOLL-FREE 800-495-5665

IMMEDIATE [magneticshield.com](http://magneticshield.com)





## Books & Reports

### Quantum Mechanics of Harmonic Oscillator in External Fields

A report presents a theoretical study of a harmonic oscillator in homogeneous or nonhomogeneous externally applied electric and/or gravitational fields. The standard quantum-mechanical formalism for a simple harmonic oscillator, starting with the Hamiltonian and the associated creation and annihilation operators, is modified to incorporate the additional terms representing the external fields. The correspondingly modified solutions of the Schrodinger equation are derived.

*This work was done by Igor Kulikov of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Harmonic Oscillator in External Fields: Theory and Applications," access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Physical Sciences category. NPO-30262*

### Algorithms for Collision-Avoidant Formation Flying

A report discusses algorithms for real-time planning of translation paths of multiple spacecraft flying in formation. The algorithm takes account of requirements to avoid collisions while operating within resource constraints (e.g., not calling for an acceleration greater than maximum possible) and striving for optimality (e.g., completing a change of formation in minimum time or at minimum energy cost). The optimality/collision-avoidance problem is formulated as a parameter-optimization problem, in which the translation path of each spacecraft is parameterized by polynomial functions of time. It is shown that this parameterization is the key to the solution of the parameter-optimization problem in that it enables decoupling of the collision-avoidance and acceleration-limit constraints, thereby making it possible to solve the problem in two stages. In the first stage, one constructs feasible paths that satisfy only the collision-avoidance constraints subject to certain optimality criteria. It is shown that the acceleration-limit constraints can be imposed *a posteriori* to compute the required maneuver duration such that at least one acceleration component is saturated. This also enables construction of paths

that require minimum time in the class of solutions being considered.

*This work was done by Gurkirpal Singh and Fred Hadaegh of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Collision Avoidance Guidance for Formation-Flying Applications," access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Mechanics category.*

*This software is available for commercial licensing. Please contact Don Hart of the California Institute of Technology at (818) 393-3425. Refer to NPO-30332.*

### Integrated Colloid Thrusters for Microspacecraft

A report proposes the development of a microfabricated, integrated colloid thruster as a prototype of devices for propulsion and control of the attitudes of microspacecraft. (In a colloid thruster, a beam of positively charged, microscopic droplets is extracted electrohydrodynamically from a column of liquid and accelerated electrostatically to produce thrust.) Unlike other electrical thrusters, colloid thrusters are amenable to extreme miniaturization. The direction of thrust would be controlled electronically through selective activation of accelerator electrodes, eliminating the need for mechanical gimbals.

*This work was done by Mohammed Mojaradi, Juergen Mueller, Jay Polk, and Colleen Marrese-Reading of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "A Fully Integrated Micro-Colloid Thruster System for Microspacecraft Applications," access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Machinery/Automation category.*

*In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to*

*Intellectual Assets Office*

*JPL*

*Mail Stop 202-233*

*4800 Oak Grove Drive*

*Pasadena, CA 91109*

*(818) 354-2240*

*E-mail: [ipgroup@jpl.nasa.gov](mailto:ipgroup@jpl.nasa.gov)*

*Refer to NPO-20945, volume and number of this NASA Tech Briefs issue, and the page number.*



**BERG**

**W. M. BERG, INC.**  
PRECISION MECHANICAL COMPONENTS

**Has the Solution!**

**for all your precision mechanical component needs, from Design Concept to Production and beyond!**

Order your free catalog today!

**W.M. BERG, INC.**

499 Ocean Ave.  
E. Rockaway, NY 11518  
Phone: 800-232-BERG  
Fax: 800-455-BERG  
[www.wmberg.com](http://www.wmberg.com)

For Free Info Circle No. 493 or  
Enter No. 493 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## FLEXIBLE BLADDERS

**NASA Qualified**


- BLADDER TANKS & AIR CELLS
- DIAPHRAGMS & ACTUATORS
- BELLOWES & FUEL CELLS
- STRESS TEST BLADDERS
- CUSTOM INFLATABLES
- PNEUMATIC / HYDRAULIC PRESSES

**800-526-5330**

**AERO TEC LABORATORIES INC.**  
RAMSEY, NJ 07446-1251 USA  
TEL: 201.825.1400 • FAX: 201.825.1962  
e-Mail: [aerotec@cybernex.net](mailto:aerotec@cybernex.net)  
[www.atilinc.com](http://www.atilinc.com)

For Free Info Circle No. 454 or  
Visit [www.nasatech.com/454](http://www.nasatech.com/454)

**New!**



## Mechanical Engineer's Handbook

An essential companion for the mechanical engineer. With over 1,000 pages, 550 illustrations,

and 26 tables, the Mechanical Engineer's Handbook is comprehensive yet affordable and portable. It covers all major areas of mechanical engineering & design with succinct definitions, formulas, and examples.

**Hardcover • 1,100 pages**  
**Introductory price: \$67.95**

**Order online:**  
[www.nasatech.com/store](http://www.nasatech.com/store)



## PCI Bridge to Instruments and Telecommunication Systems

A report describes a prototype system interface assembly (SIA) that performs the functions of a compact, radiation-hard application-specific integrated circuit (ASIC) to be built subsequently. The SIA ASIC would be installed in a spacecraft, where it would function as a peripheral-component interface (PCI) with (a) four scientific instruments that generate high-speed serial data streams and (b) either of two spacecraft telecommunication systems

— the Small Deep Space Transponder (SDST) or the Space Transponding Modem (STM). Once configured, the serial uplink and downlink channels would conform to the SDST serial interface protocol or the STM modified serial peripheral interface protocol. In the SDST configuration, the downlink could be further configured for Reed-Solomon coding, for turbo coding, for bypass mode, and/or to enable a pseudo-randomizer. The SIA ASIC would operate in conjunction with a bus controller/remote terminal/monitor ASIC (United Technologies BCRTM or equivalent) to provide the control and sta-

tus interfaces to the telecommunication systems and/or other systems that conform to MIL-STD-1553 devices. The ASIC would control, and would serve as an interface to, memory circuitry configurable by the user as external first-in/first-out buffers for each of the telecommunication and instrument interfaces.

*This work was done by Anwar Akhtar, Martin Le, John Gilbert, Alfred Khashaki, Carl Steiner, Donald Johnson, Dwight Geer, Julianne Romero, Keizo Ishikawa, Kenneth Crabtree, and Leonard Day of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "PCI Bridge to Telecom and Four Instrument Interfaces," access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Electronic Components and Systems category. NPO-30278*

(Award-winning)

# Lubes & Greases

## Industrial Applications

Award-winning "Tufoil" lubricants reduce wear, noise and friction while keeping downtime to a minimum. Highly recommended for machinery, compressors, gear boxes, etc. Our High-Temperature Grease is superb on high speed rotating equipment. Try Lubit-8 and Gun-Coat on steel parts. They clean, lubricate and preserve. Fantastic rust inhibitors!

## Thread Sealants

Oxygen-safe Lox-8 and Formula-8 were designed for use with aggressive chemicals such as chlorine or powerful oxidizers. Recent NASA testing confirms their effectiveness. Each has an extreme temperature and pressure range. Used for decades by major gas manufacturers worldwide. Use with gas, liquid and vacuum services.

1-800-922-0075

Call today and ask for one of our extensive brochures or speak with an engineer. We will be happy to discuss your specific lubrication problem and recommend a sample for your application. You can also visit us on the web at [www.fluoramics.com](http://www.fluoramics.com) where you will find data sheets and MSDS.

Fluoramics Inc.  
1-800-922-0075

[www.fluoramics.com](http://www.fluoramics.com)  
201-825-8110  
Fax: 201-825-8110

Engineering  
Lubricants  
& Sealants  
Since 1967

## Effect of Gravitation on Noninteracting Trapped Fermions

A report presents a theoretical study of the thermodynamics of an ultralow-temperature gas of fermions that interact with a gravitational field and with an externally imposed trapping potential but not with each other. The gravitational field is taken to define the  $z$  axis and the trapping potential to be of the form  $(m/2)(\omega_x^2 x^2 + \omega_y^2 y^2 + \omega_z^2 z^2)$ , where  $m$  is the mass of a fermion;  $x$ ,  $y$ , and  $z$  are Cartesian coordinates originating at the center of the trap; and the  $\omega$  values denote effective harmonic-oscillator angular frequencies with respect to motion along the respective coordinate axes. The single-particle energy is found from the solution of the time-dependent Schrodinger equation for a Hamiltonian that includes kinetic energy plus the gravitational and trapping potentials. The equation for the single-particle energy is combined with Fermi statistics to obtain equations for the chemical potential, internal energy, and specific heat of the gas; the number of trapped fermions; and the spatial distribution of fermions at zero temperature. The equations reveal the ways in which the Fermi energy, the specific heat, and the shape of the Fermion cloud are affected by the gravitational field and the anisotropy of the trapping field.

*This work was done by Igor Kulikov of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "An Influence of Gravitational Field on Properties of Trapped Fermions," access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Physical Sciences category. NPO-30248*



## ✚ Improvements in a Piezoelectrically Actuated Microvalve

A report discusses the continuing development of a normally closed, piezoelectrically actuated valve fabricated mostly by micromachining of silicon. The design and operation of the microvalve as described in the instant report are basically the same as those of the version described in "Improved Piezoelectrically Actuated Microvalve" (NPO-30158), *NASA Tech Briefs*, Vol. 26, No. 1 (January 2002), page 29. Major elements of design described in both the instant report and the cited prior article include (1) a pressure-aided sealing configuration that contributes to the desired normally-closed mode of operation and (2) knife-edge sealing rings that reduce susceptibility to trapping of particles and the consequent leakage. The report also presents additional information concerning details of design and fabrication, including, notably, additional justification for knife-edge (in contradistinction to blunt-cross-section) sealing rings: The knife-edge sealing rings provide greater sealing pressure at a given seal-

ing force, thereby reducing the leak rate and even making it possible to achieve an adequate seal with a hard seat. A potential additional advantage of the knife-edge/hard-seat design is that contact pressures may be high enough to crush contaminant particles, thereby reducing the leakage attributable to contaminants.

*This work was done by Eui-Hyeok Yang, Larry Wild, and Nishant Rohatgi of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "A Micro Valve for High Pressure Applications," access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Mechanics category.*

*In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to*

*Intellectual Assets Office  
JPL*

*Mail Stop 202-233  
4800 Oak Grove Drive  
Pasadena, CA 91109  
(818) 354-2240*

*E-mail: [ipgroup@jpl.nasa.gov](mailto:ipgroup@jpl.nasa.gov)*

*Refer to NPO-30338, volume and number of this NASA Tech Briefs issue, and the page number.*

## ✚ Low-Energy Transfer From Near-Earth to Near-Moon Orbit

A report presents a theoretical approach to designing a low-energy transfer of a spacecraft from an orbit around the Earth to ballistic capture into an orbit around the Moon. The approach is based partly on the one presented in "Low-Energy Interplanetary Transfers Using Lagrangian Points" (NPO-20377), *NASA Tech Briefs*, Vol. 23, No. 11 (November 1999), page 22. The approach involves consideration of the stable and unstable manifolds of the periodic orbits around the Lagrangian points L1 and L2 of the Sun/Earth and Earth/Moon systems. (The Lagrangian points are five points, located in the orbital plane of two massive bodies, where a much less massive body can remain in equilibrium relative to the massive bodies.)

*This work was done by Martin Lo, Jerrold Marsden, Wang S. Koon, and Shane Ross of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Low Energy Lunar Transfer and Capture," access the Technical Support Package (TSP) free on-line at [www.nasatech.com/tsp](http://www.nasatech.com/tsp) under the Mechanics category. NPO-20936*

[www.ansys.com/nastran](http://www.ansys.com/nastran)



# LITERATURE & WEB SITE SPOTLIGHT

Free catalogs and literature for NASA Tech Briefs' readers. To order, circle the corresponding number on the Readers Information Request Form on page 81.



## OMEGA® MADE IN THE USA EDITION HANDBOOKS™

The OMEGA® Made in the USA Edition Handbooks™, Volume I and II are 3,000-page hardbound color handbooks with over 100,000 products, all made in the USA. This edition features many Temperature, Pressure, Force, Flow, Level, pH, Conductivity, Humidity, and Data Acquisition instruments. Load Cells, Panel Meters, Controllers, Recorders, Thermocouples, Thermistors, and Connectors are included. OMEGA Engineering, One Omega Dr., Stamford, CT 06907; Tel: 1-888-TC-OMEGA; www.omega.com

**OMEGA Engineering, Inc.**

For Free Info Circle No. 660 or  
Enter No. 660 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## OMEGA GREENCAT™ NEW HORIZONS IN ENVIRONMENTAL MEASUREMENT & INSTRUMENTATION

The Greencat™ Product Preview from the upcoming OMEGA Volume MM® Environmental Handbook contains brand new technology products for Process Measurement and Control from mini-infrared guns with circle dot laser precision, data-logging digital thermometers with dual input features to general test equipment DMMs. OMEGA Engineering, One Omega Dr., Stamford, CT 06907; Tel: 1-888-TC-OMEGA; www.omega.com

**OMEGA Engineering, Inc.**

For Free Info Circle No. 661 or  
Enter No. 661 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## DILBERT™ BLUECAT® NEW HORIZONS® IN DATA ACQUISITION

The BLUECAT® New Horizons® Product Preview of the Data Acquisition Handbook features 90 Dilbert Cartoons and the latest products for the DAS market from Ethernet-Enabled Meters, Controllers and Signal Conditioners; Multifunction, PCI-Bus A/D Boards; DIN Rail Signal Conditioners; Power Line Monitors; Portable Dataloggers; Wireless Transmitters; and Infrared Pyrometers. Every product can be purchased online. OMEGA Engineering, One Omega Dr., Stamford, CT 06907; Tel: 1-888-TC-OMEGA; www.omega.com

**OMEGA Engineering, Inc.**

For Free Info Circle No. 662 or  
Enter No. 662 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## DILBERT™ OMEGATEMP™ NEW HORIZONS® IN TEMPERATURE, MEASUREMENT & CONTROL

The OMEGATEMP™ New Horizons® in Temperature Measurement & Control features 42 Dilbert Cartoons and the latest products from Non-Contact IR Temperature Measurement; Temperature Probes & Sensors; Industrial Meters & Controllers; Laboratory Calibration Equipment; Transmitters, and Recorders & Data Loggers for Temperature & Humidity Measurement. OMEGA Engineering, One Omega Dr., Stamford, CT 06907; Tel: 1-888-TC-OMEGA; www.omega.com

**OMEGA Engineering, Inc.**

For Free Info Circle No. 663 or  
Enter No. 663 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## EWS SERIES ENVIRONMENTAL WALL MOUNT SENSORS

OMEGA's new low-cost environmental wall mount sensors keep your office, computer room or laboratory's décor looking great at an economical price. These miniature units come in 6 models that will interface directly with most process meters, controllers, recorders, data loggers, and data acquisition systems. Thermocouple, RTD and Thermistor models come with 914 mm (36") leads standard. For more information, go to the OMEGA Engineering Inc. Website at [www.omega.com/Temperature/pdf/EWS\\_MNT\\_ALL.pdf](http://www.omega.com/Temperature/pdf/EWS_MNT_ALL.pdf)

**OMEGA Engineering, Inc.**

For Free Info Circle No. 664 or  
Enter No. 664 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## HH501DK 4-CHANNEL TYPE-K THERMOMETER

The OMEGA® HH501DK is a rugged, easy to use thermometer with 4 standard miniature connector inputs. It accepts K type thermocouple probes and covers ranges from -50 to 1300°C (-58 to 1999°F). It also provides differential temperature measurement readings of T1-T2, T1-T3, T1-T4, as well as individual readings of the 4 inputs. Price is \$95. For more information, go to the OMEGA Engineering, Inc. Web site at [www.omega.com/Temperature/pdf/HH501DK.pdf](http://www.omega.com/Temperature/pdf/HH501DK.pdf)

**OMEGA Engineering, Inc.**

For Free Info Circle No. 665 or  
Enter No. 665 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## SUPERMETER™ AUTO-RANGING DIGITAL MULTIMETER/THERMOMETER

OMEGA's new, patented, all-in-one SUPERMETER Model HHM290 combines the power of a true RMS full-function Multimeter, Non-contact Infrared Pyrometer with laser sighting, and a Dual Input Type-K Thermocouple meter with a differential measurement feature. The Multimeter measures DC/AC Voltage, Current, Resistance, Frequency, and Capacitance, and the Infrared Pyrometer offers adjustable emissivity and a wide temperature range. For more information, go to the OMEGA Engineering, Inc. Web site at [www.supermeter.net](http://www.supermeter.net)

**OMEGA Engineering, Inc.**

For Free Info Circle No. 666 or  
Enter No. 666 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## OMEGACAT™ IN PRESSURE MEASUREMENT AND INSTRUMENTATION

The OMEGACAT™ in Pressure Measurement and Instrumentation contains technology products for pressure measurement, including transducers, switches, transmitters, barometers, nanometers, calibrators, process meters & controllers, and strain indicators, as well as the latest full-function digital multimeter thermometer with built-in non-contact infrared temperature measurement and switchable laser circle or dot sighting. For more information, go to the OMEGA Engineering, Inc. Web site at [www.omegacat.com](http://www.omegacat.com)

**OMEGA Engineering, Inc.**

For Free Info Circle No. 667 or  
Enter No. 667 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## HH550 GRAPHIC RECORDER/DATALOGGER/DATA PRINTER

The HH550 is a powerful graphic recorder/datalogger/printer. Designed for laboratory or process engineering use, the unit accepts an analog signal for local display, local printing, and/or storage to be downloaded to a PC. Datalogging capacity is 50,000 records. OMEGA-SOFT® Windows software is provided to allow setup, graphing, listing of data and exporting data to an Excel spreadsheet. For more information, go to the OMEGA Engineering, Inc. Web site at [www.omega.com/ppt/pptsc.asp?ref=HH550](http://www.omega.com/ppt/pptsc.asp?ref=HH550)

**OMEGA Engineering, Inc.**

For Free Info Circle No. 668 or  
Enter No. 668 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## STRESS ANALYSIS MADE EASY

Beam 2D delivers instant, detailed analysis of complex statically indeterminate and determinate beams. Created specifically for mechanical and structural designers, this program is all you need to tackle problems involving multi-support, multi-load, multiple cross-section beams quickly and effortlessly. Features include a pop-up cross-section properties calculator, built-in databases of beam properties, shear deflection analysis, and much more. Free trial download: [www.orandsystems.com](http://www.orandsystems.com). Orand Systems Inc.; Tel: 905-569-0055; Fax: 905-569-0045.

### Orand Systems Inc.

For Free Info Circle No. 669 or  
Enter No. 669 at [www.nasatech.com/rs](http://www.nasatech.com/rs)

## TEMPERATURE MEASUREMENT SOLUTIONS

For 30 years, Lake Shore has been an international leader in measurement and control solutions. Lake Shore's new full-color temperature product guide features our complete line of cryogenic temperature sensors and instruments including the new 211 Temperature Monitor, 332 Temperature Controller, 370 AC Resistance Bridge, and DT-670 Silicon Diode temperature sensor. Lake Shore Cryotronics, Inc.; Tel: 614-891-2244 or 800-394-2243; Fax: 614-818-1600; e-mail: [marketing@lakeshore.com](mailto:marketing@lakeshore.com); [www.lakeshore.com](http://www.lakeshore.com)

### Lake Shore Cryotronics, Inc.

For Free Info Circle No. 672 or  
Enter No. 672 at [www.nasatech.com/rs](http://www.nasatech.com/rs)

## POROUS CERAMIC VACUUM CHUCK

PhotoMachining offers a porous ceramic vacuum chuck for use with thin films and other flat samples. Pore sizes under 25 microns assure uniform suction and holding power for even the smallest parts. PhotoMachining also provides contract laser-manufacturing services, and designs and builds custom laser-based manufacturing equipment. PhotoMachining, Inc., 4 Industrial Dr., Unit 40, Pelham, NH 03076; Tel: 603-882-9944; Fax: 603-886-8844; [rschaeffer@photomachining.com](mailto:rschaeffer@photomachining.com); [www.photomachining.com](http://www.photomachining.com)

### PhotoMachining, Inc.


For Free Info Circle No. 675 or  
Enter No. 675 at [www.nasatech.com/rs](http://www.nasatech.com/rs)

## FMEA SOFTWARE

Failure Modes and Effects Analysis using FMEA-Pro™ 5 empowers automotive, consumer, electronic, aerospace, defense and general manufacturing industries to improve the quality, reliability and safety of their products. This fully customizable software helps companies comply with QS 9000, ISO 9000, SAE J1739, MIL-STD-1629, ISO/TS 16949 and other regulations. FMEA-Pro™ 5 contains extensive libraries and data protection features. The report generation tools support a variety of file formats, including HTML and PDF. Download a free trial: [www.fmeasoft.com](http://www.fmeasoft.com).

### Dyadem International Ltd.

For Free Info Circle No. 678 or  
Visit [www.nasatech.com/678](http://www.nasatech.com/678)



**REMOTE VIEWING INSTRUMENTS**  
Select from over 2,000 standard RVT's for inspecting engines, air frames or components located in inaccessible areas. New, exclusive Camera Dedicated Bore-scopes, and patented ProTech™ Fiberscopes and Videoscopes. Custom and OEM scopes a specialty. ITI, the leader in Remote Viewing. Instrument Technology, Inc., PO Box 381, 33 Airport Rd., Westfield, MA 01086-0381; Tel: 413-562-3606; Fax: 413-568-9809; e-mail: [iti@scopes.com](mailto:iti@scopes.com); [www.scopes.com](http://www.scopes.com)

### Instrument Technology, Inc.

For Free Info Circle No. 670 or  
Enter No. 670 at [www.nasatech.com/rs](http://www.nasatech.com/rs)

## POWER EQUIPMENT COMPONENTS

We are ISO 9001 certified with over 50 years experience in research, development, manufacturing, and design of superior power equipment components. Clutches, torque converters, geared transmissions, high-performance gas shock absorbers, brake bands, drums, rotors and hubs are some of our products. Put your confidence in Comet. We supply per OEM specifications. Applications include City Cars, Utility Vehicles, Snowmobiles, Go-Karts, and Concrete finishing equipment. Call 800-999-8161 for a free brochure or visit [www.comet-oem.com](http://www.comet-oem.com)

### Comet Industries

For Free Info Circle No. 673 or  
Enter No. 673 at [www.nasatech.com/rs](http://www.nasatech.com/rs)

## SOURCE CALIBRATOR

Krohn-Hite Corp. introduces the NEW Model 511 precision dc voltage source/calibrator covering the range from  $\pm 100n$  Vdc to  $\pm 10$  Vdc over 3 ranges with  $\pm 10$  ppm accuracy and  $\pm 2$  ppm stability guaranteed for a full year. Resolution is 1 ppm of range. Applications include 16/18 bit DAC testing, strip chart recorders, calibration of data logging systems, and more. For more information visit our Web site at [www.krohn-hite.com/Model511.htm](http://www.krohn-hite.com/Model511.htm) or call 508-580-1660.

### Krohn-Hite Corporation

For Free Info Circle No. 676 or  
Enter No. 676 at [www.nasatech.com/rs](http://www.nasatech.com/rs)

## AWARD WINNING FLUID FLOW SOFTWARE

Design Flow Solutions (DF) DesignNet provides complete hydraulic analysis of piping networks for both gases and liquids. Network branches can consist of any combination of pipe, fittings, and valves, with virtually no limit on components. DesignNet solves networks using the Darcy-Weisbach and Bernoulli's for liquids and the differential form of Bernoulli's theorem together with numerical integration techniques for gases. Considers sonic flow and the heat transfer limitations for gases. New training manual is now available. ABZ, Inc.; Tel: 800-747-7401; Fax: 703-631-5282; [www.abzinc.com](http://www.abzinc.com)

### ABZ, Incorporated

For Free Info Circle No. 677 or  
Enter No. 677 at [www.nasatech.com/rs](http://www.nasatech.com/rs)

## PRECISION ENCODERS

New 98-page catalog gives in-depth specifications and descriptions of Accu-Coder™ brand encoders by Encoder Products Company. Catalog features a full line of Cube™, industry-standard size 15, size 20, size 25, size 58mm, C-face, NEMA mount and hollow shaft encoders, with a wide selection of configuration options, suitable for a wide variety of industrial counting, motion, and motor control applications. Encoder Products Company; Tel: 800-366-5412; Fax: 800-263-0541; [www.encoderproducts.com](http://www.encoderproducts.com)

### Encoder Products Company

For Free Info Circle No. 680 or  
Visit [www.nasatech.com/680](http://www.nasatech.com/680)





## TANGLESS® AND TANGLED HELICAL COIL INSERTS, TOOLS & THREAD REPAIR KITS

New 56-page catalog is the most comprehensive of its kind in the industry! It features the revolutionary Tangleless® CoilThread® Insert design from KATO®. Tangleless Inserts are bi-directional, FOD-free, removable, and they eliminate the labor-intensive and destructive tang break-off operation. Also included are taps, gages, hand, electric, and air tools for insertion. All KATO products meet or exceed applicable military, aerospace, and commercial standards. Kato Fastening Systems, Newport News, VA; Tel: 757-873-8980; Fax: 757-873-4920; [www.katonet.com](http://www.katonet.com)

### Kato Fastening Systems

For Free Info Circle No. 681 or Visit [www.nasatech.com/681](http://www.nasatech.com/681)



## INTERACTIVE PRECISION MECHANICAL COMPONENTS

Over 50,000 Components: bearings, belts & pulleys, shafts, couplers, gears, hardware, slides, lead screws & nuts, positioning tables, linear motion systems and more.

- Easy Online Ordering
- Application Guides
- Design formulas and calculators
- CAD drawings

Also in print - ask for Catalog 44. PIC Design; Tel: 800-243-6125; Fax: 203-758-8271; e-mail: [deptn@pic-design.com](mailto:deptn@pic-design.com); [www.pic-design.com](http://www.pic-design.com)

### PIC Design

For Free Info Circle No. 682 or Enter No. 682 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## TUSK DIRECT'S IN-STOCK LINEAR MOTION PRODUCTS

Free linear motion catalog in print, CD-ROM and on the

Web is a resource for design engineers working with linear motion and needing linear bearings of many types quickly. Included are dimensions, specifications and CAD drawings for ball slides, roller slides, heavy duty crossed roller tables, multi-axis positioning tables, recirculating slide guides, pillow blocks, shafts, hangers, supports, and linear bearing and automation components. Tusk Direct; Tel: 800-447-2042; Fax: 203-748-5147; e-mail: [sales@tuskdirect.com](mailto:sales@tuskdirect.com); [www.tuskdirect.com](http://www.tuskdirect.com)

### Tusk Direct

For Free Info Circle No. 683 or Enter No. 683 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## CYROGENIC LIQUID AUTO-FILL SYSTEM

Safely protect your investment by not running out of liquid nitrogen. American Magnetics, Inc. Cryogenic Liquid Level Controllers, used in conjunction with a level probe, solenoid valve,

and VJ transfer-line, can keep your critical devices full without manual attention. A wide variety of probe designs allows filling of vessels smaller than 1 liter in volume. American Magnetics, Inc.; Tel: 865-482-1056; e-mail: [sales@americanmagnetics.com](mailto:sales@americanmagnetics.com); [www.americanmagnetics.com](http://www.americanmagnetics.com)

### American Magnetics, Inc.

For Free Info Circle No. 684 or Enter No. 684 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## CUSTOM CERAMIC COMPONENTS

Part shapes to solve functional problems for environments where plastics and metals will not work.

- Withstands Extremely High Temperatures

- Threaded Components
  - Exacting Tolerances
  - Stock Hex-Head Alumina Nuts & Bolts
  - Resists Corrosion and Abrasion
  - Simple to Complex Shapes
  - Affordable Tooling
- Ceramco, Inc., Center Conway, NH; Tel: 603-447-2090; Fax: 603-447-3906; e-mail: [info@ceramcoceramics.com](mailto:info@ceramcoceramics.com); [www.ceramcoceramics.com](http://www.ceramcoceramics.com)

### Ceramco, Inc.

For Free Info Circle No. 685 or Visit [www.nasatech.com/685](http://www.nasatech.com/685)




## GSOLVER DIFFRACTION ANALYSIS

GSOLVER V4.20 performs rigorous diffraction efficiency calculations for arbitrary periodic grating structures, including all polarizations. The full vector calculation solves Maxwell's equations through the coupled wave method, and is completely general. GSOLVER is ideally suited for complex grating structures used in telecommunications applications created in dielectrics and metals. Visit our web site to obtain a free full functional (for 30 days) "demo" version. Grating Solver Development Co.; [www.gsolver.com](http://www.gsolver.com)

### Grating Solver Development Co.

For Free Info Circle No. 686 or Visit [www.nasatech.com/686](http://www.nasatech.com/686)



## BRUSHLESS DC MOTORS MADE TO LAST FOREVER

New catalog features most complete technical information ever assembled. Charts, diagrams, mech specs, formulas, drive configurations, voltages, power outputs, integration data, in-line parameters, custom applications. Rugged & dependable from 2 oz. to 2,000 oz. Perfect in your (or our) Actuators. Bonus literature sent with all inquiries. A must for any engineer! Island Components Group, Inc., Bohemia, NY; Tel: 631-563-4224; Fax: 631-563-4363; [www.islandcomponents.com](http://www.islandcomponents.com)

### Island Components Group, Inc.

For Free Info Circle No. 687 or Enter No. 687 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## OPERATOR INTERFACE TERMINALS

For nearly 20 years, Maple Systems has provided operator interface solutions for industrial control. With support for over 100 PLCs and motion control products, our alphanumeric and graphic touchscreen terminals can be easily integrated into any application. For more information on our value-packed terminals, call 425-745-3229 or visit [www.maple-systems.com](http://www.maple-systems.com)

### Maple Systems

For Free Info Circle No. 688 or Visit [www.nasatech.com/688](http://www.nasatech.com/688)



## HIGH-QUALITY SCREENS AND FILTER MATERIALS

FREE 68-page manual from Sefar America contains comprehensive product information and samples of precision woven plastic and wire screens. Sefar products provide high-performance filtration and separation for applications including debris screens in appliances, fuel filters for the transportation industry, EMI/RFI filters, blood and fluid filters for healthcare, fluid filters for hydraulics, and many others. Our products are backed by industry-leading technical support and customer service. Sefar America Inc.; Tel: 800-995-0531; Fax: 716-706-0154; e-mail: [h&sinfo@sefaramerica.com](mailto:h&sinfo@sefaramerica.com); [www.sefaramerica.com/hs/intro.htm](http://www.sefaramerica.com/hs/intro.htm)

### Sefar America

For Free Info Circle No. 689 or Enter No. 689 at [www.nasatech.com/rs](http://www.nasatech.com/rs)




## NEW TECHNOLOGY FOR SURFACE PROFILING AND VISUALIZATION

Triptar's surface profiling tool, SurfaceScope™, renders 3D images of surfaces. When combined with Optem's new OptiGrid® hardware that fits to a microscope and extracts height information from the microscope's standard images, an entire field of view can be profiled in seconds. Resolution is limited only by the microscope and the electronic camera used to capture the images. Triptar Lens Company, Inc.; [www.triptar.com/surfacescope.htm](http://www.triptar.com/surfacescope.htm)

### Triptar Lens Company, Inc.

For Free Info Circle No. 690 or Visit [www.nasatech.com/690](http://www.nasatech.com/690)




## Venture Capital: The Definitive Guide

Based on in-depth interviews with major players in the VC arena - including money managers as well as successful entrepreneurs - this new book provides powerful pointers on how to make a business attractive to VCs, how to negotiate agreements, and much more.

336 pages • \$34.95

Order online: [www.nasatech.com/store](http://www.nasatech.com/store)



## Directory of Venture Capital (2nd Edition)

This comprehensive, easy-to-use resource for both new and experienced entrepreneurs covers more than 600 venture capital firms with their addresses, phone numbers, types and sizes of investments, geographic preference, etc.

385 pages • \$39.95

Order online: [www.nasatech.com/store](http://www.nasatech.com/store)



# New on the MARKET

## Meters and Controllers

The iSeries temperature/process and strain meters, and PID controllers from OMEGA Engineering, Stamford, CT, connect to an Ethernet network with a standard RJ-45 connector, enabling them to send and receive data in standard TCP/IP packets. The devices can serve



Web pages over an Ethernet LAN or through the Internet, allowing monitoring and control through a Web browser from any facility. The units can control a heater, change set points, monitor temperature, and even send e-mail messages warning of alarm conditions. **For Free Info Circle No. 700 or Enter No. 700 at [www.nasatech.com/rs](http://www.nasatech.com/rs)**

## Dust Removal

The Ion Air Jet from EXAIR Corp., Cincinnati, OH, delivers a concentrated flow of ionized air to eliminate static electricity and dust, and can be used to clean parts prior to packaging, printing, painting, or finishing. It induces surrounding

airflow at a ratio of 5:1. Force and flow can be adjusted from a "blast" to a "breeze." It features a 5-foot shielded power cable, and is effective at distances up to 15 feet. **For Free Info Circle No. 702 or Enter No. 702 at [www.nasatech.com/rs](http://www.nasatech.com/rs)**



## Tie-Rod Cylinders

TRD Manufacturing, a Bimba Company, Monee, IL, offers NFPA stainless steel body tie-rod cylinders for chemical, medical, and pharmaceutical applications. The SS series features a pre-lubed design, and is available with single or double rod end, oversized rods, and bore sizes ranging from 1-1/2" to 8". The SS-NR series is a non-rotating version of the SS series. Accessories include all stainless steel alignment couplers, switches, and rod clevis and mounts. **For Free Info Circle No. 703 or Enter No. 703 at [www.nasatech.com/rs](http://www.nasatech.com/rs)**



## Drive System Simulation

Ansoft Corp., Pittsburgh, PA, has released Simplorer 5.0 mixed-technology simulation software for automotive electrical/electromechanical systems and power-electronic and drive applications. The software combines tailor-made simulation tools for circuit simulation, block diagrams, electrical machine models, and state machines for digital and discontinuous systems. All of the engineering languages can be used simultaneously, eliminating the need for mathematical transformations. **For Free Info Circle No. 704 or Enter No. 704 at [www.nasatech.com/rs](http://www.nasatech.com/rs)**



ASME International

## In Business Problems? In-Company Solutions

*Identify your training needs and save time, while cutting costs with ASME In-Company Programs!*

- ASME has the engineering courses and industry experts that enable your company to stay ahead in today's competitive marketplace.
- We will work closely with you to ensure that objectives are met and examples are incorporated specific to your company's needs.

*Call or e-mail to find out more information about ASME In-Company Programs today!*

**ASME International**

**Tel: 212-591-7752**

**Web: [www.asme.org/pro\\_dev](http://www.asme.org/pro_dev)**

**Email: [rubine@asme.org](mailto:rubine@asme.org)**

**For Free Info Circle No. 573 or  
Enter No. 573 at [www.nasatech.com/rs](http://www.nasatech.com/rs)**

## It Pays To Use Laserge... Custom Laser Processing Services

Laserge provides you with over 20 years of laser welding experience. Our staff of technical experts are ready to assist you with a high level of support from R&D engineering capabilities, to our complete metallurgical lab, to high production volumes associated with fully or semi-automated tooling applications. We assure high quality finished products, allowing you to be the first to market every time.

- Laser Machining of:  
Stents, Substrates, Ceramics,  
Composites, Plastics, Glass,  
Rubber, Metal & Most Materials
- Laser Scribing
- Laser Drilling
- Laser Welding
- Custom Cable & Wire  
Harness Assembly

See Us at NDE  
Booth # 7317

Call today for a free quotation.  
Tel: 800.830.3070  
Fax: 847.336.1103  
E-mail: [metals@laserge.com](mailto:metals@laserge.com)  
[www.laserge.com](http://www.laserge.com)



LASERGE  
TECHNOLOGY  
CORPORATION



**For Free Info Circle No. 562 or  
Enter No. 562 at [www.nasatech.com/rs](http://www.nasatech.com/rs)**



# SOME LIKE IT HOT!

Poco's high temperature graphites stand up to the challenges of today's hotter, more powerful engines, turbines and aerospace applications.

## Bring on the Heat!

Call POCO at 940-393-4480 for your custom graphite parts.  
E-mail: [industrial@poco.com](mailto:industrial@poco.com)

POCO GRAPHITE, INC.  
300 OLD GREENWOOD RD.  
DECATUR, TEXAS 76234  
[www.poco.com](http://www.poco.com)  
Toll-Free 877-762-6747

**POCO**  
GRAPHITE


For Free Info Circle No. 547 or  
Enter No. 547 at [www.nasatech.com/rs](http://www.nasatech.com/rs)

## EPOXY RESISTS CHLORINATED ACIDS AND AGGRESSIVE CHEMICALS

Designed To Your Specifications

MASTER BOND  
EP41S-4

■ Room temperature and/or elevated temperature cures ■ Convenient, non critical mix ratio ■ Excellent resistance to methylene chloride and other chlorinated solvents ■ Resistance to fuels, alcohols, acids, bases and salt solutions ■ High bond strength to both metallic and non-metallic substrates ■ Superior coating, bonding & sealing characteristics ■ 100% reactive, gap filling composition ■ Excellent dimensional stability ■ Easy application ■ Convenient packaging



**Master Bond Inc.**  
Adhesives, Sealants & Coatings

154 Hobart St., Hackensack, NJ 07601  
TEL: 201-343-8983 FAX: 201-343-2132

[www.MasterBond.com](http://www.MasterBond.com) ■ [main@masterbond.com](mailto:main@masterbond.com)


For Free Info Circle No. 550 or  
Enter No. 550 at [www.nasatech.com/rs](http://www.nasatech.com/rs)

# New LITERATURE

## Direct Writing System

A PC-compatible CD-ROM from OhmCraft, Honeoye Falls, NY, contains two video programs demonstrating the MicroPen™ direct writing system for use where screen printing and thin film technologies cannot be used. Applications include repairing an FR-4 board, prototyping a multi-layer circuit, writing a precision seal on glass, and drawing helical electrodes on an electrosurgical probe.

For Free Info Circle No. 706 or Enter No. 706 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## Pressure Regulators

Tescom, Elk River, MN, offers a 13-page brochure highlighting high-pressure, low-pressure, and high-flow controls, as well as back-pressure, hydraulic, and corrosion-resistant regulators. The catalog details inlet pressure, outlet pressure ranges, flow capacity, and body material of every product. For Free Info Circle No. 707 or Enter No. 707 at [www.nasatech.com/rs](http://www.nasatech.com/rs)




## Slides and Actuators

PHD, Fort Wayne, IN, has released "Productivity Solutions," a catalog containing information about the Series STP and SHP rail bearing slides, Series GRR and GRL grippers, and Series RI rotary actuator. Also included are engineering data, information on product applications, engineering software, and a Designer's Resource® CD-ROM. For Free Info Circle No. 708 or Enter No. 708 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## Slide Assemblies

Catalog M-2002 from Velmex, Bloomfield, NY, features over 235 motor-driven UniSlide Assemblies for scanning, feeding, or incremental positioning. Applications include R&D, manufacturing, and testing. Linear and rotary assemblies are available for single- or multi-axis systems. For Free Info Circle No. 709 or Enter No. 709 at [www.nasatech.com/rs](http://www.nasatech.com/rs)



## Grinders and Spindles

NSK America Corp., Schaumburg, IL, offers a product catalog describing grinders, spindles, hand grinders, and ultrasonic cutters. Also included are machines for hand work, machines for machine attachment, and parts and accessories for hand work and machine attachments. For Free Info Circle No. 710 or Enter No. 710 at [www.nasatech.com/rs](http://www.nasatech.com/rs)





# FREE INFORMATION REQUEST FORM

## For quickest service:

**Fax** this form to (413) 637-4343

**Use the online** reader service center at [www.nasatech.com/rs](http://www.nasatech.com/rs)

**Or mail** your completed form to  
**NASA Tech Briefs,**  
 PO Box 5077, Pittsfield, MA 01203-9109.

Name: \_\_\_\_\_

Company: \_\_\_\_\_

Address: \_\_\_\_\_

City/St/Zip: \_\_\_\_\_

Phone: \_\_\_\_\_

Fax: \_\_\_\_\_

e-mail: \_\_\_\_\_

Please tell us below how *NASA Tech Briefs* has helped you solve a problem or been applied to your business/product line.

\_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

Do you currently receive *NASA Tech Briefs*? ☐ Yes ☐ No

If no, would you like to receive *NASA Tech Briefs*? ☐ Yes ☐ No

Circle the numbers below to receive more information about products and services featured in this issue.

401	402	403	404	405	406	407	408	409	410
411	412	413	414	415	416	417	418	419	420
421	422	423	424	425	426	427	428	429	430
431	432	433	434	435	436	437	438	439	440
441	442	443	444	445	446	447	448	449	450
451	452	453	454	455	456	457	458	459	460
461	462	463	464	465	466	467	468	469	470
471	472	473	474	475	476	477	478	479	480
481	482	483	484	485	486	487	488	489	490
491	492	493	494	495	496	497	498	499	500
501	502	503	504	505	506	507	508	509	510
511	512	513	514	515	516	517	518	519	520
521	522	523	524	525	526	527	528	529	530
531	532	533	534	535	536	537	538	539	540
541	542	543	544	545	546	547	548	549	550
551	552	553	554	555	556	557	558	559	560
561	562	563	564	565	566	567	568	569	570
571	572	573	574	575	576	577	578	579	580
581	582	583	584	585	586	587	588	589	590
591	592	593	594	595	596	597	598	599	600
601	602	603	604	605	606	607	608	609	610
611	612	613	614	615	616	617	618	619	620
621	622	623	624	625	626	627	628	629	630
631	632	633	634	635	636	637	638	639	640
641	642	643	644	645	646	647	648	649	650
651	652	653	654	655	656	657	658	659	660
661	662	663	664	665	666	667	668	669	670
671	672	673	674	675	676	677	678	679	680
681	682	683	684	685	686	687	688	689	690
691	692	693	694	695	696	697	698	699	700
701	702	703	704	705	706	707	708	709	710
711	712	713	714	715	716	717	718	719	720
721	722	723	724	725	726	727	728	729	730
731	732	733	734	735	736	737	738	739	740
741	742	743	744	745	746	747	748	749	750
751	752	753	754	755	756	757	758	759	760
761	762	763	764	765	766	767	768	769	770
771	772	773	774	775	776	777	778	779	780
781	782	783	784	785	786	787	788	789	790
791	792	793	794	795	796	797	798	799	800
801	802	803	804	805	806	807	808	809	810
811	812	813	814	815	816	817	818	819	820
821	822	823	824	825	826	827	828	829	830
831	832	833	834	835	836	837	838	839	840

## ARE YOU AN INSIDER?

Subscribe today to receive the INSIDER, a FREE e-mail newsletter from *NASA Tech Briefs*. The INSIDER features exclusive previews of upcoming articles...late-breaking NASA and industry news...hot products and design ideas...links to online resources...and much more.

☐ I want to be an INSIDER. Send my newsletter to the following e-mail address:

Name \_\_\_\_\_

Company \_\_\_\_\_

I also want to receive special-focus e-newsletters on the following technology topics: (check all that apply)

- |                                  |  |
|----------------------------------|--|
| <input type="checkbox"/> CAD/CAE | <input type="checkbox"/> Fiber Optics/Communications |
| <input type="checkbox"/> Lasers  | <input type="checkbox"/> Test & Measurement          |
| <input type="checkbox"/> Optics  | <input type="checkbox"/> Imaging/Cameras             |
| <input type="checkbox"/> Sensors |  |

**For fastest service, sign up online  
 at [www.nasatech.com/insider](http://www.nasatech.com/insider)**



# Advertisers Index

For free product literature from these advertisers, enter their reader service numbers at [www.nasatech.com/rs](http://www.nasatech.com/rs)

Advertisers listed in bold-face type have banner ads on the NASA Tech Briefs Web site — [www.nasatech.com](http://www.nasatech.com)


Company	Reader Service Number	Page
Abaris Training Resources	425	68
ABZ	677	77
Accuride	505	54, 55
Aero Tec	454	73
<b>Algor, Inc.</b>	<b>513</b>	<b>7</b>
American Magnetics, Inc.	684	78
Ansoft Corporation	566	49
ANSYS, Inc.	576	75
ARC Second Inc.	528	8
ASME International	573	79
Astro-Med	405	19
Autodesk	507	15
W.M. Berg, Inc.	493	73
Cargille Laboratories Inc.	451	71
Carpenter Technology	520	39
Ceramco Inc.	685	78
COADE, Inc.	679	77
Comet Industries	673	77
Comsol, Inc.		25-26
CUI Stack	410	16
Cutting Edge Optonics	421	7a
Dewetron	402	23
Digi-Key Corporation	523	3
Dolch Computer Systems	512	17
DuPont Krytox	441	51
DuPont Vespel	524	57
Dyadem International Ltd.	678	77
EDS/PLM Solutions	518	21
Emhart, a Black & Decker Company	411, 534	28, 29
Encoder Products Company	680	77
<b>Engineering Design Team (EDT)</b>	<b>414</b>	<b>66</b>
Epix	419	10a
FJW Optical Systems, Inc.	452	22a
Fluoramics Inc.	572	74
Gage Applied, Inc.	403	20
Globe Motors	422	58
Grating Solver Development	686	78

Company	Reader Service Number	Page
IBM	558	COV IV
IEEE	401	2
Indigo Systems	485	1a
Instron Corporation	526	33
Instrument Technology	670	77
Integrated Engineering Software	539	COV III
Island Component Group	687	78
Kaman Instrumentation Corp.	404	18
Kato Fastening Systems	681	78
<b>Keithley Instruments, Inc.</b>	<b>509</b>	<b>45</b>
Krohn-Hite	676	77
Lake Shore Cryotronics	672	77
Lambda Research Corporation	473	9a
Laserage Technology Corp	562	79
Magnetic Shield Corporation	517	72
Maple Systems	688	78
<b>Master Bond Inc.</b>	<b>550</b>	<b>80</b>
MathSoft	503	9
The MathWorks, Inc.	525	31
Micro-Epsilon	426	65
Minalex Corporation	671	77
Minco Products, Inc.	497	63
<b>MSC Software</b>	<b>579</b>	<b>67</b>
MTI Instruments	533	71
<b>National Instruments Corporation</b>	<b>436, 412, 674, 436</b>	<b>COV II, 37, 77, 5a</b>
Noran Engineering, Inc.	415	10
<b>NuSil Technology</b>	<b>522</b>	<b>56</b>
Ocean Optics Inc.	581	42
Omega Engineering, Inc.	500, 501, 660-668	1, 76
<b>Optical Society of America</b>		<b>21a</b>
Orand Systems Inc.	669	77
PEM Fastening Systems - A PennEngineering Company	529	64
PhotoMachining, Inc.	675	77
Photon, Inc.	438	13a
Photron USA	555	48
PIC Design	682	78
Poco Graphite, Inc.	547	80
PTC	516	41
Redlake MASD	502	47
<b>Research Systems, A Kodak Company</b>	<b>504</b>	<b>34</b>
SAMPE		69
Seal Master Corporation	557	58
Sefar America	689	78
Sensors Expo		19a
Solid Edge-EDS PMS Solutions	518	59
Spectra-Physics Lasers	511	11a
StellarNet Inc.	418	6a
StereoGraphics	531	60
Structural Research & Analysis Corp.	508	53
Synrad, Inc.	563	11
TEAC America, Inc.	506	13
<b>Tescom Corporation</b>	<b>406</b>	<b>70</b>
TranTek Drive Systems	515	62
Tripart Lens Co.	690	78
Tusk Direct	683	78
Velmex	486	68
Visual Numerics	560	59
VX Corporation	546	4-5
Xerox Engineering Systems, Inc.	530	61
<b>yet2.com</b>	<b>585, 489</b>	<b>30, 36, 6a, 15a</b>
Zaber	444	10a
ZC & R	469	3a

## Join the Digital Revolution

Download a FREE sample of  
NASA Tech Briefs' NEW electronic  
edition at [www.qmags.com/ntb](http://www.qmags.com/ntb)

- Search and archive PDF issues
- Link seamlessly from articles/ads to Web resources
- Get earlier delivery, and special technology supplements



Start or renew  
your subscription at:  
[www.nasatech.com/subscribe](http://www.nasatech.com/subscribe)

NASA Tech Briefs, ISSN 0145-319X, USPS 750-070, copyright ©2002 in U.S. is published monthly by Associated Business Publications Co., Ltd., 317 Madison Ave., New York, NY 10017-5391. The copyright information does not include the (U.S. rights to) individual tech briefs that are supplied by NASA. Editorial, sales, production, and circulation offices at 317 Madison Ave., New York, NY 10017-5391. Subscription for non-qualified subscribers in the U.S., Panama Canal Zone, and Puerto Rico, \$75.00 for 1 year; \$135 for 2 years. Single copies \$5.00. Foreign subscriptions one-year U.S. Funds \$195.00. Remit by check, draft, postal, express orders or VISA, MasterCard, and American Express. Other remittances at sender's risk. Address all communications for subscriptions or circulation to NASA Tech Briefs, 317 Madison Ave., New York, NY 10017-5391. Periodicals postage paid at New York, NY and additional mailing offices.

POSTMASTER: Send address changes to NASA Tech Briefs, PO Box 10523, Riverton, NJ 08076-9023.



# These won't save you time or money ...

$$\nabla \times \mathbf{H} = \mathbf{J} + \epsilon \frac{\partial \mathbf{E}}{\partial t} \quad \nabla \times \mathbf{E} = -\mu \frac{\partial \mathbf{H}}{\partial t} \quad \nabla \cdot \mathbf{E} = \frac{\rho}{\epsilon} \quad \nabla \cdot \mathbf{H} = 0$$

## THESE WILL



A CAE electromagnetic package that immediately boosts productivity and saves prototyping costs is hard to find. That's where our line of innovative boundary element method (BEM) simulation software can help.

We've designed each of our packages around three basic principles: **advanced technology; productivity and outstanding customer service.**



A clean, intuitive, user interface means the software is easier to use and learn than most other electromagnetic CAE tools.

### Advanced Technology

We use Integrated's software to model precision magnetic circuits for the reprographics industry as well as other electromagnetic applications. The software enables us to create extremely accurate virtual results. This has allowed us to greatly reduce our prototype-to-production phase."

**Group Arnold**  
Magnetic Technologies Corp,  
Rochester, NY.

Advanced features like our intuitive user interface, extensive materials library, powerful solvers, exportable data and graphics, flexible post processing options and powerful parametric optimization routines give you the most sophisticated programs available anywhere. In addition, our coupled electromagnetic/mechanical suite gives you complete solutions.

### Productivity

"Integrated's software offers Industrial Coils the ability to model our designs quickly and accurately. Our design time has been reduced from three weeks down to two and a half days.

**Mike Potter**  
Assistant Engineering Manager,  
Industrial Coils,  
Baraboo, WI.

You'll be producing useful designs in a matter of hours! We provide you with sample sessions to work through, on-line help, web support and full technical and application support to help you solve your toughest design issues. You also get industry standard links that connect you to your favorite CAD program for easy file import/export, shortening your design process even further.

In just minutes, install your program on your desktop PC. Within one day begin working on,

and solving your own designs. In just one week, solve even the most challenging and sophisticated 3D designs.

### Ease and Accuracy

"We are using Amperes to model the recording process for both the writing and reading of high density data storage apps. We are very impressed with the user friendliness and accuracy of the program."

**Dr. Sakhrat Khizroev**  
**Dr. Dimitri Litvinov**  
Seagate Technologies  
Pittsburgh, PA.

### Solution capabilities include:

- magnetostatics
- eddy currents
- electrostatics
- charged particle
- high frequency
- mechanical
- thermal
- And more ...

### Yours FREE for 30 days ...

Call 204-632-5636 to order your free, no-obligation demo kit complete with:

- Tutorials

- Quick-start guide
- Full technical support
- Full user support
- Sample sessions
- Technical papers
- All FREE ...



Your **FREE** Demo kit will have you working in a matter of hours.

**Try it FREE**  
**Call today:**  
**1-204-632-5636**

**INTEGRATED**  
ENGINEERING SOFTWARE

**Web:** [www.integratedsoft.com](http://www.integratedsoft.com)  
**E-mail:** [Info@integratedsoft.com](mailto:Info@integratedsoft.com)





IBM IntelliStation E Pro  
(monitor sold separately)

Certified to  
run over 200  
applications.



— Create your own dimension,  
or just work really fast in this one.

#### Go hyperdimensional with IBM IntelliStation® workstations.

They're optimized to run some of the most demanding architectural and engineering applications in the industry, through an **intense testing and certification process**. Certified applications include PTC, CATIA, Autodesk, Cadence and SolidWorks.<sup>1</sup> The net results are you'll drag and drop – as well as rotate and zoom – fast. In fact, in the past two years, IBM IntelliStation workstations have swept **ten of ten SPECopc benchmarks** three times.<sup>2</sup> What that means to you is less time waiting for your machine to catch up with your thoughts.

#### IBM IntelliStation E Pro

Affordable workstation power

Intel® Pentium® 4 processor 1.80GHz  
128MB ECC memory  
Matrox G450 graphics  
40GB ATA/100 EIDE hard drive (7200 rpm)  
48X\* max CD-ROM  
Microsoft® Windows® 2000 Professional  
3-year parts and onsite labor limited warranty\*

**\$1,389<sup>§</sup>**

NavCode  
621420U-M395

Customize Yours:

**256MB 133MHz ECC SDRAM**  
(Part #10K0046) \$149

#### IBM IntelliStation M Pro

Exceptional workstation performance

Intel Pentium 4 processor 1.70GHz  
512MB ECC memory  
ATI Fire GL2  
18.2GB Ultra160 SCSI hard drive  
48X max CD-ROM  
Microsoft Windows 2000 Professional  
3-year parts and onsite labor limited warranty

**\$2,669**

NavCode  
684933U-M395

Customize Yours:

**512MB 800MHz ECC RDRAM**  
(Part #33L254) \$599



Get the tools that inspire  
success. Request an  
IBM PC Guide today.  
Call toll free  
1 866 426-8573.



**Direct  
To You**

Call toll free 1 866 426-8573 or  
Click **www.ibm.com/intellistation/M395**  
to buy direct, locate an IBM reseller or for more information.

NavCode™ Get the latest pricing and information fast. Use NavCode on the phone or on the Web.

Looking for Microsoft® Office XP<sup>7</sup> or 2000 Small Business on the  
system you want? Simply contact us to order it at an additional cost.

IBM PCs use genuine Microsoft® Windows®  
[www.microsoft.com/piracy/howtotell](http://www.microsoft.com/piracy/howtotell)

<sup>1</sup>For non-IBM software, applicable third-party licenses may apply. Warranty, service and support for non-IBM products, if any, are provided by third parties, not IBM. IBM makes no representations or warranties regarding non-IBM products. <sup>2</sup>Standard Performance Evaluation Corp., July 2000, March 2001 and August 2001. <sup>3</sup>GB = 1,000,000,000 bytes when referring to storage capacity; accessible capacity is less. <sup>4</sup>CD and DVD drives list maximum rates; rates are variable and are often less than the maximum. <sup>5</sup>For a copy of IBM's Statement of Limited Warranty, call 1 800 772-2227. Telephone support may be subject to additional charges. For onsite labor, IBM will attempt to diagnose and resolve the problem remotely before sending a technician. <sup>6</sup>Prices do not include tax or shipping and are subject to change without notice. Reseller prices may vary. <sup>7</sup>Certain Microsoft® software product(s) included with this computer may use technological measures for copy protection. IN SUCH EVENT, YOU WILL NOT BE ABLE TO USE THE PRODUCT IF YOU DO NOT FULLY COMPLY WITH THE PRODUCT ACTIVATION PROCEDURES. Product activation procedures and Microsoft's privacy policy will be detailed during initial launch of the product, or upon certain reinstallations of the software product(s) or reconfigurations of the computer, and may be completed by Internet or telephone (toll charges may apply). All offers subject to availability. IBM reserves the right to alter product offerings and specifications at any time, without notice. IBM cannot be responsible for photographic or typographic errors. IBM makes no representations or warranties regarding third-party products or services. All IBM product names are registered trademarks or trademarks of International Business Machines Corporation. Intel, Intel Inside, the Intel Inside logo and Pentium are registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries. Microsoft and Windows are registered trademarks of Microsoft Corporation. Other company product and service names may be trademarks or service marks of others. ©2002 IBM Corp. All rights reserved.